



Machine list ZZ 1560 AUT series

Setting up the control box MD-4-ED-220, i70L-4-ED-220 or i60-4-GL-220 on Global ZZ 1560 AUT series

| | Page |
|--|------|
| 1 - Connecting the machine cable | 1 |
| 2 - Parameter setting for under the table mounting. Drive by V-belt | 2 |
| 3 - Setting the needle positions for under the table mounting. Drive by V-belt | 3 |
| 4 - Parameter setting for direct drive | 4 |
| 5 - Setting the needle positions for direct drive on MD-4-ED-220 | 5 |
| 6 - Setting the needle positions for direct drive on i60-4-GL-220 | 6 |

Connecting the machine cable:

Cable colours (D-sub 37-pin connector MD-4-ED-220, i70L-4-ED-220 and i60-4-GL-220):

| Pin | Descript. | Function | Colour |
|------|-----------|--|------------------------------|
| 1 | R-SELEKT | Automatic machinecode setting (don't connect) | White (don't connect) |
| 4 | R-N-HP | Automatic machinecode setting (don't connect) | Brown (don't connect) |
| 5 | ZVR SW. | Reverse switch | Green |
| 6 | NHT SW. | Needle UP / DOWN switch | Yellow |
| 8 | STK SW. | Change of stitch length output (don't connect) | Grey (don't connect) |
| 11 | LSP | Safety switch (don't connect) | Pink (don't connect) |
| 14 | VRU SW. | Backtack suppression (don't connect) | Blue (don't connect) |
| 15 | WALZ | Puller output (don't connect) | Red (don't connect) |
| 16 * | + 24 Volt | + 24 Volt (don't connect) | Red - Blue |
| 17 * | + 24 Volt | + 24 Volt (don't connect) | Red - Blue |
| 26 | + 24 Volt | + 24 Volt (don't connect) | Red - Blue |
| 27 | FW | Thread wiper output (don't connect) | Purple (don't connect) |
| 28 | NK / US | Needle Cooling output (don't connect) | Grey - Brown (don't connect) |
| 33 | + 24 Volt | + 24 Volt | Red - Blue |
| 34 | VR | Reverse output | White - Green |
| 35 | FL | Foot lifter output | Green - Brown |
| 36 | FSPR | Thread Tension release output | Yellow - White |
| 37 | FA | Thread Trimmer output | Yellow - Brown |

* = not connected on every Ho Hsing model

Parameter setting for under the table mounting. Drive by V-belt:

| Parameter access | Action |
|------------------|--------------------------------|
| 1 – 46 | In normal mode, press P button |
| 47 – 122 | Press P button and power ON |
| 123 – rest | Press S button and power ON |

NOTE: always set [047.MAC] machine code first


Parameter setting for MD-4-ED-220, i70L-4-ED-220 and i60-4-GL-220 on Global ZZ 1565 AUT series

| Parameter | Value | Description |
|-----------|------------------|---|
| [047.MAC] | 0 | Machine code setting |
| [001.L] | - - - | Max. speed setting (depends on machine model) |
| [004.N] | 1000 | Start backtack speed |
| [005.V] | 1000 | End backtack speed |
| [008.SLS] | 0 | Soft start stitch setting |
| [046.DIR] | CCW | On MD-4-ED-220; direction of motor rotation |
| | CW | On i60-4-GL-220; direction of motor rotation |
| [053.POL] | OFF | Soft start after power ON |
| [057.TRU] | ON | Turn back angle after trimming (set to ON after needle positions are set) |
| [058.TR8] | 25 | Turn back angle in degrees |
| [060.L] | 150 | Positioning speed |
| [061.T] | 190 | Trimming speed |
| [066.FD] | 100 | Motor run delay after presser foot down |
| [079.LTM] | T2 | Mode selection for trimmer sequence |
| [080.LLM] | L2 | Mode selection for thread tension sequence |
| [081.TS] | 30 | Start trimmer signal after needle DOWN |
| [084.TE] | 110 | Trimmer signal length |
| [085.LS] | 60 | Start thread tension signal after needle DOWN |
| [088.LE] | 220 | Thread tension signal length |
| [122.HL] | - - - | Maximum speed limiter (depends on machine model) |
| [164.MXi] | 500 W. motor: 14 | 600 Watt motor: 15 750 Watt motor: 18 |
| [166.ACT] | 240 | |
| [167.DCT] | 260 | |
| [168.HKP] | 25 | |
| [169.LKP] | 35 | |
| [170.KP] | 25 | |
| [176.VDN] | OFF | Needle positioning by synchronizer |
| [192.PTE] | OFF | Positioning Teach in mode |
| [209.IDX] | UP | Source of index |

Setting the needle positions for under the table mounting. Drive by V-belt:

For setting the needle positions parameter [057.TRU] (turn back angle after trimming) must be set to OFF first. After the needle positions are set parameter [057.TRU] must be set to ON again. Needle positions are set by disc A (needle UP position) and disc B (needle DOWN position) inside the external synchroniser (see picture).

Needle DOWN position:




With the presserfoot UP,
the presserfoot can not touch
the needle bar




Thread lever upper dead point

Needle UP position



External synchroniser



Disc A (Needle UP)

Disc B (needle DOWN)













Parameter setting for Direct drive:

NOTE: always set / check [047.MAC] machine code first


Parameter setting for MD-4-ED-220, i70L-4-ED-220 and i60-4-GL-220 on Global ZZ 1565 AUT series

| Parameter | Value | Description |
|-----------|--------------------|--|
| [047.MAC] | 0 | Machine code setting |
| [001.L] | --- | Max. speed setting (depends on machine model) |
| [004.N] | 1000 | Start backtack speed |
| [005.V] | 1000 | End backtack speed |
| [008.SLS] | 0 | Soft start stitch setting |
| [046.DIR] | CCW | On MD-4-ED-220; direction of motor rotation |
| | CW | On i60-4-GL-220; direction of motor rotation |
| [053.POL] | OFF | Soft start after power ON |
| [057.TRU] | ON | Turn back angle after trimming |
| [058.TR8] | 25 | Turn back angle in degrees |
| [060.L] | 150 | Positioning speed |
| [061.T] | 190 | Trimming speed |
| [066.FD] | 100 | Motor run delay after presser foot down |
| [079.LTM] | T2 | Mode selection for trimmer sequence |
| [080.LLM] | L2 | Mode selection for thread tension sequence |
| [081.TS] | 30 | Start trimmer signal after needle DOWN |
| [084.TE] | 110 | Trimmer signal length |
| [085.LS] | 60 | Start thread tension signal after needle DOWN |
| [088.LE] | 220 | Thread tension signal length |
| [122.HL] | --- | Maximum speed limiter (depends on machine model) |
| [164.MXi] | 500 Watt motor: 14 | 600 Watt mini motor: 15 750 Watt mini motor: 18 |
| [166.ACT] | 240 | |
| [167.DCT] | 260 | |
| [168.HKP] | 25 | |
| [169.LKP] | 35 | |
| [170.KP] | 25 | |
| [176.VDN] | A | Needle positioning by synchronizer |
| [192.PTE] | ON | Positioning Teach in mode |
| [209.IDX] | UP | Source of index |

MD-4-ED-220, Setting the needle positions for Direct Drive:

| Action | Display shows |
|---|----------------------------|
| 1 Press  button and  button to turn Start and End back tack OFF | display is blank |
| 2 press  button and turn ON the power at the same time | 176.VDN |
| 3 press  button 5 times | 181. PDA |
| 4 press  button 1 time | PDA xxx (current value) |
| 5 press pedal slowly to make the machine run at least 2 rotations | PDA xxx (new value) |
| 6 rotate the hand wheel in normal sewing direction until the needle is in the position of picture 1 | |
| 7 press  button 1 time (under the display under "A") | PDA xxx will blink 2 times |
| 8 press  button to confirm | display is blank |
| 9 press  button for 2 seconds | 181. PDA |
| 10 press  button 2 times | 179. PUA |
| 11 press  button | PUA xxx (current value) |
| 12 press pedal slowly to make the machine run at least 2 rotations | PUA xxx (new value) |
| 13 rotate the hand wheel in normal sewing direction until the thread lever is in the Upper dead point position of picture 2 | |
| 14 press  button (under the display under "A") | PUA xxx will blink 2 times |
| 15 press  button to confirm | display is blank |
| 16 Finished | |


Picture 1









With the presser foot UP,
the presser foot can not touch
the needle bar

Thread Lever Upper Dead Point


Picture 2



i60-4-GL-220 and i70L-4-ED-220, Setting the needle positions for Direct Drive:

| Action | Display shows |
|---|----------------------------|
| 1 Press  button and  button to turn Start and End back tack OFF | display shows rotation "0" |
| 2 press  button and turn ON the power at the same time | 176.VDN |
| 3 press P button 5 times | 181. PDA |
| 4 press S button 1 time | PDA xxx (current value) |
| 5 press pedal slowly to make the machine run at least 2 rotations | PDA xxx (new value) |
| 6 rotate the hand wheel in normal sewing direction until the needle is in the position of picture 1 | |
| 7 press  ^A button 1 time | PDA xxx will blink 2 times |
| 8 press S button 1 time to confirm | display shows rotation "0" |
| 9 press P button 1 time | 181. PDA |
| 10 press  button 2 times | 179. PUA |
| 11 press S button | PUA xxx (current value) |
| 12 press pedal slowly to make the machine run et least 2 rotations | PUA xxx (new value) |
| 13 rotate the hand wheel in normal sewing direction until the thread lever is in the Upper dead point position of picture 2 | |
| 14 press  ^A button 1 time | PUA xxx will blink 2 times |
| 15 press S button to confirm | display shows rotation "0" |
| 16 Finished | |

Picture 1



With the presser foot UP,
the presser foot can not touch
the needle bar

Thread Lever Upper Dead Point

Picture 2

