


# PORTER

DESIGNERS AND MANUFACTURERS OF SPECIALIZED INDUSTRIAL SEWING EQUIPMENT

# PNR

*The Tape Edge Closing Machine*



CONTENTS

SET UP  
OPERATION

PARTS

ASSEMBLY

ASSEMBLY  
DIAGRAMS

**INSTRUCTIONS,  
PARTS CATALOG &  
SERVICE MANUAL**



## PORTER

SEWING MACHINES, INC.

97 RANTOUL STREET, BEVERLY, MA 01915

## CONTENTS

### SET-UP AND OPERATION

Assembly Instructions .....	3
Sewing Head Adjustments .....	4
Operating Instructions .....	13

### PARTS

Sewing Head Parts .....	15
PNR Parts .....	17
Standard Parts .....	20
PNR Accessory Parts .....	21

### ASSEMBLY

Front Assembly Sewing Arm .....	23
Upper Shaft Assembly .....	24
External Parts Sewing Arm .....	25
Front Assembly Sewing Bed .....	28
Lower Shaft Assembly .....	29
External Parts Sewing Bed .....	30
Cross Shaft in Sewing Bed .....	31
Gear Box Assembly .....	32
Caster Assembly .....	33

### ASSEMBLY DIAGRAMS

Main Drive Assembly .....	34
Machine Traverse Speed Adjustment .....	39
Table .....	40
Swivel Assembly .....	42
Sewing Head Drive-belt Path .....	43
Lubrication .....	43
Piping Attachment .....	44

### WIRING DIAGRAMS

Table Wiring Diagram .....	45
Main Drive Wiring Diagrams .....	46

SEWING HEAD PARTS CHART .....	Insert
-------------------------------	--------

Printed in USA  
2M 9-90

©1990 Porter Sewing Machines, Inc.

## ASSEMBLY INSTRUCTIONS

The PNR Tape Edge system consists of three main assemblies: the table, the carriage, and the sewing head.

When locating the table, care must be taken to find a level section on the production floor. To level the table, adjustment screws with lock nuts are located at the bottom of each table leg. Additional powered adjustments are available to adjust the table height to individual operators.

The carriage assembly mounting requires the removal of the roller and stud assembly from the upper track level bracket. When the carriage has been lifted on to the track and is running on its casters, the roller and stud can be replaced.

The sewing head can be attached to the carriage by means of four (4) hex head screws which are provided. The screws are mounted from underneath the carriage tilt plate. The drive wheel cover and its V-belt should be removed so that the V-belt can be fastened over the pulley. The drive belt must be attached before operating. The sewing head comes fully threaded, so observe the various thread guides.

Located on the carriage are two electrical outlets. The top outlet is the main power wire coming down from the swivel. The bottom outlet is for the work light. Both plugs are of the twist-on type.

Fasten the thread cone platter and the top reel on the same side of the carriage away from the edge of the table. Three thread guides consisting of a wire loop at each end are fastened to the carriage and sewing head below the tape reel.

The right-hand (needle) thread uses two thread guides, a long one on the carriage and a shorter one on the head. The looper thread, further to the left, uses only one (long) thread guide on the carriage. These guide the two threads to the bracket on the top of the head. The looper thread passes from the bracket down through a tube provided.

The ceiling electrical connection should now be connected. It should be located 7" (2.15M) to 10' (3.08M) above the floor level. The swivel wire is brought down and threaded thru a loop which is fastened to the sewing head. The swivel wire is plugged in and twisted (locked) in place on the upper of the two connectors located on the side of the carriage.

Now the machine is ready to operate.

*Note: You should turn the head over by hand to insure correct operations before power is turned on.*

## NEEDLES

The size of the needle to be used is determined by the size of the thread which must pass freely through the eye of the needle.

Orders for needles should specify quantity required and size number.

### To Set The Needle

Turn machine pulley over toward the operator until the needle bar is at its highest point, as shown in Fig. 1.

Insert needle into needle bar as far as it will go, making certain that the scarf of the needle faces toward the left, as shown in Fig. 1.

## THREADING THE MACHINE


### Upper Threading

Turn machine pulley over toward operator until needle bar is at its highest point.

Pass thread from unwinder through threading points indicated in Fig. 2. See insert, Fig. 2, for correct threading of needle.

Draw approximately two inches of thread through needle eye with which to start sewing.


FIG. 1



## THREAD

Either left twist or right twist may be used in the needles and loopers.

Rough or uneven thread, or thread which passes through the needle eye with difficulty will interfere with successful operation of the machine.



### THREADING THE LOOPERS

Pass thread from unwinder through threading points as indicated. Draw approximately two inches of thread through looper eye with which to start sewing.




FIG. 3

## TENSION

Tension on thread should be light as possible while still sufficient to set the stitch correctly in material.

### Needle Thread Tension

To regulate needle thread tension, turn thumb screw, indicated in Fig. 3, as required.

*IMPORTANT: Regulate needle thread tension only when presser foot is down.*

### Looper Thread Tension

To regulate looper thread tension, turn thumb screws, indicated in Fig. 4, as may be required.

FIG. 4





FIG. 5



## STITCH LENGTH

To adjust the stitch length, depress plunger, Fig. 5, located on top of arm. Continue to hold plunger down and turn machine pulley toward operator until plunger enters notch in arm shaft eccentric. Turn plunger to lock in position. Depress button, Fig. 5, located on machine bed. Hold down and turn machine pulley toward operator to increase length of stitch, or away from operator to decrease length of stitch. Letter "A" on machine pulley indicates the longest stitch. When desired length, indicated by letter, is opposite arrow on front of machine; release button and turn plunger to right or left until it springs outward.

*CAUTION: Never turn machine pulley with plunger in locked position until button on machine bed is depressed.*

## PRESSURE

Pressure on material should be as light as possible while still sufficient to insure correct feeding.

### Alternating Pressers

To increase pressure, loosen lower lock nut and loosen lock screw, then tighten upper lock nut, Fig. 6. When correct pressure is attained, tighten lock screw. Then tighten the lower lock nut. To decrease pressure, loosen upper lock nut and loosen lock screw, then tighten lower lock nut. When correct pressure is attained, tighten lock screw. Then tighten the upper lock nut.

**CAUTION:** Limit lift of pressers to minimum required for the work, as this permits higher speeds.




FIG. 6




FIG. 7

### Machines with Alternating Pressers

The lift of the vibrating and lifting pressers is controlled by an adjustable eccentric. To adjust, remove arm cover at rear of machine. Turn machine pulley over toward operator until feeding presser is down. Loosen the two lock screws, Fig. 7 and the two clamp screws. Insert screwdriver into notch of adjusting disc and turn machine pulley as indicated in Fig. 7. Then tighten the two clamp screws and the two lock screws.

When it is desirable to have either one of the pressers lift higher than the other, turn machine pulley over toward operator until the lifting presser is at its highest position. Loosen the two clamp screws, Fig. 8, and turn lifting rock shaft crank up or down until desired lift of each presser is attained. Then tighten the two clamp screws.

The vibrating presser should be timed so that under normal sewing conditions, the presser foot will seat on the material at approximately the same time the needle enters material. This timing can be advanced or retarded slightly depending on the type of operation being performed, such as sewing over seams. To adjust, loosen two holding screws, Fig. 8, not more than one half turn. Then turn the adjustable eccentric, Fig. 7, until the vibrating presser seats at the correct time. Securely tighten the two holding screws after adjustment is made.




FIG. 8






FIG. 9




FIG. 10




FIG. 11

## TO SET FEED BAR AT CORRECT HEIGHT

When the feed bar is set at the correct height the feed lift link clamp will be aligned with the rock shaft timing flat. To adjust, make certain that the feed lifting crank timing screw, Fig. 9, engages shaft spot correctly. Loosen clamp screw and move the feed lift clamp link to correct position. Then tighten clamp screw.

## CENTRALIZING FEED DOG

### Sidewise Setting

Needle should enter needle hole of feed dog with the same clearance between the needle and left or right side of hole. To adjust, loosen feed dog screws, Fig. 10. Move feed dog until correct clearance is attained. Hold in position and tighten feed dog screws.

Additional adjustment, if necessary, may be attained by loosening the four rock shaft collar set screws, the two rock shaft crank clamp screws, Fig. 10, and feed lifting clamp screw, Fig. 9. Move complete assembly to required position and tighten screws.

### Lengthwise Setting

The feed dog should clear the ends of the feed slots in the throat plate equally at both ends of feed travel. To adjust, set feed for desired stitch length. Loosen the two rock shaft crank clamp screws, Fig. 10. Move feed rocker forward or backward until correct positioning is attained. Then, tighten the two clamp screws.


## SETTING FEED DOG AT CORRECT HEIGHT

When the feed dog height is set correctly, approximately the full depth of the teeth will show above the throat plate. To adjust, loosen lock nuts, Fig. 11, and slightly loosen feed dog clamping screw. To raise feed dog, turn jack screw clockwise; to lower, turn jack screw counter-clockwise and tap feed dog down. When correct setting is attained, tighten the clamping screws and lock nuts.

### TIMING FEED LIFT ECCENTRIC

When the feed dog is at its highest position, the top of the teeth should be parallel with, and project full depth of teeth above upper surface of throat plate. To adjust, insert screwdriver in hole in feed strap and loosen the two set screws, Fig. 12. Move feed lift eccentric forward for earlier rise of feed dog, or backwards for later rise. Then, tighten the two set screws.

FIG. 12



### NEEDLE BAR POSITIONING

Needle should enter needle hole of feed dog toward the front, with approximately the same clearance between the front of the needle and the needle hole, as at the side. To adjust, press needle bar rock frame, Fig. 13, against drive arm and at the same time loosen the two driving arm clamp screws. Continue holding the rock frame against the drive arm, move needle bar to correct position and tighten the two clamp screws.




FIG. 13

### POSITIONING LOOP DEFLECTOR

When loop deflector, located on underside of feed dog, is positioned correctly there should be a clearance of approximately 1/32 inch between the right side of the needle and the loop deflector. To adjust, move looper out of sewing position and tilt machine back on its hinges. Loosen loop deflector screws, Fig. 14. Move deflectors toward rear of feed dog as far as the screw slots allow. Tighten slightly to allow for further adjustment. Return looper to sewing position and turn machine pulley until needle bar has descended to bottom of the needle bar stroke. Tap deflector to left or right until correct clearance is attained. Move looper out of sewing position and tighten loop deflector screws.




FIG. 14



## SETTING THE LOOPER AT CORRECT DISTANCE FROM NEEDLE

FIG. 15

LOOPER  
HOLDER

LOOPER  
HOLDER  
SCREW





FIG. 16

LOOPER  
SET  
SCREWS

1/16"



### Sidewise Setting

When the looper is correctly positioned, the point of the looper just clears the scarf of the needle on the forward stroke of the looper. To adjust, turn machine pulley until the looper point is directly opposite the center of the needle. Loosen looper holder screw, Fig. 15, and tap holder to left or right until correct clearance is attained. Then, securely tighten the looper holder screw.

Move looper to extreme forward position. Check clearance between heel of looper and loop deflector, Fig. 16, which should be approximately 1/16 inch. To adjust, loosen the two looper set screws. Turn looper to left or right until correct clearance is attained. Hold in position and securely tighten the two set screws.

LOOPER CARRIER  
CLAMP NUT




FIG. 17

NEEDLE BAR  
CLAMP SCREWS




FIG. 18

### Lengthwise Setting and Setting Height of Needle Bar

When correctly set, the point of the looper should be directly opposite the center of the needle and at the center of the clearance above the eye of the needle when the looper timing mark LT on machine pulley is opposite the timing arrow on the arm.

To adjust the looper, loosen looper carrier clamping nut, Fig. 17. Move carrier forward or backward until looper point is directly opposite center of needle. Then tighten clamping nut.

To adjust needle bar, first make certain that needle is inserted up into the needle bar or clamp as far as possible. Loosen the two needle bar clamping screws, Fig. 18, and raise or lower needle bar to correct position. Then, securely tighten the two clamping screws.


## TIMING LOOPER DRIVING CRANK

When the looper driving crank is properly timed, the point of the looper will pass above the eye of the needle at the same distance on both the forward and backward strokes of the looper.

To adjust when point of looper passes higher on forward stroke, loosen looper driving crank set screw, Fig. 19. Loosen looper crank timing screw (left) approximately 1/8 turn and tighten looper crank timing screw (right). Continue to adjust until correct adjustment is made. Then, securely tighten set screw.

When point of looper passes higher on backward stroke, reverse the adjustment by loosening timing screw (right) and tightening timing screw (left).


FIG. 19



## SETTING THE NEEDLE GUARD

When needle guard is properly set, it should pass as closely as possible to the needle without touching. To adjust, turn machine pulley over towards operator until the point of the looper is about to pass the needle on its forward stroke. At this point, the looper timing mark LT on the machine pulley should be approximately 1/8 inch above the arrow on machine arm. Loosen needle guard set screws, Fig. 20. Turn needle guard as close to the needle as possible without touching. Tighten set screws. Check by springing the needle to the left and turning the machine pulley to make certain that the looper points do not stroke the needle.

FIG. 20






FIG. 21

## POSITIONING SPREADER

### Sidewise and Height Setting

When looper on its forward stroke is passing spreader:

The point of the spreader should be exactly opposite top of thread groove at left side of looper.

The clearance between spreader point and looper should be approximately the double thickness of ordinary paper.

To adjust, loosen the two spreader holder set screws, Fig. 21. Move spreader and holder to correct position. Hold in position and tighten the set screws.




FIG. 22

## Lengthwise Setting

When the point of the needle on its downward stroke is even with the point of the spreader, the clearance between the two points should be approximately 1/16 inch. To adjust, loosen spreader screw, Fig. 22, and move spreader forward or backward to correct position. Then tighten spreader screw.




FIG. 23

## CHANGING MOVEMENT OF SPREADER

The sidewise movement of the spreader may be adjusted for sewing under abnormal conditions. Under normal conditions, maximum spreader movement is generally used. To adjust, tilt machine back on its hinges, loosen the two spreader driving eccentric screws, Fig. 23, and the two spreader driving eccentric flange screws. Move eccentric to left to increase movement, or to right to decrease movement. When correctly positioned, tighten the two spreader driving eccentric screws first, hold flange against strap and tighten flange screws. Then refer to preceding information regarding positioning of spreader.

**CAUTION:** When increasing sidewise movement, allow sufficient clearance between spreader driving rock shaft, Fig. 23, and left side of eccentric ball strap. They should not touch when eccentric ball stud is in its highest position.

## ADJUSTING NEEDLE THREAD TAKE-UP

The needle thread take-up and thread guide may be adjusted to increase or decrease the amount of thread drawn at the top of the needle bar stroke. To increase the amount, loosen thread take-up set screw, Fig. 24, and raise take-up or loosen guide screw and lower the guide. To decrease the amount, reverse the adjustment by lowering the take-up or raising the guide.

For average sewing conditions, the guide should be set with upper end 5/8 inch above the guide screw. The thread take-up should be set with the lower end 1/2 inch below the bottom of its holder.

## ADJUSTING NEEDLE THREAD TENSION RELEASER

When correctly adjusted, the tension releaser should release tension on the needle thread when the presser foot is raised and allow full adjusted tension when presser foot is down. To adjust, loosen set screw, Fig. 25, and move tension releaser cap out for earlier release of tension, or in for later release. Hold in position and tighten set screw. Should the tension releaser not release tension at the correct time after making the above adjustments, loosen the tension releaser plate screw and move plate sidewise to correct position. Then tighten screw.

## ADJUSTING LOOPER THREAD TAKE-UP

The looper thread take-up and guide may be adjusted for handling more or less thread, according to thickness of material and length of stitch, and to change the ratio of looper thread in the finished stitch.

To change the amount of thread handled, loosen looper thread guide screw, Fig. 26, and looper thread take-up rod screw. Move thread guide and take-up rod to the left for more thread or to the right for less thread. Tighten the two screws making certain that take-up rod passes through the center of the guide yoke.

To change ratio of looper thread in finished stitch, loosen thread guide screw, Fig. 26, and lower the yoke or right end of thread guide for more thread. For less thread, raise end of guide. Hold in position and tighten guide screw.




FIG. 24




FIG. 25




FIG. 26



## OPERATING INSTRUCTIONS

The Porter Tape Edge Machine is designed to bind the full circumference of the mattress.

The heavy duty sewing head sews without bobbins and without interruption. It makes what is known as a 401 chain stitch using two threads. Due to the special construction of the sewing head, it sews with the walking feet close to the end of the arm. The binding tape is always under compression and requires a minimum of effort from the operator.

The PNR Tape Edge is provided with either 7/8" or 1 1/4" binder.

A combination of the head tilt and the power adjustment of the table height permits the closing of mattresses and cushions from 1" up to 11 1/4".

The clutch handle, located to the left of the starting switch, engages the carriage to the table. When the handle is vertical, the carriage is not in gear and will not move forward when the power is turned on.

When the clutch handle is in the horizontal position the carriage is engaged to the table and will move forward when the power is turned on.

To lock the carriage tight in place, there is a plunger type locking device located just below the clutch handle.

The general operation of the PNR Tape Edge is such that the forward movement of the carriage and the sewing head is governed by a knee pressure control. To move the carriage forward, the knee pressure is slowly released. By using this knee control, the operator has both hands free to handle the mattress top pad and border.

Once the mattress has been made ready for final assembly, it is placed on the PNR Tape Edge table. The operator should now properly set the table height for the thickness of the mattress. The table height can be adjusted by simply pulling the cord located just underneath the table top. Pull the cord to the right to raise the table and to the left to lower it.

Before starting to sew, the operator needs to lock the presser foot in the upper (open) position so that the

mattress panel and quilted border can be pushed into the binder without difficulty. To release the presser foot from the upper (raised and locked) position, the operator needs only to push the lever with his elbow. This moves the presser foot down onto the material to be sewn. Again, the sewing head should be turned over by hand before sewing is to begin.

The operator should now move the clutch handle to the horizontal position to engage the carriage to the table. The operator will need to push the knee pad in before the power switch is turned on. This will prevent the carriage from traveling forward.

The operator can now withdraw the knee pressure gradually to move the carriage forward. If he needs to stop, he applies knee pressure on the pad to disengage the clutch.

The technique of a PNR Tape Edge operator is to handle the panel and the overedged border into the binder. When the material is well into the binder, the operator should be holding the panel and border several inches in front of the needle. As the sewing head travels toward the operator, his hands should continuously feed the panel and border into the binder. It is common that the inexperienced operator will stop the carriage every time he needs to move his hands. As experience is gained, longer stretches of tape will be sewn without stopping the machine. This experience will also help in making the corners.

In the PNR Tape Edge operation, the handling of the extra firm mattresses necessitate additional effort especially when the half way point is reached, because the mattress tightens up and is difficult to handle. At this point, it is essential for the operator to use the left elbow to draw the panel toward the needle to ease the pressure at the point of sewing. A combination of crawling fingers and the elbow technique aids in the non-stop sewing on the long seams.

The PNR Tape Edge is equipped with two motors. One is located at the bottom of the carriage to drive the carriage and the sewing head. The second is located under the table to raise and lower the table height depending upon the operator.



## **NOTICE TO OUR CUSTOMERS PRICES AND TERMS**

All prices are F.O.B. Beverly, MA, and are valid at the time of shipment.

All prices are list, unless otherwise noted.

Open account terms extended to firms with established credit.

All overseas orders must be paid before shipment.

### **TAXES**

Where the law requires, state sales and/or use taxes must be charged.

### **SHIPPING**

Please state how the shipment is to be made when ordering parts (UPS Red/Blue; Federal Express; Reg. UPS; air freight).

Freight charges are included in the invoice.

If a customer is on C.O.D. status, then shipping costs are included in the C.O.D. amount.

### **RETURNED GOODS**

Porter Sewing has incorporated a policy on returned parts that must be strictly adhered to.

1. All customers must call Porter to obtain a RMA (Returned Material Authorization) number. Parts returned without a RMA number will be returned to the customer.
2. All parts to be returned must be shipped to Porter prepaid unless otherwise instructed by the Porter Parts Department.
3. Credit for parts will be issued upon inspection by Porter and credited against the account. Credit memos are not sent.
4. A restocking charge of 15% will be issued on parts ordered incorrectly by the customer.

### **CLAIMS**

If a parcel post shipment reaches you in damaged condition, advise us immediately so that a claim can be filed. All parcel post packages are insured by Porter. If a truck, UPS or express shipment arrives damaged, request the driver to make a notation on the freight bill. If the damage was concealed at the time of delivery, call the carrier for an inspection and obtain a "DAMAGE REPORT". This is necessary in order to file a claim. In the case of truck lines, you must file the claim. We will give any needed assistance, but the carrier is responsible for the safe arrival of your goods.

### **MINIMUM ORDERS**

Due to the rising costs of handling orders, we have established a minimum order of \$25.00.

## **ORDERING INFORMATION**

Fax and Telex available 24 hours per day

To order by Fax: 1 (617) 599-70811

To order by phone : 1 800 343-8138

To order by Telex: 383818.

To order by mail: Porter Sewing Machines, Inc.  
97 Rantoul Street  
Beverly, MA 01915

### **NOTICE**

To assist us in handling your order, please have the following information ready when ordering:

1. Customer Number
2. Bill to and Ship to addresses
3. Fax Number
5. Person placing order
6. Machine Model Number
7. Part Number or complete part description.

# PORTER

DESIGNERS AND MANUFACTURERS OF SPECIALIZED INDUSTRIAL SEWING EQUIPMENT

PART #	DESCRIPTION	PAGE #	PART #	DESCRIPTION	PAGE #
1562J	NUT .....	30	200377	SCREW .....	28
2102	FLANGE .....	27	200378	SCREW FOR 268142 .....	24
2455	FLANGE .....	30	200380C	SCREW .....	24
10141	SPRING .....	30	200382C	SCREW .....	29
25362	BALL FOR 267718 .....	23	200386C	SET SCREW FOR COLLAR 268072 .....	24
32572	FLANGE .....	27	200394E	FEED LIFTING ECCENTRIC SET SCREW .....	29
32787	LIFTING CRANK .....	23	200403C	SCREW .....	31
50326	STUD .....	27	200416E	SCREW .....	30
51570	NUT .....	27	200417C	SCREW .....	25
54279	NEEDLE THREAD TENSION GUIDE DOUBLE .....	27	200507	SCREW .....	30
59537	BUSHING .....	27	200571D	SCREW .....	23
67425	LOOPER CARRIER CRANK WASHER .....	28	200573D	SCREW .....	29
131741	SPRING FOR NEEDLE THREAD TENSION .....	27	200578XC	SCREW .....	27
140321	SCREW FOR COLLAR # 167416 .....	28	200583X	SCREW .....	23
167416	COLLAR .....	28	200650X	SCREW .....	25
200004E	SCREW .....	30	200928	SHOULDER SCREW .....	26
200043C	SCREW FOR 267638 .....	25	200987	STUD .....	30
200047D	SCREW .....	24	201052	SCREW .....	27
200054C	LOOPER THREAD TUBE .....	27	201063D	HINGE PIN PINCH SCREW .....	24
200058C	SCREW FOR 267702 AND 267621 .....	24	201160E	SCREW EYE .....	26
200061D	SCREW FOR 32787 .....	23	201188C	SET SCREW FOR THREAD GUIDE .....	23
200061C	SCREW .....	29	201254C	SCREW .....	23
200064C	SCREW .....	29	201256C	SCREW .....	28
200064D	SCREW .....	31	201363C	SCREW .....	26
200066C	SCREW FOR 267629 .....	23	201409F	SCREW .....	23
200069C	SCREW FOR PNR-438 .....	23	201418C	SCREW .....	29
200078F	LOCKING SCREW FOR PNR-433A .....	23	201485C	SCREW .....	26
200078H	SCREW FOR 267604 .....	25	201522E	NUT .....	29
200081C	SCREW FOR 267629 .....	23	201524E	NUT .....	26
200082D	NEEDLE THREAD GUIDE SCREW .....	27	201526E	NUT .....	26
200089C	SCREW .....	28	201537	NUT .....	28
200095X	NEEDLE BAR CONN. LINK CAP WASH SCREW .....	23	201622	NUT .....	26
200098F	LOOPER THREAD TAKE-UP DRIVING CONN. SCREW .....	26	201736E	NUT .....	29
200100C	FEED DOG SCREW .....	28	202005	WASHER .....	30
200123D	CONNECTION CAP SCREW .....	29	204348	SPRING .....	26
200125F	SCREW FOR PNR-482 .....	23	204365	SPRING .....	27
200167E	SCREW FOR 32787 AND 200167"E .....	23	204925	WASHER .....	29
200169B	SCREW .....	30	206133	WASHER .....	26
200173D	NEEDLE BAR OILING FELT HOLD. SCR. ....	23	208636	WASHER .....	28
200303H	LOOPER DRIVING CRANK OIL HOLE COVER SCREW .....	29	210805	WASHER .....	26
200342C	BALANCE WHEEL POSITION SCREW .....	24	224742	PIN .....	30
200337C	TOP SHAFT LOCK SET SCREW .....	25	225708	SPRING .....	30
200344C	SCREW .....	23	226206	RELEASING PIN .....	27
200346	SCREW FOR 268142 .....	24	238089	PLATE PIN .....	26
200347C	BALANCE WHEEL LOCK SCREW .....	24	240245	SPRING .....	30
200351C	LIFT. PRESS. BAR GUIDE ROD SET SCR. ....	23	241763	BALL .....	24
200354C	SCREW .....	24	259549	BINDER .....	30
200362C	SCREW .....	25	267110	BEARING .....	24
200364	SCREW .....	29	267600	ARM CASTING .....	26
200373C	SCREW .....	25	267603	ARM SHAFT ASSEMBLY .....	24

PART #	DESCRIPTION	PAGE #	PART #	DESCRIPTION	PAGE #
267609	CONNECTOR ASSY. INCLUDED 267608-271055 .....	24	268064	LIFTING ECCENTRIC .....	24
267610	FEED DRIVING ECCENTRIC .....	24	268065	ADJ. FLANGE/398834 ASSY. & 398805 ASSY. ....	25
267612	FOOT LIFTER CRANK .....	25	268066	ADJUSTING FLANGE SPRING .....	29
267617	LIFINTG ECC. CONNECTION HINGE PIN .....	23	268067	ADJUSTING FLANGE COLLAR .....	29
267618	LIFTING ECC. ADJUSTING DISC SPRING .....	24	268070	FEED DRIVING ROCK SHAFT .....	28
267619	CONNECTION FOR 267620 ASSEMBLY .....	24	268072	COLLAR REPLACED BY 167416 .....	24
267620	ASSEMBLY INCLUDING 268063 AND 267619 .....	24	268073	FEED DRIVING ROCK SHAFT CRANK .....	29
267621	LIFTING ECCENTRIC CONN. CRANK .....	24	268074	FEED DRIVING CONNECTION .....	29
267622	LIFTING ECCENTRIC FLANGE .....	24	268075	FEED LIFTING CRANK .....	28
267623	GIB FOR 398834 ASSY. & 398805 ASSY. ....	24	268078	FEED LIFTING LINK .....	28
267624	LIFTING ECCENTRIC SPACING COLLAR .....	24	268079	FEED LIFTING LINK HINGE PIN .....	28
267625	LIFTING LEVER .....	23	268080	FEED LIFTING ROCK SHAFT .....	28
267626	LIFTING LEVER LINK STUD .....	23	268081	FEED REGULATING STUD .....	30
267627	LIFTING LEVER LINK .....	23	268082	FEED REGULATING STUD SOCKET .....	30
267628	LIFTING PRESSER BAR .....	23	268102	LOOPER DRIVING CRANK OIL HOLE COVER .....	29
267629	LIFTING PRESSER BAR GUIDE BLOCK .....	23	268121	NEEDLE THREAD TENS. BRKT. SPRING COLLAR .....	27
267630	LIFTING PRESSER BAR GUIDE ROD .....	23	268123	LOOPER THREAD TUBE .....	27
267631	LIFTING PRESSER BAR LIFTING CRANK .....	23	268124	LOOPER THREAD TUBE CLAMP .....	27
267633	LIFTING ROCK SHAFT FOR 267634 ASSY. ....	25	268139	NEEDLE BAR CONN. LINK CAP WASHER .....	23
267634	LIFTING ROCK SHAFT 267633 W/2022,267636 .....	25	268142	NEEDLE BAR CRANK .....	24
267636	LIFTING ROCK SHAFT AS PART OF 267634 .....	25	268144	NEEDLE BAR OILING FELT .....	23
267638	NEEDLE BAR ROCK FRAME DRIVING ARM .....	25	268150	NEEDLE BAR ROCK FR. REG. STUD .....	25
267639	NEEDLE BAR ROCK FR. DRIV. ECC. FLANGE .....	24	268162	SPREADER POINT .....	31
267650	PRESS. BAR SPRING HOUSING SUPP. RET. ....	26	268167	NEEDLE THREAD TENSION BRACKET .....	27
267657	VIBRATING PRESSER BAR .....	23	268168	NEEDLE THREAD TENSION RELEASE .....	27
267658	VIBRATING PRESSER BAR HINGE STUD .....	23	268169	NEEDLE THREAD TENSION RELEASE CAP .....	27
267665	LOOP DEFLECTOR FOR 267664 FEED DOG .....	28	268185	SPREADER HOLDER .....	31
267673	NEEDLE BAR ROCK FRAME .....	23	268187	SPREADER DRIVING CRANK .....	31
267702	FOOT LIFTER ARM .....	25	268190	SPREADER DRIVING PIN .....	31
267704	FOOT LIFTER LEVER ROD .....	26	268197	FACE PLATE LOCK SPRING PLATE .....	23
267707	NEEDLE THREAD TENS. REL. PLATE ADJ. ....	26	268198	FEED LIFTING ROCK SHAFT CRANK .....	29
267714	PRESSER BAR PRESSURE CYLINDER SUPPORT .....	26	268208	LOOPER CARRIER CRANK HINGE PIN .....	28
267718	PRESSER BAR SPRING ARM .....	23	268214	ARM SHAFT OIL STOP BALL .....	29
267738	LEVER .....	26	268216	LOOPER DRIVING CONNECTION ASSEMBLER .....	28
268004	ARM SHAFT BALL BEARING BACK HOUSING .....	24	268219	NEEDLE BAR ROCK FRAME THREAD GUIDE .....	23
268005	ARM SHAFT BALL BEARING FRONT .....	24	268220	THRUST WASHER .....	29
268008	FLANGE FOR TOP SHAFT .....	24	268233	SPREADER DRIVING CONNECTOR .....	29
268029	NEEDLE BEARING .....	23	268265	BED SHAFT OIL CONTROL ROD (WOOD) .....	29
268032	FACE PLATE LOCK SPRING .....	23	268277	LOOPER DRIVING CRANK .....	29
268044	ARM SHAFT OIL STOP BALL SPRING (REAR) .....	29			
268045	SPREADER DRIVING ECCENTRIC .....	29			
268046	SPREADER DRIVING ECC. COUNTER BALANCE .....	29			
268047	FEED LIFTING ECCENTRIC .....	29			
268048	BALANCE WHEEL .....	24			
268049	ASSY. INCLUDING 268048,200-347-200342 .....	24			
268051	LOOPER THREAD GUIDE .....	30			
268052	LOOPER THREAD TAKE-UP ROD .....	31			
268053	SPREADER DRIVING ROCK SHAFT .....	31			
268061	PULLER FEED DRIVING CONNECTION .....	29			
268062	PIN .....	25			
268063	BEARING FOR 267619 ASSY. 267620 .....	24			

PART #	DESCRIPTION	PAGE #	PART #	DESCRIPTION	PAGE #
268278	NEEDLE BAR CEILING FELT HOLDER .....	23	PNR-849	CASTER ARM-RIGHT .....	33
268307	LOOPER CARRIER CRANK .....	28	PNR 30	CENTER PIVOT ROLLER, STEEL .....	33
268308	LOOPER CARRIER CRANK CLAMP STUD .....	28	PNR-32	SLEEVE, STEEL .....	33
268310	NEEDLE GUIDE .....	28	PNR-33	WASHER, STEEL .....	33
268312	NEEDLE THREAD GUIDE (ON ARM HEAD) .....	27	PNR-34	HEAD TILT BASE,STEEL .....	34
268315	FEED DRIVING FLANGE WITH ACCESSORIES .....	29	PNR-35	HEAD TILT PIVOT SHAFT, STEEL .....	36
268330	STUD FOR FACE PLATE PNR-411 .....	23	PNR-38A	HEAD TILT SCREW SHAFT, STEEL .....	34
268331	PLATE .....	30	PNR-39A	HEAD TILT NUT, BRONZE .....	34
268333	FRAME GUIDE .....	30	PNR-40	HEAD TILT ARM, STEEL .....	34
268369	LOOPER ASSEMBLY .....	30	PNR-41	HEAD TILT LINK, STEEL .....	34
268370	LOOPER .....	30	PNR-42	HEAD TILT CRANK, BRASS .....	34
268373	THREAD GUIDE .....	30	PNR-45	HEAD TILT PAD, STEEL .....	34
268506	THREAD GUIDE FOR TOP ARM .....	27	PNR-46	HEAD BELT ADJUSTER ARM, STEEL .....	37
268512	THREAD GUIDE (ON NEEDLE BAR STUD) .....	23	PNR-47	HEAD BELT ADJ. SPRING, STEEL WIRE .....	37
268513	THREAD GUIDE .....	27	PNR-170	KNEE PLUNGER ROD, STEEL .....	37
270026	FEED REGULATING STUD SPRING .....	30	PNR-49	BRAKE ARM BRACKET, STEEL .....	37
270266	BEARING FOR PNR-439 .....	23	PNR-50	BRAKE ROD,STEEL .....	36
271055	BEARING FOR 267609 .....	24	PNR-51	BRAKE DISC. SPRING, STEEL WIRE .....	36
350149C	SPREADER SCREW .....	31	PNR-52	BRAKE DISC, BRAKE LINING .....	36
350171C	SET SCREW .....	24	PNR-171	CLUTCH ARM, STEEL .....	34
350267E	LOOPER HOLDER SCREW .....	28	PNR-172	GEAR LOCK PIN HOUSING .....	36
350466C	SPREADER DRIVING ROCK SHAFT SCREW STUD .....	29	PNR-173	CLEVIS ADJUSTING ROD .....	37
350467AL	SCREW FOR 398834 & 398805 .....	24	PNR-174	COVER PLATE (SINGLE PHASE ONLY) .....	36
350477C	SCREW FOR 398834 & 398805 .....	24	PNR-58	KNEE CONTROL SPRING, STEEL WIRE .....	37
350478C	SCREW .....	28	PNR-59	FLANGETTE STAMPING, STEEL .....	37
350524X	FOOT LIFTER LEVER ROD HINGE SCREW .....	26	PNR-60	LEADING & TRAILING CAM ROLLER, STEEL .....	36
350548C	SCREW FOR GIB FOR 398834 ASSY.& 398805 ASSY. ....	24	PNR-61	LEADING ROLLER STUD, STEEL .....	36
350552	SCREW .....	28	PNR-64	CORNER CAM, STEEL .....	40
398805	ASSEMBLY .....	29	PNR-65	ROLLER-CASTER .....	33
398817	ASSEMBLY CRANK FOR LOOPER .....	29	PNR-66	BRACKET-RIGHT GUIDE ROLLER .....	33
398834	ASSEMBLY (TOP SHAFT) .....	24	PNR-67	BRACKET- LEFT GUIDE ROLLER .....	33
			PNR-68	SPACER-GUIDE ROLLER BRACKET .....	33
			PNR-69-R	ASSY.(BEARING FOR PNR-65& CASTER ROLLER .....	33
			PNR-69-L	ASSY. (RET. RING FOR PNR66) .....	33
			PNR-70	CAP-GEAR BOX .....	32
			PNR-71	GASKET-GEAR BOX CAP .....	32
			PNR-73	GASKET-LARGE CAP .....	32
			PNR-75	PIPE LUG-VENTED .....	32
			PNR-77	SPACER-CAM .....	40
			PNR-83	TABLE END GEAR RACK, STEEL .....	40
			PNR-84	TABLE SIDE GEAR RACK, STEEL .....	41
			PNR-85	CORNER GEAR SEGMENTS,STEEL .....	41
			PNR-86	MAIN DRIVE GEAR, STEEL .....	37
			PNR-88	LOWER ROLLER STUD,STEEL .....	36
			PNR-89	LOWER ROLLER STEEL .....	36
			PNR-90	CLUTCH RELEASE ARM, STEEL .....	37
			PNR-91	CLUTCH RELEASE STUD, STEEL .....	37
			PNR-333	LEFT DEAD BELT IDLER SHEAVE .....	36
			PNR-95	GEAR LOCK PIN, STEEL .....	36
<b>PNR PART</b>					
PNR-1	MAIN DRIVE ASSEMBLY .....	37			
PNR-2	MAIN FRAME STEEL WELDMENT .....	35			
PNR-3	GEAR BOX, CASTING .....	32			
PNR-4	WORM DRIVE SHAFT, STEEL .....	32			
PNR-5	CLUTCH RING, STEEL .....	32			
PNR-9	DRIVE SHAFT WORM, STEEL .....	32			
PNR-10	GEAR BOX VERTICAL BEARING,STEEL .....	32			
PNR-12	SEW. DRIVE SHEAVE (GROOVE PULLEY) CAST. ....	37			
PNR-14	V-BELT CLUTCH, STEEL .....	37			
PNR-15	HEAD-DRIVE V-BELT, RUBBER .....	36			
PNR-18	GEAR BOX COVER PLATE, CASTING .....	32			
PNR-20	DRIVEN ADJ. SHEAVE (PULLEY) CASTING .....	37			
PNR-22	VERTICAL SHAFT, STEEL .....	37			
PNR-23	VERTICAL SHAFT,SLEEVE(BUSHING) BRONZE .....	32			
PNR-24	MAIN DRIVE WORM GEAR CASTING .....	32			
PNR-25	FEED CLUTCH SPRING, STEEL WIRE, 3"X1" .....	37			
PNR-27	CENTER PIVOT BRACKET, CASTING .....	33			
PNR-848	CASTER ARM-LEFT .....	33			

## PNR PART

PART #	DESCRIPTION	PAGE #
PNR-849	CASTER ARM-RIGHT .....	33
PNR 30	CENTER PIVOT ROLLER, STEEL .....	33
PNR-32	SLEEVE, STEEL .....	33
PNR-33	WASHER, STEEL .....	33
PNR-34	HEAD TILT BASE,STEEL .....	34
PNR-35	HEAD TILT PIVOT SHAFT, STEEL .....	36
PNR-38A	HEAD TILT SCREW SHAFT, STEEL .....	34
PNR-39A	HEAD TILT NUT, BRONZE .....	34
PNR-40	HEAD TILT ARM, STEEL .....	34
PNR-41	HEAD TILT LINK, STEEL .....	34
PNR-42	HEAD TILT CRANK, BRASS .....	34
PNR-45	HEAD TILT PAD, STEEL .....	34
PNR-46	HEAD BELT ADJUSTER ARM, STEEL .....	37
PNR-47	HEAD BELT ADJ. SPRING, STEEL WIRE .....	37
PNR-170	KNEE PLUNGER ROD, STEEL .....	37
PNR-49	BRAKE ARM BRACKET, STEEL .....	37
PNR-50	BRAKE ROD,STEEL .....	36
PNR-51	BRAKE DISC. SPRING, STEEL WIRE .....	36
PNR-52	BRAKE DISC, BRAKE LINING .....	36
PNR-171	CLUTCH ARM, STEEL .....	34
PNR-172	GEAR LOCK PIN HOUSING .....	36
PNR-173	CLEVIS ADJUSTING ROD .....	37
PNR-174	COVER PLATE (SINGLE PHASE ONLY) .....	36
PNR-58	KNEE CONTROL SPRING, STEEL WIRE .....	37
PNR-59	FLANGETTE STAMPING, STEEL .....	37
PNR-60	LEADING & TRAILING CAM ROLLER, STEEL .....	36
PNR-61	LEADING ROLLER STUD, STEEL .....	36
PNR-64	CORNER CAM, STEEL .....	40
PNR-65	ROLLER-CASTER .....	33
PNR-66	BRACKET-RIGHT GUIDE ROLLER .....	33
PNR-67	BRACKET- LEFT GUIDE ROLLER .....	33
PNR-68	SPACER-GUIDE ROLLER BRACKET .....	33
PNR-69-R	ASSY.(BEARING FOR PNR-65& CASTER ROLLER .....	33
PNR-69-L	ASSY. (RET. RING FOR PNR66) .....	33
PNR-70	CAP-GEAR BOX .....	32
PNR-71	GASKET-GEAR BOX CAP .....	32
PNR-73	GASKET-LARGE CAP .....	32
PNR-75	PIPE LUG-VENTED .....	32
PNR-77	SPACER-CAM .....	40
PNR-83	TABLE END GEAR RACK, STEEL .....	40
PNR-84	TABLE SIDE GEAR RACK, STEEL .....	41
PNR-85	CORNER GEAR SEGMENTS,STEEL .....	41
PNR-86	MAIN DRIVE GEAR, STEEL .....	37
PNR-88	LOWER ROLLER STUD,STEEL .....	36
PNR-89	LOWER ROLLER STEEL .....	36
PNR-90	CLUTCH RELEASE ARM, STEEL .....	37
PNR-91	CLUTCH RELEASE STUD, STEEL .....	37
PNR-333	LEFT DEAD BELT IDLER SHEAVE .....	36
PNR-95	GEAR LOCK PIN, STEEL .....	36



PART #	DESCRIPTION	PAGE #	PART #	DESCRIPTION	PAGE #
PNR-96A	CLUTCH ECCENTRIC, STEEL .....	37	PNR-338	WIRE	
PNR-97	ECCENTRIC SLEEVE, STEEL .....	37	PNR-339	WIRE	
PNR-98	MOTOR PIVOT BASE, STEEL .....	37	PNR-340	WIRING DIAGRAM (TABLE-1 PHASE)	
PNR-99	TOOL TRAY, STEEL WELDMENT .....	35	PNR-351	LEVER SWITCH SEGMENT .....	41
PNR-100	TAPE WEIGHT-STEEL		PNR-352	BRACKET - VERTICAL .....	40
PNR-101	MOTOR PIVOT SHAFT, STEEL .....	35	PNR-353	STUD .....	40
PNR-102	KNEE PAD PLATE, STEEL .....	35	PNR-354	BRACKET - ELEVATING MOTOR .....	40
PNR-104	KNEE PLATE PAD, DOUBLE SPONGE RUBBER .....	35	PNR-355	LIFTING LEVER HINGE STUD	
PNR-105	ROUND SIDE COVER, STEEL .....	34	PNR-356	CHAIN .....	40
PNR-106	THREAD SPOOL BRACKET, STEEL .....	34	PNR-372	WIRE	
PNR-107	RECTANGULAR REAR COVER, STEEL .....	35	PNR-392	HARNESS-TABLE WIRING-UNIVERSAL	
PNR-108	FULL REAR COVER, STEEL .....	35	PNR-393	WIRING DIAGRAM-TABLE-3 PHASE	
PNR-109	HEAD DR. SHEAVE (PULLEY) COVER, STEEL .....	34	PNR-394	SET SCREW	
PNR-375	HEAD DRIVE IDLER SHEAVE (PULLEY), ST. ....	37	PNR-396	BRACKET - SPECIAL - ADDIT. IDLER	
PNR-112	CLUTCH RELEASE ARM GUIDE SCREW, STEEL .....	37	PNR-401	SEWING MACHINE BED, ALUMINUM .....	28
PNR-115	WIRE SWITCH TO PNR-134 BLACK PLAST. CVR.		PNR-402	BED PLATE, LEFT, STEEL .....	30
PNR-116	WIRE (SWITCH TO #1309)		PNR-403	PRESS. FT. LIFT LEVER SCR., STEEL .....	27
PNR-117	WIRE (SWITCH TO MOTOR), BLK. PLASTIC CVR.		PNR-405	BED SHAFT, STEEL .....	29
PNR-120	MOTOR .....	36	PNR-406	BED SHAFT, OIL PLUG, STEEL .....	29
PNR-123	BRACKET SHIM .....	36	PNR-407	BED PLATE, RIGHT, STEEL .....	30
PNR-125	KEY, STEEL (PNR9 TO PNR-22) .....	37	PNR-408	HEAD SHEAVE (GROOVED PULLEY), STEEL .....	29
PNR-132	HEATERS		PNR-409	PLATE OILER ASSEMBLY .....	30
PNR-133	RECEPTACLE COVER PLATE, STEEL .....	34	PNR-410	COVER PLATE, STEEL .....	30
PNR-146	ELECTRICAL BOX (FOR PNR 149) .....	35	PNR-411	FACE PLATE, ALUMINUM .....	23
PNR-147	TRANSFORMER .....	35	PNR-412	FACE PLATE, PIN, STEEL .....	23
PNR-148	WIRE #1921A TO PNR14, & PNR147 TO #1309 .....	35	PNR-413	PRESSER FOOT, STEEL .....	23
PNR-149	TRANSFORMER (SPECIAL) .....	35	PNR-414	SIDE BED COVER, STEEL .....	30
PNR-156	EXT.-TAPE REEL PIN, COPPER TUBING LAMP .....	30	PNR-415	THREAD GUARD, STEEL .....	30
PNR-157	HINGE PIN .....	33	PNR-416	GASKET, VELLUMOID .....	30
PNR-163	DECAL) .....	35	PNR-417	BINDER PIVOT STUD STEEL .....	30
PNR-164	LAMP .....	26	PNR-418	LOOPER ROCKER SHAFT BUSHING-STEEL .....	28
PNR-165	SLEEVE WORM SPACER .....	32	PNR-419	LOOPER ROCKER SHAFT, STEEL .....	28
PNR-166	SLEEVE WORM SPACER-SHEAVE SIDE .....	32	PNR-420	SPREADER BAR, STEEL .....	31
PNR-167	CAP GEAR BOX, LARGE .....	32	PNR-421	FEED DOG, STEEL .....	28
PNR-168	NUT WORM SHAFT .....	32	PNR-423	FEED DOG ADAPTER, STEEL .....	28
PNR-300	TAPE ASSEMBLY .....	41	PNR-424	THROAT PLATE, STEEL .....	30
PNR-301	LEG, STEEL (W/PNR-301 SUB.1-5) .....	41	PNR-425	PRESSER FOOT LIFTING ROD STEEL .....	26
PNR-846	RAIL WELDMENT ASSY. , STEEL .....	41	PNR-426	PRESSER FOOT LIFTING LEVER, STEEL .....	27
PNR-303	BUSHING, BRONZE (FOR PNR-311) .....	41	PNR-427	LIFT. LEVER LATCH PLATE, STEEL .....	27
PNR-847	RACK AND RAIL ASSEMBLY (SUB.) .....	41	PNR-428	LOOPER CARRIER, STEEL .....	28
PNR-306	LOWER SIDE RAIL, STEEL .....	41	PNR-429	COLLAR .....	28
PNR-307	LOWER END RAIL, STEEL .....	40	PNR-430	THREAD GUIDE, STEEL .....	30
PNR-308	REVERSING SWITCH SASH CORD, 20 FT. LONG .....	41	PNR-431	OILWICK ASSEMBLY, YARN .....	27
PNR-310	ELEVATING LIMIT SWITCH TRIP, STEEL .....	40	PNR-432	FEED DOG LIFTING SHANK, STEEL .....	28
PNR-311	ELEVATING SCREW, STEEL .....	41	PNR-433	VIBRATING PRESSER FOOT, STEEL .....	23
PNR-312	ELEVATING SPROCKET, STEEL .....	41			
PNR-313	ELEVATING SPROCKET, RETAINING, STEEL .....	41			
PNR-315	TABLE ELEVATING DR. SPROCKET (ON MOTOR) .....	41			
PNR-316	MOTOR REDUCTION UNIT .....	40			
PNR-318	ELEVATING LIMIT SWITCH BRKT., STEEL .....	41			
PNR-322	BRACKET-ELEVATING LIMIT SWITCH .....	40			
PNR-331	WIRE, #1 TERM, TO #3 TERM				



# PORTER

DESIGNERS AND MANUFACTURERS OF SPECIALIZED INDUSTRIAL SEWING EQUIPMENT

PART #	DESCRIPTION	PAGE #	PART #	DESCRIPTION	PAGE #
PNR-434	FEED DOG LIFTING MOTION SHAFT, STEEL .....	28	PNR-601	ELEVATING SCREW TOP PLATE, STEEL .....	39
PNR-438	NEEDLE BAR CONN. STUD, STEEL .....	23	PNR-S-259552	.....TAPE BINDER ONLY 9/16"	
PNR-439	NEEDLE BAR CONNECTING LINK, STEEL .....	23	PAT-29	WHEEL SPACER, STEEL (FOR SHEAVE #7151) .....	39
PNR-440	LOOPER HOLDER, STEEL .....	28	PBM-186	PLATE MODEL AND MACHINE NO. ....	25
PNR-441	SIDE COVER BED SPACER .....	30	PBM-187	PLATE - MODEL AND MAHINE NO. ....	34
PNR-442	SCREW, STEEL .....	23	PBM-430	THREAD SPOOL HOLDERS, STEEL .....	34
PNR-443	LONG SHAFT COLLAR, STEEL .....	28	PBEE-197	FOOT, STEEL (FOR PNR-301) .....	39
PNR-444	SPREADER BAR BEARING, STEEL .....	31	PD-6	THRUST BEARING (FOR PNR-38) .....	34
PNR-445	FELT OILER .....	31	PD-650	COMPLETE SWIVEL (BANJO) ASSY. 4 WIRE	
PNR-446	SPRING SPREADER BAR OILER RETAINER .....	31	PDBM-337	KEY, STEEL (PNR-9 TO PNR-4) .....	32
PNR-447	CONNECTING BELT PULLEY,STEEL .....	29	PDBM-338	KEY STEEL (MAIN SHAFT TO PNR-22) .....	37
PNR-448	SMALL NEEDLE, FOR PLASTICS .....	23	PN-9	FEED CLUTCH, STEEL .....	37
PNR-449	SWING PLATE FOR 1 7/16" BINDER .....	44	PN-2-B	NUT - TENSION LOCK	
PNR-450	BINDER 1 3/8" TAPE ONLY .....	44	PN-691	CLUTCH RELEASE HANDLE, BRASS .....	35
PNR-450	BINDER 1 1/4, 1 7/16" TAPE ONLY .....	44	PN-740	TAPE REEL, STEEL .....	30
PNR-451	SET SCREW, STEEL .....	28	PNR-465R	PIPING ATTACHMENT ASSEMBLY	
PNR-457	PIPING SUPPORT .....	44	PNR-465A-R	PIPING GUIDE ASSEMBLY	
PNR-458	PIPING GUIDE RING BRACKET, STEEL		PNR-720-S	TABLE EXTENSION ASSEMBLY	
PNR-459	PIPING REEL HOLDER BRACKET, STEEL		PUTS-1-T	UNDER TABLE SWIVEL (FACTORY ASSEMBLY)	
PNR-460	PIPING REEL HOLDER BRACKET, STEEL, STUD		PNR717-R	QUICK REVERSE 1 1 ASSY. (FACTORY ASSY.)	
PNR-461	PIPING REEL HOLDE		259553-5/8	WIDE MOUTH BINDER	
PNR-466	FEED DRIVING ROCK FRAME, STEEL .....	28	259553-9/16	WIDE MOUTH BINDER	
PNR-467	FEED BAR, STEEL .....	28	259553-7/8	WIDE MOUTH BINDER	
PNR-468	FEED BAR HINGE PIN COLLAR, STEEL .....	28	250549-5/8	NARROW MOUTH BINDER	
PNR-469	SPREADER, STEEL .....	31	250549-9/16	NARROW MOUTH BINDER	
PNR-470	STANDARD NEEDLE, FOR REGULAR WORK .....	23	250549-7/8	NARROW MOUTH BINDER	
PNR-474	BODY - TAPE TENSION		97-23253	OIL CAN	
PNR-475	PLATE - TAPE TENSION				
PNR-476	FIELD ASSEMBLY				
PNR-478	PIPING GUIDE BASE PLATE				
PNR-480	PIPING GUIDE				
PNR-481	BEARING .....	29			
PNR-482	NEEDLE BAR, STEEL .....	23			
PNR-484	THREAD GUIDE .....	24			
PNR-485	BINDER SWING PLATE STOP .....	30			
PNR-486	FOOT LIFTER LEVER .....	26			
PNR-488	ASSEMBLY - THROAT PLATE				
PNR-489	BINDER ASSEMBLY 1 3/4" RUCHING				
PNR-490	GUIDE - 1 3/4" RUCHING				
PNR-491	PULLEY - ARM SHAFT TIMING PULLEY .....	24			
PNR-492	FLANGE-TIMING PULLEY (PART OF PNR-491)				
PNR-493	PULLEY-ARM SHAFT-TIMING (PNR-491N)				
PNR-494	BELT-ARM SHAFT-TIMING ASSEMBLY				
PNR-496	ASSY., BINDER HEAD & TAPE TENS. ON BRKT. ....	30			
PNR-499	COVER SCREWS .....	30			
PNR-501	SCREW .....	30			
PNR-502	PRESSER BAR SPRING ARM FULCRUM .....	25			
PNR-505	ASSY.-PRESSER BAR PRESSURE CONTROL .....	26			
PNR-506	ADAPTOR FOR PNR-505 .....	26			
PNR-520	ALTERNATE GEAR BOX				
PNR-521	ALTERNATE SWIVEL				
PNR-600	TABLE TOP, STEEL (INCL. SUB 1-8) .....	39			


## STANDARD PARTS

23308	SCREW DRIVER
4803	WRENCH FOR#3&#4 HEX. SOC. SET. SCREWS
66	SCREW
101	SCREW, STEEL
102	LOCKWASHER
105	WASHER, STEEL
106	NUT
107	WASHER
108	WASHER, SPEC., STEEL (FOR JOINT #1658)
109	NUT, STEEL
110	SCREW, STEEL
113	SCREW, STEEL
115	NUT, STEEL
116	LOCKWASHER, STEEL
117	WASHER, STEEL, SPECIAL (FOR PNR-97)
119	WASHER,STEEL,SPEC. (PNR-40 TO PNR-2-T)
120	LOCKWASHER, STEEL
129	COTTER PIN, STEEL
138	SCREW
148	NUT

PART #	DESCRIPTION	PAGE #	PART #	DESCRIPTION	PAGE #
160	SCREW,STEEL		1309	FLUSH BASE-FEMALE	
164	COMPRESSION ELBOW		1318	OIL GAUGE	
172	SCREW		1360	NIPPLE, STEEL (UTILITY BOX TO MOTOR)	
174	NUT, STEEL		1367	OIL CUP	
177	SCREW, STEEL		1542	RETAINING RING, STEEL	
181	WASHER, STEEL, SPECIAL		1630	RETAINING RING, STEEL	
193	LOCKWASHER, STEEL		1632	LOCKWASHER, STEEL, SPECIAL	
198	KEY, STEEL		1633	SCREW, STEEL	
199	SCREW		1634	BUSHING, BRONZE	
214	SCREW		1635	COLLAR, STEEL	
229	BOLT		1636	SCREW, STEEL	
234	WASHER,ST.-SPEC. (FOR PNR-89)		1637	SCREW, STEEL	
238	LOCKWASHER, STEEL		1638	SCREW, STEEL	
261	SCREW, STEEL		1640	SCREW, STEEL	
262	PIPE PLUG, STEEL		1641	SET SCREW, STEEL	
268	SCREW, STEEL		1642	SET SCREW, STEEL	
270	NUT, STEEL		1643	LOCKWASHER, STEEL, SPECIAL	
282	NUT, STEEL		1645	PIN, STEEL	
302	SCREW		1647	RIVET, STEEL	
319	NUT, STEEL		1648	BALL JOINT W/ MALE AND FEM. ENDS	
331	NUT, STEEL		1650	NEEDLE BEARING, STEEL	
350	SCREW, STEEL		1651	SCREW, STEEL	
353	SCREW		1655	THUMB SCREW, STEEL	
356	SET SCREW, STEEL		1661	MICRO SW., SINGLE PH./TABLE PNR-318N	
364	SCREW		1665	SCREW	
367	WASHER		1685	CONDUIT	
368	SCREW, STEEL		1687	SET SCREW	
416	SCREW, STEEL		1688	SET SCREW	
418	SCREW		1711	SCREW	
428	PIPE PLUG		1720	FLUSH BASE, MALE	
446	SCREW, STEEL		1721	REVERSING SWITCH	
494	SCREW, STEEL		1722	COVER, UTILITY BOX	
500	SCREW, STEEL		1723	CONNECTOR BODY, FEMALE (4 WIRE)	
522	SCREW		1725	UTILITY BOX	
525	SCREW		1743	WIRE CAP	
645	TAPER PIN		1752	NUT FOR WIRE CONNECTOR	
648	LOCK WASHER		1773	WIRE CAP	
694	SCREW, STEEL		1854	BEARING	
705	SCREW, STEEL		1909	CONNECTOR	
746	SCREW, STEEL		1911	SCREW	
749	SCREW, STEEL		1921A	SWITCH	
751	SCREW, STEEL		1922	TRANSFORMER	
760	SCREW, STEEL		1959	REDUCER	
771	SCREW, STEEL		1992	SWITCH ENCLOSURE	
813	WASHER, STEEL		1994	KNOB (PLASTIC)	
815	LOCKWASHER, STEEL		2036	BEARING FOR CASTER ROLLER	
877	SCREW, STEEL		2076	CONNECTING LINK	
1028	FLEXIBLE CONDUIT (BOX TO BOX)		2084	LAMP	
1028	FLEXIBLE CONDUIT (SWITCH BOX TO MOTOR)		2126	ROMEX CONNECTOR	
1132	STEEL CONNECTOR		2127	CONNECTOR	
1153	VERT. SHAFT UPPER BEARING W/ COLLAR		2306	SCREW, STEEL	
1307	MALE CAP WITH CORD GRIP		2438	PIPE PLUG (VENT)	




PART #	DESCRIPTION	PAGE #	PART #	DESCRIPTION	PAGE #
1073	SCREW		115	NUT	
1774	SCREW		116	LOCKWASHER	
1841	SCREW		119	WASHER	
1990	ROLL PIN		120	LOCKWASHER	
2171	MACHINE SCREW		151	BOLT	
6067	NUT		232	BOLT (UTS21 TO UTS11)	
6219	SCREW - TAPE TENSION ADJUSTING		273	BOLT	
7230	SCREW		282	NUT	
PN-21B	NUT TAPE TENS. LOCK (COTTON TUFTER PT.)		287	BOLT	
PSM-163A	SPRING - TAPE TENSION		301	SCREW (BRG. TO UTS 2 COLUMN)	
<b>UNDER TABLE SWIVEL</b>			372	NUT	
PUTS 2	ELEVATOR - UNDER TABLE SWIVEL		393	BOLT	
PUTS 3	SUPPORT - TABLE TOP		500	SCREW	
PUTS 4	ELEVATING SCREW		522	SCREW	
PUTS 5	ELEVATING NUT		691	BOLT	
PUTS 6	SPROCKET - ELEVATING SCREW		815	LOCKWASHER	
PUTS 11	BRUSH BLOCK		1027	CONNECTOR	
PUTS 12	BRUSH ASSEMBLY		1028	CONDUIT	
PUTS 13	BRUSH		1058	ARM SLIP RING CLOSURE/44 1/2 WIDE TABLE	
PUTS 14	BRUSH CAP		1132	CONNECTOR W/NUT, FLEXIBLE	
PUTS 15	BRUSH HOLDER		1360	CHASE NIPPLE	
PUTS 16	INSULATING SHEET		1471	FITTING	
PUTS 17	SLIP RING		1661	MICROSWITCH	
PUTS 18	SPACER BUTTON		1685	FLEXIBLE CONDUIT	
PUTS 19	ELEVATOR INSULATOR		1686	90 CONNECTOR	
PUTS 20	SPRING - BRUSH HOLDER CONTACT		1689	UTILITY BOX	
PUTS 21	COVER - TOP & BOTTOM		1721	REVERSING SWITCH	
PUTS 22	ENCLOSURE - SLIP RING		1722	COVER	
PUTS 23	COVER - ENCLOSURE		1725	UTILITY BOX	
PUTS 24	FELT - COVER SEAL		1909	CONNECTOR	
PUTS 25	ROD - SLIP RING CLOSURE		1981	CONNECTOR	
PUTS 26	SLEEVE - BEARING SPACER		2558	TAPER PIN	
PUTS 27	STUD - SLIP RING CONTACT		2953	CORD SLIP RING CLOSURE SWIVEL	
PUTS 28	BRACKET - REVERSING SWITCH		3059	SCREW	
PUTS 29	EXTENSION - SWITCH SHAFT		3080	90 ELBOW	
PUTS 31	BRACKET - EXTENSION CORD		5702	BOLT (BRG. TO UTS 21 COVER)	
PUTS 32	BRACKET - EXTENSION CORD - SHORT		5857	ARM - SLIP RING CLOSURE	
PUTS 33	GUARD - EXTENSION CHAIN		6050	SET SCREW	
PUTS 35	TUBE - EXTENSION CORD		6076	LOCKWASHER	
PUTS 41	WIRE		6171	WASHER	
PUTS 42	WIRE		6360	NUT	
PUTS 43	WIRE		6427	SCREW	
PUTS 44	WIRE		6451	NUT	
PUTS 45	BRACKET - FLEXIBLE CONDUIT		6526	SET SCREW	
PUTS 46	WIRE		6574	SCREW	
PUTS 47	WIRE		6657	SCREW	
PUTS 48	WIRE		7019	LOCKNUT	
PUTS 49	WIRE		7024	CONNECTOR	
102	LOCKWASHER		7131	COVER	
106	NUT		7136	CONNECTOR W/ NUT	
			7221	SET SCREW	
			7485	BEARING	




FRONT ASSEMBLY SEWING ARM







## UPPER SHAFT ASSEMBLY







EXTERNAL PARTS SEWING ARM



# EXTERNAL PARTS SEWING ARM




EXTERNAL PARTS SEWING ARM




FRONT ASSEMBLY SEWING BED




# LOWER SHAFT ASSEMBLY







CROSS SHAFT IN SEWING BED



GEAR BOX ASSEMBLY

CASTER ASSEMBLY

PNR-849  
PNR-36  
PNR-65  
1542  
2036  
PNR-68  
1542  
PNR-66  
6360  
199  
1911  
7485  
6287  
PNR-30  
8668  
7283  
PNR-32  
PNR-67  
1911  
7485  
6287  
PNR-65  
2036  
PNR-68  
1542  
199  
6360  
PNR-848\*  
1542  
6287  
7172  
1854  
PNR-36  
PNR-27  
7177  
PNR-157  
6287  
7172  
1367  
5997  
PNR-33  
7100  
6139  
7100  
6139  
PNR-849  
1542  
PNR-65  
2036  
PNR-68  
1542  
PNR-66  
6360  
199  
1911  
7485  
6287  
PNR-30  
8668  
7283  
PNR-32  
PNR-67  
1911  
7485  
6287


\*PNR-848 & PNR-849 CASTER ARMS  
ARE INTERCHANGEABLE ONLY  
WITH PNR-36 SPACER

THIS PART USED ONLY ON  
MACHINE SERIAL NO. 1666  
& SUBSEQUENT.


\*PNR-848 & PNR-849 CASTER ARMS  
ARE INTERCHANGEABLE ONLY  
WITH PNR-36 SPACER

THIS PART USED ONLY ON  
MACHINE SERIAL NO. 1666  
& SUBSEQUENT.







MAIN DRIVE ASSEMBLY





# MAIN DRIVE ASSEMBLY



# MAIN DRIVE ASSEMBLY



# MAIN DRIVE ASSEMBLY





PNR-520

ALTERNATE GEARBOX FOR MAIN DRIVE ASSEMBLY




- 1 SLIP HEAD DRIVE BELT FROM PULLEY
- 2 RELEASE UPPER MOTOR ADJUSTING SCREW 1/2" APPROX.
- 3 TO CHANGE MACHINE TRAVEL SPEED — RELEASE SET SCREW  
IN HUB & OPEN (FASTER) OR CLOSE (SLOWER) TO DESIRED  
POSITION — RESET SCREW ON FLAT
- 4 WITH CLUTCH CLOSED (SEE NOTE) RESET 2 SCREWS READJUSTING  
TILT OF MOTOR FOR PROPER BELT TENSION




NOTE  
CLUTCH PULLEY IS COMPLETELY CLOSED  
WHEN ADJUSTING MOTOR SCREWS FOR  
BELT TENSION  
ROTATE CLUTCH BY HAND & PUSH TOWARD  
MOTOR TO CLOSE CLUTCH TO OPERATING POSITION

#### MACHINE TRAVERSE SPEED ADJUSTMENT






FOR 3 PH. APPLICATION & 115 D.C.

## DETAIL "A"




TABLE






SWIVEL ASSEMBLY




PNR 521

ALTERNATE SWIVEL ASSEMBLY




## LUBRICATION CHART



## SEWING HEAD DRIVE BELT PATH





PIPING ATTACHMENT









TABLE WIRING DIAGRAM



*110 Volts Single Phase*  
**MAIN DRIVE WIRING DIAGRAM**



**MAIN DRIVE WIRING DIAGRAM**



**MAIN DRIVE WIRING DIAGRAM**