





WX-8800-C MODEL PARTS



GAUGE PARTS



FRONT GUIDE



COVERSEAM GUIDE

WX-8800-C MODEL PARTS

REF#	ITEM#	DESCRIPTION	QTY
1	14-831	NEEDLE PLATE 2 NEEDLE 3/16	1
2	14-832	NEEDLE PLATE 2 NEEDLE 7/32	1
3	14-833	NEEDLE PLATE 2 NEEDLE 1/4	1
4	14-861	NEEDLE PLATE 3 NEEDLE 7/32	1
5	14-862	NEEDLE PLATE 3 NEEDLE 1/4	1
6	15-806	REAR FEED DOG 2 & 3 NEEDLE 3/16 & 7/32	1
7	15-808	REAR FEED DOG 2 & 3 NEEDLE 1/4	1
8	15-826	FRONT FEED DOG 2 & 3 NEEDLE 3/16 & 7/32	1
9	15-823	FRONT FEED DOG 2 & 3 NEEDLE 1/4	1
10	21-825	FRONT COVER	1
11	17-831-1	PERSSER FOOT 2 NEEDLE 3/16	1
12	17-832-1	PERSSER FOOT 2 NEEDLE 7/32	1
13	17-833-1	PERSSER FOOT 2 NEEDLE 1/4	1
14	17-861-1	PERSSER FOOT 3 NEEDLE 7/32	1
15	17-862-1	PERSSER FOOT 3 NEEDLE 1/4	1
16	84-382	SCREW	1
17	17-818-A	PERSSER FOOT SHANK	1
18	17-818-E	PERSSER FOOT SPRING RIGHT	1
19	17-818-D	PERSSER FOOT SPRING LEFT	1
20	17-818-F	PERSSER FOOT SHANK SPRING	1
21	84-101	SCREW	1
22	17-818-G	PERSSER FOOT SHANK PIN	1
23	17-818-B	PRESSER FOOT YIELDING	2
24	17-818-H	PRESSER FOOT GUIDE	1
25	26-830	FRONT GUIDE	1
26	75-455	WASHER	2
27	84-574	SCREW	2
28	26-824	COVERSEAM GUIDE BASE	1
29	26-826	COVERSEAM GUIDE LEFT	1
30	26-827	COVERSEAM GUIDE RIGHT	1
31	26-825	COVERSEAM GUIDE BASE SUPPORT	1
32	84-193	SCREW	1
33	84-167	SCREW	1
34	84-556	SCREW	2