



parts list

No.	Parts	No.	Parts	
1	Handle (Knob)	21	Movement indicator (set)	
2	Clip of Main spring	22	Movement indicator Plate	
3	Sleeve	23	Knock	
4	Main spring	24	Slider	
5	Base plate	25	Shaft	
6	Pad holder	Set = 6	26	Index
7	Pad lever		27	Index spring
8	Locking lever	28	Gear pole shaft	
9	Frame	Set = 9	29	Selector shaft
10	Front cover		30	Selector spring
11	Cam shaft	31	Pad holder clip (set)	
12	Cam spring	32	Clip	
13	Plunger assembly	33	Case	
14	Swing	34	Spring	
15	Main wheel shaft	35	Shaft	
16	Wheel (1st - 10th)	36	Pad (doz)	
17	Index gear (Dup 1.)	37	Base plate screw	
18	Index gear (Trip 1.)	38	Front cover screw	
19	Index gear (Quadr.)	39	E - ring	
20	Gear pole (set)			