

Part Number	Description	Pictures
COS0204	front cover	
COS0205	inside cover	
COS0203	pushing piece	
COS0206	bar for spring of pushing piece	
COS0207	spring of pushing piece	
COS0208	pin	
COS0210	right support	
COS0209	left support	

COS0211	screw for support	
COS0214	lock pin for staple feeder	
COS0215	spring for staple feeder	
COS0216	base mount	
COS0219	washer	
COS0220	fixed nut for handle	
COS0221	pusher	
COS0223	spring for pusher	

<p>COS020295</p>	<p>base for pushing piece</p>	
<p>COS021295NI</p>	<p>maganize base</p>	
<p>COS022495SP</p>	<p>base for pusher</p>	
<p>COS0225</p>	<p>e-ring</p>	
<p>COS0218</p>	<p>handle</p>	