

-Passing the needle reads.

Pass the needle thread according to the illustration.

① to ⑮ for the left needle.

Ⓐ to Ⓞ for the right needle.

