



Fig. 7

#### 4. Threading the machine

To pass the needle thread, follow the numerical order as shown in Fig. 8. Start from the needle thread guide pin ①, to the needle ⑨ in order. (Refer to Fig. 2 for complete view)

- ② Three-hole thread eyelet
- ③ Tension disc
- ④ Take-up spring
- ⑤ Thread take-up guide
- ⑥ Thread take-up
- ⑦ Frame thread guide, upper
- ⑧ Frame thread guide, lower
- ⑨ Needle

