


CONSEW

PARTS FOR MODEL 105



PART NO.	PART NAME	PART NO.	PART NAME	PART NO.	PART NAME
1	2110801 100 B ARM BED ASSEMBLY	60	9540903 241 SCREW FOR 59	121	2110605 141 FEED FORK
2	2110212 311 SPOOL PIN	61	2110203 230 B PRESSER BAR GUIDE BRACKET COMPLETE	122	2110305 311 D FEED REGULATOR FORK
3	2110619 319 NUT FOR 2 & 6	61A	2110203 231 B PRESSER BAR GUIDE BRACKET	123	2110305 302 FEED REGULATOR LINK COMPLETE
4	9540908 101 SCREW FOR 171	61B	9531102 256 SCREW FOR 61A	124	2110305 313 CAP SCREW FOR 123
5	2110401 204-B OIL CAP	62	9060100-009 THRUST WASHER FOR 61	125	9013300 005 JOINT SCREW FOR 123
6	2110602 312 THREAD GUIDE WITH THREE HOLES	63	2110202 316 B THREAD REGULATOR	126	9410152-204 NUT FOR 125 & 132
7	2110602 313 A THREAD GUIDE, RIGHT	64	9541104 256 SCREW FOR 63 & 69	127	2110806 251 A OIL TRAY, REAR
8	9540916 119 SCREW FOR 7	65	2110603 240 B PRESSER BAR LIFTER COMPLETE	129	2110806 375 FELT FOR 127
9	2120201-153 BED LEG, RIGHT	65A	2110203 241 F PRESSER BAR LIFTER	130	9540908 279 SCREW FOR 127
10	2120201-152 BED LEG, FRONT	65B	2110603 242 A KNEE LIFTER PLATE	131	2110806 256 A OIL WICK GUIDE
11	2110401 153 B BED LEG, REAR	65C	9015500 021 JOINT SCREW FOR 65B	132	9015500 036 A JOINT SCREW FOR 150
12	2120501-241 GUARD FOR TAKE UP LEVER	66	9080200 007 STOP RING FOR 65	133	2110305 320 A FULCRUM SHAFT COMPLETE FOR 122
13	9541108 259 SCREW FOR 13	67	2110203 411 B THREAD TENSION RELEASE	134	9060100 007 OIL SEAL, INNER FOR 133
14	2240101-181 BACK COVER PLATE	68	1210707 576 A SPRING FOR 67	135	9060100-005 OIL SEAL, OUTER FOR 133
15	9560904 307 SCREW FOR 15 & 35	69	2110213 412 ADJUST PLATE FOR TENSION RELEASE	136	2110105 325 SOFT PLUG FOR 133
16	9540904 101 SCREW FOR 38	70	2110203 413 A SHAFT FOR 67	137	2110605 330 A FEED REGULATOR ARM
17	2120201 234 OIL STOP PLUG	71	9500904 256 SET SCREW FOR 70	138	2110605 335 REGULATOR SHAFT
18	2110603 351 PRESSER BAR LIFTER LEVER	72	2110206 392 A OIL WICK RETAINER	139	9030400 001 WASHER FOR 142
19	9015500 049 HINGE SCREW FOR 19	73	2110806 311 OIL WICK	140	2110305 334 C FEED REGULATOR HAND LEVER
20	2110603 315 PRESSER BAR LIFTER CRANK ARM	74	2110404 111 B TOP SHAFT ONLY	141	9541217 107 CLAMP SCREW FOR 140
21	9541111 207 SCREW FOR 21	75	2110804 112 TOP SHAFT FRONT BUSHING	142	9541208 107 CAP SCREW FOR 140
22	2110603 255 KNEE LIFTER BELL CRANK, LEFT	76	2110804 113 TOP SHAFT CENTER BUSHING	143	2110605 338 A SPRING FOR 135
23	2210203 251 SHAFT FOR 23	77	2110404 271 PACKING FOR 107	144	9080200-001 STOP RING FOR 143
24	2110603 253 KNEE LIFTER ROD	78	2110804 114 TOP SHAFT REAR BUSHING	145	2110305 350 D FEED REGULATOR DIAL
25	9015500 047 JOINT SCREW FOR 25	79	2110406 364 OIL FELT FOR TOP SHAFT BUSHING	146	2110605 305 A FEED REGULATOR BUSHING COMPLETE
26	2110803 252 KNEE LIFTER BELL CRANK, RIGHT	80	2110106 384 C OIL PIPE	147	9541203 247 LOCK SCREW FOR 145
27	9015500 048 HINGE SCREW FOR 27	81	9015600 006 SET SCREW 75, 76, ETC	148	2110305 353 B STOP PIN FOR 145
28	2110603 313 KNEE LIFTER BELL CRANK, LINK	82	2120302 130 TAKE UP LEVER CRANK COMPLETE	149	2110105 354 A SPRING FOR 145
29	9015500 019-A HINGE SCREW FOR 29	83	2110604 151 HAND WHEEL	150	2110405 251 C FEED LIFTING SHAFT
30	2110603 321 KNEE LIFTER PULL ROD	84	9501503 276 SET SCREW FOR 83	151	2110305 261 A FEED LIFTING BELL ARM
31	9410125 100 NUT FOR 31	85	2110604 152 CAP SCREW FOR 83	152	9581201 456 CLAMP SCREW FOR 151
32	2110803 330 KNEE LIFTER RELEASE LEVER COMPLETE	86	2110312 021 TAKE UP LEVER COMPLETE	153	2110205 204 SLIDING BLOCK & SHAFT FOR 151
33A	2110603 331 BRACKET FOR 33B	86A	2110202 101 E NEEDLE BAR BRACKET COMPLETE	154	9541209 259 SCREW FOR 153
33B	2110803 332 KNEE LIFTER RELEASE LEVER	87	2110201 254 PLUG FOR SCREW HOLE	155	2110405 271 K FEED ROCK SHAFT
33C	2110803 333 SPRING FOR 33B	88	2110202 122 A SLIDING BLOCK FOR 86A	156	2110305 221 D FEED BAR
33D	2110603 334 HINGE SHAFT FOR 33B	89	2110806 331 A OIL TRAY, FRONT	157	2110405 223 A FEED DOG
33E	2110603 325 JOINT FOR 31	90	2110806 132 OIL FELT FOR 89	158	9530801 279 SCREW FOR 157
33F	9080200 008 STOP RING FOR 33E	91	2110806 132 SCREW FOR 89	159	2110205 225 B FEED BAR SHAFT
34	9541201 256 SCREW FOR 33A & 136	92	9540920 207 GEAR COMPLETE	160	9030100 036 WASHER FOR 159
35	2110801 231 FACE COVER PLATE	93	2110414 101 VERTICAL SHAFT ONLY	161	2110405 280 FEED ROCK ARM COMPLETE
36	2110801 234 WINDOW FOR ADJUSTMENT	94	2110404 241 VERTICAL SHAFT UPPER BUSHING	161A	9531105 259 CLAMP SCREW FOR 161
37	2110802 315 A THREAD GUIDE, LEFT	95	2110804 242 A VERTICAL SHAFT LOWER BUSHING	162	2110105 237 CENTER FOR FEED SHAFT, FRONT
38	2110801 293 PIN & NEEDLE HOLDER	96	2110404 243 B VERTICAL SHAFT LOWER BUSHING	163	2110105 238 CENTER FOR FEED SHAFT, REAR
39	2110801 294-A MAGNET FOR 38	97	2110406 367 OIL FELT FOR 96	164	0201020 110 E ACCESSORIES COMPLETE
40	2110202 350 F TENSION COMPLETE	98	2110404 211 HOOK SHAFT ONLY	164A	0102681 111 A ACCESSORY BOX
40A	2110202 354 CHECK SPRING	99	2110804 212 HOOK SHAFT FRONT BUSHING	164B	0101033 111 D SCREW DRIVER, LARGE
41	9501508-276 SET SCREW FOR 40 & 159	100	2110404 214 HOOK SHAFT REAR BUSHING	164C	0101023 112 C SCREW DRIVER, SMALL
42	2110202 111 B NEEDLE BAR ONLY	101	2110404 272 PACKING FOR 105	164D	0201065 173 A BED HINGE
43	2110202-170 A NEEDLE CLAMP COMPLETE	102	2110416 364 OIL FELT FOR 99	164E	2110202 190 A NEEDLE COMPLETE
44	2110202-173 THREAD GUIDE FOR 43	103	2110406 367 OIL FELT FOR 100	164F	0102245 111 CLOTH GUIDE
45	9530601-119 SCREW FOR 44	104	9015600 005 A SET SCREW FOR 100, 162, ETC	164G	0201033 121 F WRENCH, LARGE
46	2110202 194 NEEDLE #14	105	2110404 231 A COLLAR FOR 98	164H	0201033 122 C WRENCH, SMALL
47	2110602-113 NEEDLE BAR UPPER BUSHING	106	9501601 256 SET SCREW FOR 105	164I	0211011 154 WOOD SCREW FOR 164J
48	2110202-114 B NEEDLE BAR LOWER BUSHING	107	2110404 205 J GEAR CASE, UPPER	164J	0211021 129 C BED HINGE SEAT
49	2110602-116 THREAD GUIDE FOR 48	107A	2110201 254 PLUG FOR 107	164K	1110101 142 C CLOTH GUIDE THUMB SCREW
50	2110202-115 C RUBBER CAP FOR 47	108	2110404 206 C GEAR CASE, LOWER	164L	9321725 119 WOOD SCREW
51	9501501 256 SET SCREW FOR 47, 48, ETC	109	2110424 310 ROTATING HOOK ASSEMBLY	166	2110202 410 C BOBBIN WINDER ASSEMBLY
52	2110313 113 A NEEDLE PLATE	110	2110204 315 E HOOK RETAINER	168	0201021 124 A OIL DRIP PAN
53	9561103 262 SCREW FOR 52	111	9531104 267 SCREW FOR 110	169	2110103 303 D KNEE LIFTER COMPLETE
54	2110213 120-A SLIDE PLATE COMPLETE	112	9130500 318 WASHER FOR 111	170	0201056 111 MACHINE HEAD COVER
54A	1110301 522 SLIDE PLATE SPRING	113	2110104 301 B BOBBIN CASE COMPLETE	171	2110209 211 NAME PLATE
54B	9540601-119 SCREW FOR 54A	114	2110104 321 BOBBIN	172	2110819 111 USER'S HAND BOOK
55	2110403 271-A PRESSURE REGULATOR SCREW	115	2110305 111 C FEED CAM	173	2110829 411 MODEL NUMBER PLATE
56	2110103 211 A PRESSER BAR ONLY	116	9015600 005 A SET SCREW FOR 115	174	0201076 130 A COTTON STAND
57	2110803 213 PRESSER BAR SPRING	117	2110405 112 A GUIDE FOR FEED FORK	175	2110209 421 EXPORT MARK
58	2110403-215 BUSHING FOR 56	118	2110406 369 OIL FELT FOR 117	176	2110309 444 NEEDLE SIZE PLATE
59	2110103 220 C HINGED FOOT COMPLETE	119	2110406 371 SPRING FOR 118		
		120	2110305-160 A CRANK ROD COMPLETE		

Use only exact parts number for ordering. Be sure indicate all digits and letters as indicated in listing.
Do not use position number from illustration for ordering.