



GLOBAL

LP 8971-i-NP-AUT


Parts manual

(Parts that differ from LP 8971-
i-AUT)

www.globalsew.com

info@globalsew.com


HOOK MECHANISM



HOOK MECHANISM


[illegible]

HOOK SUPPORT SEAT MECHANISM



[illegible]


THREAD TRIMMING MECHANISM



THREAD TRIMMING MECHANISM

[illegible]


FEEDING SUPPORT SEAT MECHANISM



FEEDING SUPPORT SEAT MECHANISM

[illegible]

BACKTACK FEEDING MECHANISM



BACKTACK FEEDING MECHANISM

[illegible]