



GLOBAL




ZZ 1267-3S


Cam controlled Extra heavy duty, drop
feed zig-zag sewing machine with top feed.


Spare parts manual

www.globalsew.com


info@globalsew.com









		Description	
1	F0101	--- bottom plate	1
2	SF0102	--- head case	1
3	F0103	--- base of shuttle bed	1
4	SF0104	--- face plate	1
5	GW100	--- push pedal spring	1
6	GK205	--- sliding plate (left)	1
7	SF0107	--- needle plate	1
8	GK206	--- connection board	1
9	M0110	--- angle stand	1
10	M0111	--- belt hood support	1
11	M0112	--- belt hood	1
12	SF0112	--- back cover	1
13	SF0113	--- hood 2	1
14	GXR222	--- hinge 2	2
15	GX101	--- threading screw	1
16	GK209A	--- small oil seal	7
17	GS17520	--- screw	4
18	GS13312	--- screw	6
19	GS13316	--- screw	3
20	GS13530	--- screw	4
21	GS12104	--- screw	2
22	GS172	--- screw	4
23	GS13635	--- screw	4
24	GS13420	--- screw	2
25	GS13416	--- screw	2
26	GS13480	--- screw	3
27	GO100	--- belt hood screw saddle	3
28	GL204	--- nut	9
29	GS105	--- pin	2
30	M0131	--- pin	2
31	F1142	--- washer	4
32	SF0132	--- side plate (front)	1
33	GK208	--- big oil seal	1




		Description	
1	GZ107	upper shaft	1
2	F0202	thread take-up cam	1
3	F0203	screw	1
4	M0217	needle bar connecting rod	1
5	F0205	screw	1
6	M0212	thread take-up lever	1
7	GZ105	roller shaft	1
8	GU100	thread take-up roller	1
9	M0213	thread take-up shaft	1
10	GS215	washer	1
11	F0211	upper shaft (front)	1
12	M0218	cam	1
13	M0220	slide plate	1
14	M0221	feed dog lift connecting rod	1
15	M0222	feed dog lift eccentric	1
16	GK237	slide plate (B)	1
17	GO129	eccentric sleeve	1
18	HK4512	needle roller bearing	1
19	M0229	connecting rod	1
20	GK236	slide plate (A)	1
21	GO107	upper shaft (back)	1
22	M0207	pulley	1
23	GK216	upper shaft key	1
24	GK217	washer	1
25	GS13540	screw	1
26	GS13316	screw	1
27	GS11516	screw	2
28	GS13208	screw	4
29	GS13525	screw	1
30	GS13420	screw	2
31	GS13410	screw	3
32	GS13440	screw	1




		Description	
1	F0301	--- needle bar ---	1
2	DY×3	--- needle ---	1
3	F0305	--- rotating bar link ---	1
4	F0304	--- needle bar connecting shaft ---	1
5	F0307	--- washer ---	1
6	F0309	--- pendulum stand ---	1
7	F0314	--- pin (left) ---	1
8	F0313	--- pin (right) ---	1
9	F0310	--- shaft of pendulum stand ---	1
10	F0311	--- bushing ---	1
11	F0315	--- stand link ---	1
12	F0316	--- pin (1) ---	1
13	F0318	--- pin (2) ---	1
14	F0320	--- rocking bar ---	1
15	F0321	--- bushing ---	1
16	F0322	--- rocking bar shaft ---	1
17	F0325	--- rocking bar connecting shaft ---	1
18	F0326	--- nut ---	1
19	F0319	--- E-type ---	1
20	F0324	--- E-type snap spring ---	1
21	GS13420	--- screw ---	1
22	GS12316	--- screw ---	3
23	GS11305	--- screw ---	5
24	GS11406	--- screw ---	1
25	GS16208	--- screw ---	1
26	GS11205	--- screw ---	2




		Description		
1	F0401	bobbin bed cover	1	
2	GN116	bobbin	1	
3	GN111/9	shuttle hook	1	
4	M0405	shuttle support	1	
5	M0406	washer	3	0.2, 0.3, 0.5
6	M0407	washer	1	
7	M0408	screw	2	
8	F0408	bobbin bed	1	
9	M0410	shuttle set	1	
10	M0412	front shaft bushing	1	
11	M0413	shaft	1	
12	M0414	right helix bevel gear	1	
13	M0415	pin	1	
14	GX110	screw	2	
15	F0415	needle protecting board	1	
16	M0419	back shaft bushing	1	
17	M0420	washer	1	
18	M0421	bushing	1	
19	M0423	nut	1	
20	M0424	side plate	1	
21	GX108	pin	1	
22	GK241	bobbin bed press stand	1	
23	GX109	screw	1	
24	GX112	screw	2	
25	GW111	pressing spring	1	
26	GX117	screw	1	
27	GK243	press stand spanner	1	
28	GX113	screw	1	
29	M0437	cover	1	
30	GS13210	screw	8	
31	GL203	nut	1	
32	GS102	screw	1	
33	GS11406	screw	1	
34	GS11306	screw	2	
35	GS13216	screw	3	
36	GS12104	screw	2	
37	GS13460	screw	1	




		Description	
1	M0501	— — — left helix bevel gear — — — — —	1
2	M0504	— — — front shaft bushing — — — — —	1
3	M0505	— — — back shaft bushing — — — — —	1
4	M0506	— — — blocking ring of lower shaft — — —	1
5	M0508	— — — lower shaft II — — — — —	1
6	M0509	— — — tight ring of lower shaft — — —	1
7	M0512	— — — blocking ring of lower shaft — — —	1
8	M0513	— — — back shaft bushing — — — — —	1
9	GZ112	— — — lower shaft (1) — — — — —	1
10	GP107	— — — small gear of lower shaft — — —	1
11	GO130	— — — bushing — — — — —	1
12	GO132	— — — bushing — — — — —	2
13	M0522	— — — swinging shaft — — — — —	1
14	GZ128	— — — shaft — — — — —	1
15	M0524	— — — pendulum axle stand — — — — —	1
16	GP106	— — — gear — — — — —	1
17	M0519	— — — washer — — — — —	3
18	GS13318	— — — screw — — — — —	3
19	GS10414	— — — screw — — — — —	2
20	M0415	— — — pin — — — — —	2
21	GS11406	— — — screw — — — — —	2
22	GS13416	— — — screw — — — — —	2
23	GS11306	— — — screw — — — — —	2
24	GS11406	— — — screw — — — — —	1




		Description	
1	M0601	--- bottom feeding shaft ---	1
2	M0602	--- back bushing of feeding shaft ---	2
3	M0604	--- front feeding crank ---	1
4	M0605	--- blocking ring of feeding axle ---	2
5	M0607	--- front bushing of feeding shaft ---	1
6	GH125	--- teeth fork ---	1
7	GZ128	--- pin shaft ---	1
8	M0614	--- small oil seal ---	2
9	M0615	--- E-shaped snap spring ---	1
10	M0616	--- shaft of tooth-shelf ---	1
11	M0617	--- oil pipe joint ---	1
12	SF0612	--- feed dog ---	1
13	M0621	--- shelf ---	1
14	M0624	--- connection board ---	1
15	M0623	--- bearing ---	2
16	M0627	--- tooth-lifting axle ---	1
17	M0626	--- front shaft bushing ---	1
18	M0605	--- lifting tooth axle retaining ring ---	1
19	M0628	--- crank ---	1
20	M0631	--- pin shaft ---	1
21	M0632	--- E-shaped snap spring ---	1
22	M0625	--- back shaft bushing ---	1
23	GS13416	--- screw ---	3
24	M0630	--- nut ---	1
25	GS11406	--- screw ---	7
26	M0620	--- nut ---	2
27	GS13420	--- screw ---	2
28	GS13308	--- screw ---	2




		Description	
1	G0120	--- shaft bushing	1
2	GL204	--- nut	1
3	GK249	--- stitch seat fixed stand	1
4	GK246	--- stitch support	1
5	GK245	--- sliding block	1
6	GZ129	--- screw	1
7	GZ130	--- screw	1
8	GW210	--- spring	1
9	GW209	--- stitch screw sleeve levf	1
10	GK248	--- stitch spacing board	2
11	GKS105	--- stitch cover plate	1
12	GZ131	--- stitch spacing sleeve	1
13	GZ132	--- stitch regulation screw sleeve	1
14	GKS247	--- stitch handle ball	1
15	GS13416	--- screw	2
16	GS13320	--- screw	1
17	GS11425	--- screw	1




		Description	
1	GZS139	--- uplifting presser handle ball ---	1
2	GZ138	--- uplifting handle bar ---	1
3	M0805	--- shaft ---	1
4	GW211	--- uplifting handle axle jump ring ---	1
5	M0804	--- thread loosing sleeve ---	1
6	F0822	--- thread releasing plate (2) ---	1
7	GW217	--- uplifting presser spring ---	1
8	M0802	--- eccentric slice ---	1
9	M0312	--- block ---	1
10	GZ125	--- pressure regulated screw ---	1
11	M0314	--- nut ---	1
12	GW201	--- presser bar spring ---	1
13	M0310	--- setting block of pressing rod ---	1
14	M0307	--- pressing rod lower bushing ---	1
15	GK226	--- presser lifting locating slideway ---	1
16	M0309	--- presser bar ---	1
17	SF0817	--- presser foot ---	1
18	SF0818	--- uplifting presser lever shaft ---	1
19	GW212	--- lever torsional spring ---	1
20	SF0820	--- uplifting presser lever ---	1
21	GD0911	--- lifting lever finger ---	1
22	GD0912	--- presser lifting bar ---	1
23	GS11410	--- screw ---	1
24	GS13210	--- screw ---	1
25	GS13325	--- screw ---	2
26	GS13320	--- screw ---	2
27	GS13216	--- screw ---	1
28	GS13420	--- screw ---	1




		Description	
1	GLS204	--- tension nut ---	3
2	GW115	--- thread tension spring ---	3
3	GK232	--- thread releasing plate ---	2
4	GK231	--- tension plate ---	4
5	GZ126	--- tension screw ---	2
6	GX106	--- loosen bolt ---	2
7	M0908	--- thread passing ring ---	1
8	M0910	--- thread tension rack ---	1
9	M0911	--- thread releasing plate ---	1
10	M0912	--- pin ---	1
11	GKS108	--- drawing stand ---	1
12	GKS107	--- thread passing sead ---	1
13	GC0814	--- thread take-up soring ---	1
14	M0922	--- thread take-up spring ---	1
15	M0925	--- tension screw ---	1
16	GK233	--- thread passing plate ---	2
17	GK234	--- washer ---	2
18	GP102	--- thread passing wheel ---	2
19	GL205	--- nut ---	2
20	GS13208	--- screw ---	1
21	GS13316	--- screw ---	2
22	M0913	--- nut ---	1
23	GS11206	--- screw ---	1




		Description	
1	GKR221	--- table	1
2	GKR200	--- hinge	2
3	GC1005	--- screw	6
4	GC1004	--- rubber cushion	4
5	GKR216	--- oil pan	1
6	GBS112	--- screw	6
7	GC1021	--- screw	4
8	M1010	--- stand	1
9	GKR184	--- footstep axle seat	4
10	GKR182	--- pedal	1
11	GKR111	--- pedal	1
12	GKR116	--- lower rod of clutch motor	1
13	GKR183	--- rod adjusting device	1
14	GKR118	--- upper rod of clutch motor	1
15	M1014	--- thread stand	1



		Description	
1	F1101	cam	3
2	F1102	cam bracket	1
3	F1106	shaft	1
4	F1107	pin	1
5	F1109	shaft key	1
6	F1108	speed reducer	1
7	F1114	wheel	1
8	F1116	wheel	1
9	F1118	teeth belt	1
10	F1134	shaft	1
11	F1133	roller	1
12	F1131	screw	1
13	F1130	rocker	1
14	F1129	bushing	1
15	F1128	T-bar	1
16	F1126	synchro rocker	1
17	F1125	synchro rocker slide	1
18	F1122	bear (right)	1
19	F1121	bear (left)	1
20	F1120	screw rod	1
21	F1119	hood	1
22	F1123	nut	1
23	F1124	nut	1
24	F1132	nut	1
25	F1127	washer	1
26	F1111	washer	6
27	F1142	washer	4
28	F1105	washer	1
29	F1113	washer	1
30	GS13416	screw	2
31	GS13420	screw	5
32	GS12412	screw	2
33	GS13425	screw	5
34	GS13520	screw	2
35	GS11406	screw	2
36	GS172	screw	2



		Description	
1	SF1201	walking foot	1
2	SF1202	walking foot rod	1
3	SF1203	guide plate	1
4	SF1204	cushion	2
5	SF1205	link shaft	1
6	SF1206	front crank	1
7	SF1207	connecting rod	1
8	SF1208	back feeding crank	1
9	GX123	pin	1
10	GH148	fork-rod of swinging pressing foot	1
11	GU119	crank slide block	1
12	GU120	screw of slide block of pressing foot	1
13	GK254	upper feeding axle retainer axle	2
14	GZ120	upper feeding axle	1
15	GH152	upper feeding back crank seat	1
16	GO124	upper feeding axle back axle sleeve	1
17	GK254	upper feeding adjustment bar	1
18	GZ133	upper feeding connecting pin	2
19	GW205	upper feeding connecting pin jump ring	1
20	GU110	washer	1
21	GR245	washer	1
22	GL106	nut	3
23	GC0819	finger	1
24	GS13208	screw	2
25	GS13318	screw	2
26	GS180	screw	2
27	GS11410	screw	2
28	GS212	screw	1
29	GS13416	screw	1
30	GS11406	screw	4
31	GS13520	screw	2
32	GS13420	screw	2
33	GS13312	screw	1



		Description	
1	SF1301	--- large connecting rod ---	1
2	SF1302	--- pressing foot front crank ---	1
3	SF1303	--- blocking ring ---	1
4	SF1304	--- presser foot lift cam ---	1
5	SF1305	--- screw ---	2
6	SF1306	--- pressing foot lifting rocking board	1
7	SF1307	--- sliding block ---	1
8	GO127	--- pressing foot lifting shaft front sleeve	1
9	GZ122	--- pressing foot lift shaft	1
10	GO126	--- pressing foot lifting shaft back sleeve	1
11	GH146	--- pressing foot lifting adjusting back crank	1
12	GS150	--- screw ---	1
13	GD0606	--- large pressing foot lifting connecting rod	1
14	GL108	--- nut ---	1
15	GR245	--- washer ---	1
16	GL106	--- nut ---	1
17	GS181	--- screw ---	1
18	GW206	--- E-type ---	2
19	GS153	--- screw ---	1
20	GS10508	--- screw ---	1
21	GS11410	--- screw ---	2
22	GS13416	--- screw ---	2
23	GS11406	--- screw ---	2
24	GS13520	--- screw ---	1

