
# JUKI MO-804 THREADING 3 THREAD MACHINES

MO-804


- 1. Overlock needle thread is No. I and is shown in red color.
- 2. Upper looper thread is No. 2 and is shown in blue color.
- 3. Lower looper thread is No. 3 and is shown in yellow color.



#### JUKI MO-816 THREADING 4-5 THREAD MACHINES


MO-816

- 1. Overlock needle thread is No. 1 and is shown in red color.
- 2. Double chain needle thread is No. 2 and is shown in green color.
- 3. Upper looper thread is No. 3 and is shown in blue color.
- 4. Lower looper thread is No. 4 and is shown in yellow color.
- 5. Double chain looper thread is No. 5 and is shown in black color.



## **JUKI MO-2500 THREADING**

Thread the machine according to the threading chart given below. (The same chart is on the inside of the looper cover.)




### **JUKI MO-3600 THREADING**


#### 4. THREADING THE MACHINE




Carry out the following steps of procedure after the power switch has been turned OFF.

Thread the machine according to the threading chart given below. (The same chart is on the inside of the looper cover.)






MO-3616





(Caution) Raise looper thread cam thread guide ① and perform threading. Return looper thread cam thread guide ① to its home position and securely fix it to retaining spring ②.



(Caution) Be sure to pass the needle thread for double chainstitch through the needle thread take-up lever.

(Pass the needle thread for overlocking through the thread take-up lever located ouiside.)





(Caution) When using an untwisted thread such as wooly nyton thread or weak thread, do not wind it round the intermediate thread guide.