

Pfaff 5487

Pfaff 5489

Pfaff 5487 706 81

Pfaff 5489 706 81

Pfaff 5487 706 82

Pfaff 5489 706 82

PFAFF[®] 5487/5489
-706/81
-706/82*

Unterklassen-Ausstattung
Subclass parts
Composition des sous-classes
Composición de las subclases

Unterklassen-Ausstattung

Subclass organization



Equipement des sous-classes

Dotación de las subclases


Unterklasse Subclass Sous-classe Subclase	Ausführung Model Version Tipo de máquina	Nadelstange Needle bar Barre à aiguille Barra de aguja	Stoffschieberpaar ⁴ Feed dog, pair Paire de griffes Par de transportadores interiores	Stoffschieber, vorn ⁴ Feed dog, front Griffe avant Elemento anterior del transportador inferior	Stoffschieber, hinten ⁴ Feed dog, rear Griffe arrière Elemento posterior del transportador inferior
-814/01-706/81-6/41	A; B	91-170 245-92	91-047 600-03	91-047 602-04	91-047 601-04
-814/01-706/81-6/41-900/71	A; B	91-170 245-92	91-047 589-03	91-047 591-04	91-047 590-04

- ⁴ = Ausführung angeben
= Indicate model
= Préciser la version
= Indíquese el tipo de máquina

Unterklassen-Übersicht/Table of subclasses/Table des sous-classes/Tabla de subclases




-6/41-900/71




-6/41

91-058 235-04 ⁴




-6/41

91-058 408-04 ⁴








-6/41-900/71

91-055 556-91



Unterklasse Subclass Sous-classe Subclase	Equipement des sous-classes Unterklassen-Ausstattung			Dotación de las subclases Subclass organization	
	Sichplatte Head plate Plaque à aiguille Placa de aguja	Nähfuß Presser foot Pied presseur Pie prensatelas	Stoffschieber Vibrating presser Pied entraîneur Transportador superior	Kettensichgreifer Looper Boucleur Garfio para punto cadena	Abdeckplatte Cover plate Plaque de recouvrement Placa cubierta
-814/01-706/81-6/41	91-058 235-04	91-055 556-91	91-049 154-45	91-170 966-05	91-170 365-91
-814/01-706/81-6/41-900/71	91-058 408-04	91-055 557-01	91-049 154-45	91-170 966-05	91-172 069-91

Unterklassen-Übersicht/Table of subclasses/Table des sous-classes/Tabla de subclases

<p>91-055 557-01</p>  <p>-6/41-900/71</p>	<p>91-049 154-45</p>  <p>-6/41 (-900/71)</p>	<p>91-170 966-05</p>  <p>-6/41 (-900/</p>
<p><u>91-170 365-91</u></p> 		<p><u>91-172 069-91</u></p>  <p>-6/41-900</p>