

LIST OF PARTS COMPLETE FOR MACHINE NO. 62-47

For general work in fabrics and light leather. For lap seaming button laps on shoes, etc. Two needles, two loopers, gauges $\frac{3}{32}$ inch to $\frac{3}{8}$ inch. Alternating pressers, independent upper and under feeds.

*52583	Arm, upper and lower (solid).....	
46216	" Rock Shaft.....	
46217	" " " Crank (back) with two 1497c....	
1497c	" " " " " Set Screw.....	
46399	" " " " (front) with 448c and 457c	
23724	" " " " " Pin.....	
448c	" " " " " Set Screw.....	
46218	" Rotary Shaft.....	
38329	" " " Collar with two 457c.....	
457c	" " " " " Set Screw.....	
23872	" " " Flanged Bushing.....	
159F	" " " " " Screw.....	
4784	" " " Oil Pad (felt).....	
144D	" " " Screw.....	
17509	" Side Cover (lower).....	
286D	" " " " Thumb Screw.....	
52554	" " " (upper).....	
9533	" " " " Pin.....	
176D	" " " " " Screw.....	
23873	Balance Wheel with two 430c.....	
430c	" " " Set Screw.....	
38414	Cloth Plate.....	
691F	" " " Screw (left).....	
1094F	" " " " (right).....	
38415	" " " Slide (large) with 1602E.....	
1602E	" " " " " Bushing.....	
38416	" " " " " Spring.....	
725H	" " " " " " Screw.....	
38417	Cloth Plate Slide (large) complete, Nos. 38415, two 38416 and four 725H.....	
38418	Cloth Plate Slide (small).....	
38419	" " " " " Spring.....	
725H	" " " " " " Screw.....	

38420	Cloth Plate Slide (small) complete, Nos. 38418, 38419 and two 725H.....
38421	Cloth Plate complete, Nos. 38414, 38417 and 38420.
46221	Crank Connecting Rod with 46222, 46223 and two each 896E and 1057E.....
50069C	Crank Connecting Rod Ball Screw Stud.....
1619E	" " " " " " Nut.....
*46222	" " " Cap (lower).....
896E	" " " " " Screw.....
*46223	" " " " (upper).....
1057E	" " " " " Screw.....
46225	" " " Washer (fibre).....
52584	Face Plate.....
171D	" " Screw.....
38425	Feed (lower) Bar with 231C and 460C.....
23716	" " " Bushing.....
23726	" " " Hinge Pin.....
231C	" " " Set Screw.....
38426	" " " Slide Block.....
38427	" " Connecting Rod with 23865 and three 1057E.....
*23865	Feed (lower) Connecting Rod Cap.....
1057E	" " " " " Screw.....
23866	" " " " " Hinge Pin (eccentric)
1057E	" " " " " Clamping Screw.....
52534	Feed (lower) Dog.....
898C	" " " Screw.....
460C	" " " Stop Screw.....
*38127	" " Eccentric.....
*23729	" " " Body.....
443C	" " " Set Screw.....
21331	" " " Pressure Spring.....
21332	" " " " " Cap.....
934D	" " " " " " Screw..
196F	" " " Set Screw.....
38128	Feed (lower) Eccentric (adjustable) complete, Nos. 196F, 934D, 1103C, 21331, 21332, 23729, 38127 and two 443C.....
38429	Feed (lower) Lifting Eccentric with two 465C.....
46113	" " " " " Cover.....
335D	" " " " " Screw.....
465C	" " " " " Set Screw.....
1103C	" " " " " Regulating Screw.....
38431	" " " " " Rocking Frame.....
38432	" " " " " Bracket with two 465C
123E	" " " " " " Screw.....
38433	" " " " " Hinge Pin.....
465C	" " " " " " Set Screw..

52585	Feed (upper) Bar
199D	" " " Cap Screw
52586	" " " Connecting Link
1423D	" " " " " Cap Screw
1048C	" " " " " Hinge Screw
19356	" " " Lifting Bell Crank
199D	" " " " " " Cap Screw
52587	" " " " " " Connecting Link
199D	Feed (upper) Bar Lifting Bell Crank Connecting Link Cap Screw
46416	Feed (upper) Bar Lifting Bell Crank Driving Arm with 1186D
1186D	Feed (upper) Bar Lifting Bell Crank Driving Arm Clamping Screw
46417	Feed (upper) Bar Lifting Bell Crank Driving Arm Connection
1423D	Feed (upper) Bar Lifting Bell Crank Driving Arm Connection Cap Screw
46418	Feed (upper) Bar Lifting Bell Crank Driving Arm Connection Hinge Stud
457C	Feed (upper) Bar Lifting Bell Crank Driving Arm Connection Hinge Stud Set Screw
1316C	Feed (upper) Bar Lifting Bell Crank Driving Arm Connection Screw Stud
46419	Feed (upper) Bar Lifting Bell Crank Driving Arm Shaft
52588	Feed (upper) Bar Lifting Bell Crank Driving Arm Shaft Bracket
896E	Feed (upper) Bar Lifting Bell Crank Driving Arm Shaft Bracket Screw
52589	Feed (upper) Connecting Rod with 904C, 52590 and two 896E
*52590	Feed (upper) Connecting Rod Cap
896E	" " " " " Screw
40247	" " " " " Hinge Pin
904C	" " " " " " Set Screw
*21230	" " " Eccentric
*52591	" " " Body
446C	" " " " Set Screw
21331	" " " Pressure Spring
21332	" " " " " Cap
934D	" " " " " " Screw
196F	" " " " Set Screw
52592	Feed (upper) Eccentric (adjustable) complete, Nos. 196F, 934D, 1106C, 21230, 21331, 21332, 52591 and two 446C

1106C	Feed (upper) Regulating Screw.....
52593	" " Shaft.....
52594	" " " Crank (back) with 157E.....
157E	" " " " " Clamping Screw..
52595	" " " " (front) with 1057E.....
1057E	" " " " " Clamping Screw..
52596	Feeding Foot.....
203F	" " Screw.....
46092	Lifting Presser Bar.....
46073	" " " Bushing (lower).....
1133E	" " " " " Set Screw.....
38456	" " " " (upper).....
1133E	" " " " " Set Screw.....
46421	" " " Guide Bracket with 157D and 892C.....
892C	Lifting Presser Bar Guide Bracket Adjusting Screw
157D	" " " " " Clamping Screw.
52597	Lifting Presser Bar Lifter.....
52598	" " " " " Hinge Stud.....
465C	" " " " " Set Screw....
52599	" " " Lifting Bracket with 1356E....
1356E	" " " " " Clamping Screw
52600	" " " " " Connecting Link.....
990F	Lifting Presser Bar Lifting Bracket Connecting Link Cap Screw.....
724C	Lifting Presser Bar Lifting Bracket Connecting Link Hinge Screw.....
46422	Lifting Presser Bar Spring (flat).....
38468	" " " " Stud.....
52535	" " Foot.....
190D	" " " Screw.....
52536	Looper (back) with 590D and 38393.....
1147C	" " Set Screw.....
38393	" " Thread Guard.....
590D	" " " " Screw.....
52537	" (front).....
1120C	" " Set Screw.....
46226	" Bell Crank with 1037C.....
38436	" " Hinge Stud.....
443C	" " " " Set Screw.....
46227	Looper Bell Crank Pitman complete, Nos. 1706E, 1713E and 46233 to 46235.....
50070C	Looper Bell Crank Pitman Ball Screw Stud (upper)
1636E	" " " " " " " " " " " "
	Nut.....
46228	Looper Bell Crank Pitman Ball Stud (lower).....
1037C	" " " " " " " " Set Screw.....

*46229	Looper Bell Crank Pitman Cap (lower).....
171E	" " " " " " Screw.....
*46230	" " " " " " (upper).....
171E	" " " " " " Screw.....
*46231	" " " " " End Bearing (lower)...
*46232	" " " " " " (upper)...
46233	" " " " " Head (lower) Nos. 46228,
	46229, 46231 and two 171E.....
46234	Looper Bell Crank Pitman Head (upper) Nos. 46230,
	46232, 50070c and two 171E.....
46235	Looper Bell Crank Pitman Rod.....
1706E	" " " " " Nut (lower).....
1713E	" " " " " " (upper).....
38496	" Carrier with 1120c and three 1147c.....
38440	" " Hinge Pin.....
1147C	" " " " Set Screw.....
46236	Looper Carrier Pitman complete, Nos. 1708E, 1709E
	and 46241 to 46243.....
50070C	Looper Carrier Pitman Ball Screw Stud (right)....
1636E	" " " " " " " Nut
46237	" " " " " Stud (left).....
1147C	" " " " " " Set Screw..
*46238	" " " Cap (left).....
171E	" " " " " Screw.....
*46238	" " " " (right).....
171E	" " " " " Screw.....
*46239	" " " End Bearing (left).....
*46240	" " " " (right).....
46241	" " " Head (left) Nos. 46237 to
	46239 and two 171E.....
46242	Looper Carrier Pitman Head (right) Nos. 46238,
	46240, 50070c and two 171E.....
46243	Looper Carrier Pitman Rod.....
1708E	" " " " Nut (left).....
1709E	" " " " " (right).....
46244	" " " Washer (fibre).....
46042	" " Rock Shaft with two 175D.....
175D	" " " " Adjusting Screw.....
38450	" " " " Crank (forked) with
	159E.....
159E	Looper Carrier Rock Shaft Crank Clamping Screw..
38451	" " " " " Slide Block.....
46043	" " " " Hinge Pin.....
1508E	" " " " " Nut.....
129E	" " " " " Set Screw....
38452	" Eccentric with two 465C.....
465C	" " Set Screw.....
38453	" Shaft.....

38454	Looper Shaft Bracket.....	
123E	" " " Screw.....	
391D	" " " Screw.....	
46051	Needle Bar.....	
46052	Needle Bar complete, Nos. 46051 and 46053.....	
38456	" " Bushing.....	
1133E	" " " Set Screw.....	
38458	" " Connecting Link.....	
38459	" " " " Hinge Stud.....	
1520E	" " " " " Nut.....	
38460	" " " Stud with two 391E.....	
391E	" " " " Clamping Screw.....	
46053	" Clamp with 46054 and two 1072F.....	
46054	" " Thread Guide (two pieces).....	
38461	Needle Guard (back).....	
176F	" " " Screw.....	
46001	" " (front).....	
206F	" " " Screw.....	
1072F	" Set Screw.....	
46002	Oil Cup with two 38463.....	
38463	" " Packing (felt).....	
225F	" " Screw.....	
574D	Pressure Regulating Thumb Screw.....	
1539D	" " " " Lock Nut.....	
52538	Slack Thread Controller.....	
52539	" " " Bracket.....	
175D	" " " " Screw.....	
52540	" " " Connection with 457C.....	
457C	" " " " Set Screw.....	
110C	" " " Hinge Screw.....	
2102	Tension (under thread) Disc.....	
1560C	" " " Regulating Thumb Nut.....	
916F	" " " Screw Stud.....	
10148	" " " Spring.....	
17547	" " " Thread Guide.....	
2102	" (upper thread) Disc.....	
1560C	" " " Regulating Thumb Nut.....	
916F	" " " Screw Stud.....	
13710	" " " Spring.....	
17547	" " " Thread Guide.....	
38225	Thread (under) Eyelet (back).....	
190D	" " " " Screw.....	
38284	" " " (front).....	
46049	" " Nipper Cam with 465C.....	
465C	" " " " Set Screw.....	
38210	" " " Spring (lower).....	
38211	" " " " (upper).....	
46247	" " " " " Stop.....	
176F	" " " " " Screw.....	

38475	Thread (under) Take-up with 465C	
465C	" " " Set Screw	
46047	" " " Staple	
46040	" " " " Bracket with 910C ..	
690D	" " " " " Screw	
46041	" " " " Spring	
190D	" " " " " Screw	
910C	" " " " Stop Screw	
38482	" " " Stripper	
207D	" " " " Screw	
38476	" " " Thread Guard (left)	
207D	" " " " " " Screw	
38477	" " " " " " (right)	
207D	" " " " " " Screw	
52601	" (upper) Controller	
206F	" " " Screw	
46170	" " Eyelet	
190D	" " " Screw	
46171	" " Take-up with 223D	
223D	" " " Clamping Screw	
52542	Throat Plate for 52534	
691F	" " " Screw	

ACCESSORIES

2015	Machine Cushion (rubber)	
—	1¾ in. wood screw No. 16, to secure machine to table	
4718	Machine Rest (felt)	
35859	Oiler with Cap and 35861	
35860	" 35859, filled with oil	
35861	" Spout, 3½ in. long	
26026	Screw Driver	
38487	Threading Wire	
35095	Tweezers, 6 in.	
8908	Wrench for 1520, 1706, 1708 and 1709	
23766	" " 1508 and 1636	
19221	" " 1619	

FOOT LIFTER PARTS

6439	Chain, 36 in. to 45 in.	
------	------------------------------	--

NOTE. When ordering No. 6439 give length required.

4879	Chain Connecting Link for 4885	
52602	Lifting Lever	
802D	" " Hinge Screw	

52603	Lifting Lever Link.....
957D	" " " Hinge Screw.....
23761	" " Spring.....
1002D	" " Stop Screw.....
4881	Treadle.....
4882	" Shaft.....
4883	" Spring.....
4884	" Stand.....
4885	Treadle complete, Nos. 4879, 4881 to 4884 and two wood screws 1 in. No. 16.....
52604	Foot Lifter complete, Nos. 802D, 957D, 1002D, 4885, 6439, 23761, 52602 and 52603.....

KNEE LIFTER PARTS

52602	Lifting Lever.....
23760	" " Connecting Rod for 52605.....
38384	" " " " " 52606.....
802D	" " Hinge Screw.....
52603	" " Link.....
957D	" " " Hinge Screw.....
23761	" " Spring.....
1002D	" " Stop Screw.....
2763	Rock Shaft.....
12242	" " Hanger with two wood screws 1 in. No.10
6335	" " Knee Arm.....
6336	Rock Shaft Knee Arm complete, Nos. 2766, 2767 and 6335.....
2766	Rock Shaft Knee Arm Hub with 356C.....
356C	" " " " " Set Screw.....
2767	" " " Plate with 356C.....
356C	" " " " Set Screw.....
6337	" " Lifting Bracket with two 356C.....
7125	" " " " Hook.....
356C	" " " " " Set Screw.....
356C	" " " " " Set Screw.....
2770	" " Stop Dog with 356C.....
356C	" " " " " Set Screw.....
23767	Rock Shaft complete, Nos. 2763, 2770, 6336, 6337, 7125 and two 12242.....
52605	Knee Lifter complete (power table) Nos. 802D, 957D, 1002D, 23760, 23761, 23767, 52602 and 52603
52606	Knee Lifter complete (bench stand) Nos. 802D, 957D, 1002D, 23761, 23767, 38384, 52602 and 52603

THREAD UNWINDER

FOR FOUR LARGE SPOOLS OR FOUR LARGE CONES OF THREAD

27623	Spool Pin.....	
155c	" " Set Screw.....	
41534	" Rest.....	
41535	" " 41534 with 1149c and four each 155c and 27623.....	
1149c	Spool Rest Set Screw.....	
27940	" Stand with 453c.....	
41514	" Weight, 4 in. diam., with 41515.....	
41515	" " Centre Pin.....	
27739	Thread Cone (wood).....	
41633	" Guard with 208E and four 41569.....	
41569	" " Eyelet.....	
41637	" " Rod (lower).....	
41638	" " " (upper).....	
41639	" " " Coupling with two 456c.....	
456c	" " " " Set Screw.....	
41640	Thread Guard Rod complete, 30 in. long, Nos. 41637 to 41639.....	
453c	Thread Guard Rod Set Screw.....	
208E	" " Screw.....	
41537	Thread Unwinder complete, Nos. 27940, 41535, 41633, 41640, three wood screws 1 in. No. 12 and four each 27739 and 41514.....	

