

62-53

NUMBERING DEPARTMENT
AUGUST 7, 1914

LIST OF PARTS COMPLETE



Machine No. 62=53

THE SINGER MANUFACTURING COMPANY

LIST OF PARTS COMPLETE

FOR

MACHINE NO. 62-53

For two line stitching in fabrics. Has cloth plate specially fitted for lap seam feller. Two needles, two loopers. Gauges from $\frac{1}{32}$ in. to $\frac{9}{16}$ in.

FORMERLY 62 S. V. 74

*52736	Arm, upper and lower (solid).....
52630	" Oil Tube with 49092, for oiling 46221.....
49092	" " " Packing (felt).....
46216	" Rock Shaft.....
46217	" " " Crank (back) with two 1497c.....
1497c	" " " " " Set Screw.....
38412	" " " " (front) with 443c.....
23724	" " " " " Pin.....
443c	" " " " " Set Screw.....
46218	" Rotary Shaft.....
38329	" " " Collar with two 457c.....
457c	" " " " " Set Screw.....
23872	" " " Flanged Bushing.....
159F	" " " " " Screw.....
4784	" " " Oil Pad (felt).....
144D	" " " Screw.....
17509	" Side Cover (lower).....
286D	" " " " Thumb Screw.....
52554	" " " (upper).....
9533	" " " " Pin.....
190D	" " " " Screw.....
23873	Balance Wheel with two 430c.....
430c	" " " Set Screw.....
46078	Cloth Plate.....
691F	" " Screw (left).....
1094F	" " " (right).....
46461	" " Slide (left).....
38419	" " " " Spring.....
725H	" " " " " Screw.....
46462	Cloth Plate Slide (left) complete, Nos. 38419, 46461 and two 725H.....

38105H	Cloth Plate Slide (right) with 1602E.....
1602E	" " " " Bushing.....
286D	" " " " Thumb Screw.....
46079	Cloth Plate complete, Nos. 286D, 1460H, 38105H, 46078, 46082 and 46462.....
46221	Crank Connecting Rod with 46222, 46223 and two each 896E and 1057E.....
50069c	Crank Connecting Rod Ball Screw Stud.....
1619E	" " " " " " Nut.....
*46222	" " " " Cap (lower).....
896E	" " " " " Screw.....
*46223	" " " " (upper).....
1057E	" " " " " Screw.....
46179	Face Plate.....
46111	" " Pin.....
286D	" " Thumb Screw.....
38425	Feed Bar with 231c and 460c.....
23716	" " Bushing.....
23726	" " Hinge Pin.....
231c	" " Set Screw.....
38426	" " Slide Block.....
38427	" Connecting Rod with 1057E, 23865 and two 896E.
*23865	" " " Cap.....
896E	" " " " Screw.....
23866	" " " Hinge Pin (eccentric).....
1057E	" " " " " Clamping Screw.....
46080	" Dog, for $\frac{1}{32}$ in. to $\frac{5}{32}$ in. gauge.....
46081	" " " $\frac{3}{16}$ in. to $\frac{3}{8}$ in. gauge.....
52817	" " " $\frac{13}{32}$ in. to $\frac{9}{16}$ in. gauge.....
50073D	" " Screw.....
460c	" " Stop Screw.....
*38127	" Eccentric.....
*23729	" " Body.....
443c	" " " Set Screw.....
21331	" " " Pressure Spring.....
21332	" " " " Cap.....
934D	" " " " " Screw.....
196F	" " " Set Screw.....
38128	Feed Eccentric (adjustable) complete, Nos. 196F, 934D, 1103c, 21331, 21332, 23729, 38127 and two 443c.....
38429	Feed Lifting Eccentric with two 465c.....
46113	" " " Cover.....
335D	" " " " Screw.....
465c	" " " Set Screw.....
1103c	" Regulating Screw.....

38431	Feed Rocking Frame.....
38432	" " " Bracket with two 465c.....
123E	" " " " Screw.....
38433	" " " Hinge Pin.....
465c	" " " " " Set Screw.....
46082	Folder Holder Seat Cover.....
1460H	" " " " Screw.....
52774	Looper (back) with 590D and 52776.....
52775	" " Carrier with 1147c.....
193F	" " " Screw.....
1147C	" " Set Screw.....
52776	" " Thread Guard (double).....
590D	" " " " Screw.....
52777	" (front).....
52778	" " Carrier with 1120c and two 1147c.....
1120c	" " Set Screw.....
46226	" Bell Crank with 1037c.....
38436	" " " Hinge Stud.....
443c	" " " " " Set Screw.....
46227	Looper Bell Crank Pitman complete, Nos. 1706E, 1713E and 46233 to 46235.....
50070c	Looper Bell Crank Pitman Ball Screw Stud (upper)
1636E	" " " " " " " "
	Nut.....
46228	Looper Bell Crank Pitman Ball Stud (lower).....
1037C	" " " " " " " Set Screw
*46229	" " " " Cap (lower).....
171E	" " " " " " Screw.....
*46230	" " " " " (upper).....
171E	" " " " " " Screw.....
*46231	" " " " End Bearing (lower).....
*46232	" " " " " (upper).....
46233	" " " " Head (lower) Nos. 46228, 46229, 46231 and two 171E.....
46234	Looper Bell Crank Pitman Head (upper) Nos. 46230, 46232, 50070c and two 171E.....
46235	Looper Bell Crank Pitman Rod.....
1706E	" " " " Nut (lower).....
1713E	" " " " " (upper).....
52779	Looper Carrier (adjustable) complete, for $\frac{1}{32}$ in. to $\frac{9}{16}$ in. gauge, Nos. 193F, 52775 and 52778....
38440	Looper Carrier Hinge Pin.....
1147C	" " " " Set Screw.....
46236	Looper Carrier Pitman complete, Nos. 1708E, 1709E and 46241 to 46243.....
50070c	Looper Carrier Pitman Ball Screw Stud (right).....
1636E	" " " " " " " Nut...
46237	" " " " Stud (left).....

1147c	Looper Carrier Pitman Ball Stud (left) Set Screw.....
*46238	" " " Cap (left).....
171E	" " " " " Screw.....
*46238	" " " " (right).....
171E	" " " " " Screw.....
*46239	" " " End Bearing (left).....
*46240	" " " " " (right).....
46241	" " " Head (left) Nos. 46237 to 46239 and two 171E.....
46242	Looper Carrier Pitman Head (right) Nos. 46238, 46240, 50070c and two 171E.....
46243	Looper Carrier Pitman Rod.....
1708E	" " " " Nut (left).....
1709E	" " " " " (right).....
46244	" " " Washer (fibre).....
46042	" " " Rock Shaft with two 175D.....
175D	" " " " Adjusting Screw.....
38450	" " " " Crank (forked) with 159E.....
159E	" " " " " Clamping Screw.....
38451	" " " " " Slide Block.....
46043	" " " " Hinge Pin.....
1508E	" " " " " " Nut.....
129E	" " " " " " Set Screw.....
38452	" Eccentric with two 465c.....
465c	" " Set Screw.....
38453	" Shaft.....
52553	" " Bracket.....
123E	" " " Screw.....
391F	" " Screw.....
46051	Needle Bar.....
46052	Needle Bar complete, Nos. 46051 and 46053.....
38456	" " Bushing.....
1133E	" " " Set Screw.....
38458	" " Connecting Link.....
38459	" " " " Hinge Stud.....
1520E	" " " " " " Nut.....
38460	" " " Stud with two 391E.....
391E	" " " " Clamping Screw.....
46053	" Clamp with 46054 and two 1072F.....
46054	" " Thread Guide (two pieces).....
52819	" Guard (back).....
190D	" " " Screw.....
52820	" " (front) for $\frac{1}{32}$ in. to $\frac{5}{32}$ in. gauge.....
52821	" " " " $\frac{3}{16}$ in. to $\frac{1}{4}$ in. gauge.....
52822	" " " " $\frac{9}{32}$ in. to $\frac{3}{8}$ in. gauge.....
52823	" " " " $\frac{13}{32}$ in. to $\frac{1}{2}$ in. gauge.....
52824	" " " " $\frac{17}{32}$ in. to $\frac{9}{16}$ in. gauge.....
206D	" " " Screw.....

1072F	Needle Set Screw.....
17540	Presser Bar.....
38464	" " Bushing (lower).....
1133E	" " " " Set Screw.....
38456	" " " (upper).....
1133E	" " " " Set Screw.....
17541	" " Lifter.....
17542	" " " Hinge Pin.....
38466	" " Lifting Bracket with 453c and 892c.....
892C	" " " " Adjusting Screw.....
453C	" " " " Set Screw.....
38467	" " Spring (flat).....
38468	" " " Stud.....
26276	" Foot Hinge Pin.....
46086	" " Plate.....
46087	" " Shank.....
46088	Presser Foot (hinged) complete, for general work, Nos. 26276, 46086 and 46087.....
190D	Presser Foot Screw.....
574D	Pressure Regulating Thumb Screw.....
1539D	" " " " Lock Nut.....
46034	Slack Thread Controller.....
46035	" " " Clamp.....
190D	" " " " Screw.....
46007	" " Regulator.....
38473	" " " Bracket with 172c and 1823.....
172C	" " " " Clamping Screw.....
38474	" " " Bushing.....
1823	" " " Roller and Stud.....
50062D	" " " Screw.....
1620E	" " " " Nut.....
2102	Tension (under thread) Disc.....
1560C	" " " Regulating Thumb Nut.....
916F	" " " Screw Stud.....
10148	" " " Spring.....
17547	" " " Thread Guide.....
2102	" (upper thread) Disc.....
1560C	" " " Regulating Thumb Nut.....
916F	" " " Screw Stud.....
2103	" " " Spring.....
17547	" " " Thread Guide.....
38225	Thread (under) Eyelet (back).....
190D	" " " " Screw.....
38284	" " " (front).....
46049	" " Nipper Cam with 465c.....
465C	" " " Set Screw.....
38210	" " " Spring (lower).....
38211	" " " " (upper).....

46247	Thread (under) Nipper Spring (upper) Stop
176D	" " " " Screw
38475	" " Take-up with 465c
465C	" " " Set Screw
46047	" " " Staple
46040	" " " " Bracket with 910c
690D	" " " " " Screw
46041	" " " " Spring
190D	" " " " " Screw
910C	" " " " Stop Screw
38482	" " " Stripper
207F	" " " " Screw
38476	" " " Thread Guard (left)
207D	" " " " " " Screw
38477	" " " " " (right)
207D	" " " " " " Screw
38483	" (upper) Controller
206F	" " " Screw
46009	" " Eyelet
190D	" " " Screw
46010	" " Take-up with 457c
457C	" " " Set Screw
46089	Throat Plate for 46080
46090	" " " 46081
52825	" " " 52817
691F	" " Screw

ACCESSORIES

2015	Machine Cushion (rubber)
—	1¾ in. Wood Screw No. 16, to secure machine to table.
4718	Machine Rest (felt)
35859	Oiler with Cap and 35861
35860	" 35859, filled with oil
35861	" Spout, 3½ in. long
26026	Screw Driver
38487	Threading Wire
35095	Tweezers, 6 in.
8908	Wrench for 1520, 1620, 1706, 1708 and 1709
23766	" " 1508 and 1636

LAP SEAM FELLER PARTS

26269	Folder.....
18114	“ Slide.....
18116	“ “ Spring.....
8505	“ “ “ Rivet.....
35998	Holder with 8505 and 18116.....
1460H	“ Screw.....
26272	Lap Seam Feller (right hand) complete, Nos. 18114 and 26269.....
46060	Feed Dog, for $\frac{3}{32}$ in. to $\frac{1}{4}$ in. gauge.....
52724	“ “ (spiked teeth) for $\frac{3}{32}$ in. to $\frac{1}{4}$ in. gauge....
46062	“ “ for $\frac{9}{32}$ in. to $\frac{3}{8}$ in. gauge.....
52655	“ “ (spiked teeth) for $\frac{9}{32}$ in. to $\frac{3}{8}$ in. gauge.....
35990	Presser Foot Guide.....
233D	“ “ “ Screw.....
26276	“ “ Hinge Pin.....
35991	“ “ Plate.....
35992	“ “ Shank.....
35250	“ “ Spring.....
35993	Presser Foot (spring hinged) complete with left hand stationary guide, Nos. 233D, 26276, 35250 and 35990 to 35992.....
36347	Presser Foot Guide.....
233D	“ “ “ Screw.....
26276	“ “ Hinge Pin.....
36348	“ “ Plate.....
36349	“ “ Shank.....
35250	“ “ Spring.....
36350	Presser Foot (spring hinged) complete with right hand stationary guide, Nos. 233D, 26276, 35250 and 36347 to 36349.....
46061	Throat Plate for 46060 and 52724.....
46063	“ “ “ 46062 and 52655.....
36609	Lap Seam Feller (left hand) on Slide 18114.....
36599	“ “ “ (right hand) on Slide 18114.....
36600	Feed Dog, for $\frac{1}{4}$ in. to $\frac{3}{8}$ in. gauge.....
26276	Presser Foot Hinge Pin.....
36601	“ “ Plate.....
36602	“ “ Shank.....
36603	Presser Foot (hinged) complete, Nos. 26276, 36601 and 36602.....
36604	Throat Plate for 36600.....

FOOT LIFTER PARTS

6439 Chain, 36 in. to 45 in.

NOTE: When ordering No. 6439 give length required.

4879 Chain Connecting Link for 4885.
 23759 Lifting Lever.
 802D " " Hinge Screw.
 23761 " " Spring.
 1002D " " Stop Screw.
 4881 Treadle.
 4882 " Shaft.
 4883 " Spring.
 4884 " Stand.
 4885 Treadle complete, Nos. 4879, 4881 to 4884 and two
 wood screws 1 in. No. 16.
 23769 Foot Lifter complete, Nos. 802D, 1002D, 4885, 6439,
 23759 and 23761.

KNEE LIFTER PARTS

23759 Lifting Lever.
 23760 " " Connecting Rod for 23768.
 38384 " " " " " 38385.
 802D " " Hinge Screw.
 23761 " " Spring.
 1002D " " Stop Screw.
 2763 Rock Shaft.
 12242 " " Hanger with two wood screws 1 in. No. 10
 6335 " " Knee Arm.
 6336 Rock Shaft Knee Arm complete, Nos. 2766, 2767 and
 6335.
 2766 Rock Shaft Knee Arm Hub with 356c.
 356c " " " " Set Screw.
 2767 " " " Plate with 356c.
 356c " " " Set Screw.
 6337 " " Lifting Bracket with two 356c.
 7125 " " " " Hook.
 356c " " " " Set Screw.
 356c " " " " Set Screw.
 2770 " " Stop Dog with 356c.
 356c " " " " Set Screw.
 23767 Rock Shaft complete, Nos. 2763, 2770, 6336, 6337, 7125
 and two 12242.

- 23768 Knee Lifter complete (power table) Nos. 802D, 1002D,
23759 to 23761 and 23767.....
- 38385 Knee Lifter complete (bench stand) Nos. 802D, 1002D,
23759, 23761, 23767 and 38384.....
-

THREAD UNWINDER

FOR FOUR LARGE SPOOLS OR FOUR LARGE CONES OF THREAD

- 27623 Spool Pin.....
- 155c " " Set Screw.....
- 41534 " Rest.....
- 41535 " " 41534 with 1149c and four each 155c and
27623.....
- 1149c Spool Rest Set Screw.....
- 27940 " Stand with 453c.....
- 41514 " Weight, 4 in. diam., with 41515.....
- 41515 " " Centre Pin.....
- 27739 Thread Cone (wood).....
- 41633 " Guard with 208E and four 41569.....
- 41569 " " Eyelet.....
- 41637 " " Rod (lower).....
- 41638 " " " (upper).....
- 41639 " " " Coupling with two 456c.....
- 456c " " " " Set Screw.....
- 41640 Thread Guard Rod complete, 30 in. long, Nos. 41637 to
41639.....
- 453c Thread Guard Rod Set Screw.....
- 208E " " Screw.....
- 41537 Thread Unwinder complete, Nos. 27940, 41535, 41633,
41640, three wood screws 1 in. No. 12 and
four each 27739 and 41514.....

