



PARTS BOOK

SPS/E-BS1202 Series SPS/E-BR1202 Series

Electronically Controlled
Button Sewing Machine
(Direct Drive Type)

PME-130121

Information

A. Parts Book 구성 Structure of Part Book

①
②
③
④
⑤
⑥
⑦
⑧
⑨

A Arm, Bed & Machine Body Mechanism
 압. 베드 및 외장품 관계

Part No.	Parts No.	Name	Name of Parts	品名	Q'ty	Assembly No.
A-01	01-030C-001	Arm	压杆	压杆	1	
A-02	01-030C-002	Bed	压床	压床	1	
A-03	01-030C-003	Press Bed	压床板	压床板	1	
A-04	01-030C-004	Press Bed Support	压床板支撑	压床板支撑	1	
A-05	01-030C-005	Press Bed Head	压床板头	压床板头	1	
A-06	01-030C-006	Press Bed Tail	压床板尾	压床板尾	1	
A-07	01-030C-007	Press Bed Middle	压床板中	压床板中	1	
A-08	01-030C-008	Press Bed Foot	压床板脚	压床板脚	1	
A-09	01-030C-009	Press Bed Base	压床板底	压床板底	1	
A-10	01-030C-010	Press Bed Cover	压床板盖	压床板盖	1	
A-11	01-030C-011	Press Bed Head Cover	压床板头盖	压床板头盖	1	
A-12	01-030C-012	Press Bed Tail Cover	压床板尾盖	压床板尾盖	1	
A-13	01-030C-013	Press Bed Middle Cover	压床板中盖	压床板中盖	1	
A-14	01-030C-014	Press Bed Foot Cover	压床板脚盖	压床板脚盖	1	
A-15	01-030C-015	Press Bed Base Cover	压床板底盖	压床板底盖	1	
A-16	01-030C-016	Press Bed Head Support	压床板头支撑	压床板头支撑	1	
A-17	01-030C-017	Press Bed Tail Support	压床板尾支撑	压床板尾支撑	1	
A-18	01-030C-018	Press Bed Middle Support	压床板中支撑	压床板中支撑	1	
A-19	01-030C-019	Press Bed Foot Support	压床板脚支撑	压床板脚支撑	1	
A-20	01-030C-020	Press Bed Base Support	压床板底支撑	压床板底支撑	1	
A-21	01-030C-021	Press Bed Head Pad	压床板头垫	压床板头垫	1	
A-22	01-030C-022	Press Bed Tail Pad	压床板尾垫	压床板尾垫	1	
A-23	01-030C-023	Press Bed Middle Pad	压床板中垫	压床板中垫	1	
A-24	01-030C-024	Press Bed Foot Pad	压床板脚垫	压床板脚垫	1	
A-25	01-030C-025	Press Bed Base Pad	压床板底垫	压床板底垫	1	
A-26	01-030C-026	Press Bed Head Bolt	压床板头螺栓	压床板头螺栓	1	
A-27	01-030C-027	Press Bed Tail Bolt	压床板尾螺栓	压床板尾螺栓	1	
A-28	01-030C-028	Press Bed Middle Bolt	压床板中螺栓	压床板中螺栓	1	
A-29	01-030C-029	Press Bed Foot Bolt	压床板脚螺栓	压床板脚螺栓	1	
A-30	01-030C-030	Press Bed Base Bolt	压床板底螺栓	压床板底螺栓	1	
A-31	01-030C-031	Press Bed Head Nut	压床板头螺母	压床板头螺母	1	
A-32	01-030C-032	Press Bed Tail Nut	压床板尾螺母	压床板尾螺母	1	
A-33	01-030C-033	Press Bed Middle Nut	压床板中螺母	压床板中螺母	1	
A-34	01-030C-034	Press Bed Foot Nut	压床板脚螺母	压床板脚螺母	1	
A-35	01-030C-035	Press Bed Base Nut	压床板底螺母	压床板底螺母	1	
A-36	01-030C-036	Press Bed Head Washer	压床板头垫圈	压床板头垫圈	1	
A-37	01-030C-037	Press Bed Tail Washer	压床板尾垫圈	压床板尾垫圈	1	
A-38	01-030C-038	Press Bed Middle Washer	压床板中垫圈	压床板中垫圈	1	
A-39	01-030C-039	Press Bed Foot Washer	压床板脚垫圈	压床板脚垫圈	1	

①:관계 별 고유 코드

Unique code by mechanism

②:관계 별 고유 명칭

Unique name by mechanism

③:관계도

Explode view

④Ref.No.:파트별 고유 식별 번호

Unique identification number by part

⑤Parts No.:고유 제품 코드

Unique Product code

Ex)

구분 Category	Code	비고 remarks
구 부품 Old part	01-030C-1230	
신 부품 New Part	AS-000000-00	조(組) 파트 Set parts
	GP-000000-00	기구적 파트 Instrumental parts
	EP-000000-00	전기적 파트 Electrical parts

⑥Note:공지사항 표기 및 메모

Refers to notice and memo

⑦품

명:파트의 고유 품명

Name of Part:Unique name of parts

⑧Q'ty:파트의 수량

The number of parts

⑨Assembly no.:조(組) 파트의 식별 번호

Unique identification number by set part

Warning

1. 조에 속한 파트는 개별 조립 시 제품의 파손 또는 재봉 불량 발생될 수 있어 해당 파트에 대한 주문 시에는 조 품목으로만 구입이 가능합니다.
2. 본 책자는 Parts Book으로 제작되었으므로 매뉴얼로 사용 불가합니다.
3. 사전 예고 없이 사양이 변경 될 수도 있습니다.

1. The parts classified as ass'y items may cause damage to the machine or bad sewing when they are separately assembled. Hence, when they are ordered, they can be purchased as ass'y items only.
2. This is a parts book. It cannot be used as a manual.
3. Parts are Subject to change in Design Without Prior Notice.

Note

- 썬스타 제품의 부품은 아래 인터넷주소로 접속하시어 신청할 수 있습니다.
<http://www.sunstarcs.com>
- 가입된 회원께서는 썬스타 포탈 사이트에 로그인후 필요한 부품을 신청할 수 있습니다.
- 부품관리-발주관리-발주등록 항목에서 부품번호와 신청수량을 입력하여 등록하시면 발주가 됩니다.
- 부품번호를 모르시는 경우 파츠북 조회를 클릭하시고 사용하는 기종을 검색하여 선택하시면 해당 기종의 파츠북을 조회할 수 있습니다.
- 파츠북은 관계별로 구분되어 있으며 관계를 알고 있다면 부품 찾기가 용이합니다.
- You can make an order for the parts of Sunstar machine to connect internet address.
<http://www.sunstarcs.com>
- You can request for parts you want after login if you are a registered member.
- In parts Management - Order Management - Order Registration entry, you can place an order by entering the part number and quantity.
- If you don't know the parts number, click the parts book menu bar.
In a download list, you can read parts book by searching model you use.
- This parts book is classified by the mechanism, therefore you can find part easily.

Button S/M Model / 단추달이 봉기 모델

SPS/E-B□1202-01

Sunstar Pattern System
썬스타 패턴 시스템

Series
시리즈

Name of Bar Tacking Sewing Machine
바택 재봉기명
S : Shuttle Hook
R : Rotary Hook

Button Type 용도 구분

- 01 : Small-Size Button, Standard
Wiper Type
(기구식 와이퍼형, 소형 단추용)
- 02 : Large-Size Button, Standard
Wiper Type
(기구식 와이퍼형, 대형 단추용)
- 03 : Small & Large Size Button,
Wiper Type
(슬레노이드식 와이퍼형, 소형 및
대형 단추용)

NOTE : Parts are Subject to change in Design Without Prior Notice.

1. 조에 속한 파트는 개별 조립 시 제품의 파손 또는 재봉 불량에 발생될 수 있어 해당 파트에 대한 주문 시에는 조 품목으로만 구입이 가능합니다.
2. 본 책자는 Parts Book으로 제작되었으므로 매뉴얼로 사용 불가합니다.
1. The parts classified as ass'y items may cause damage to the machine or bad sewing when they are separately assembled. Hence, when they are ordered, they can be purchased as ass'y items only.
2. This is a parts book. It cannot be used as a manual.

CONTENTS


목 차

A	Machine Body Mechanism 두부 및 외장 관계	6
B	Upper Shaft Mechanism 상축 관계	10
C1	Lower Shaft Mechanism 하축 관계 (BS)	14
C2	Lower Shaft Mechanism 하축 관계 (BR)	16
D	Presser Plate Mechanism 누름판 관계	18
E	Thread Release & Thread Tension Mechanism 실 늦추기 및 실장력 관계	20
F	Wiper Mechanism 와이퍼 관계	22
G	Thread Trimmer Mechanism 사절 관계	24
H	X-Y Mechanism X-Y 관계	28
I	Button Clamp Mechanism 버튼 클램프 관계	30
J	Lubrication Mechanism 급유 관계	34
K	Table & Thread Stand Mechanism 테이블 및 실패꽃이 관계	36
L	Accessories Mechanism 액세서리 관계	38
M	Control Box Mechanism 컨트롤 박스 관계	40
N	Operation Box Mechanism 오퍼레이션 박스 관계	44
	Index 인덱스	46

A

Arm, Bed & Machine Body Mechanism

두부 및 외장 관계






Ref. No.	Parts No.	Note	Name of Parts	품 명	Q'ty		Applied Period
					BS	BR	
A-1	AS-008563-00		Arm, Bed	암, 베드(조)	1Set	-	
A-2	AS-008571-00		Arm, Bed	암, 베드(조)	-	1Set	
A-4	CMB-LA000700		Face Plate	면판	1	1	
A-5	CMB-FC000301		Face Plate Gasket	면판가스켓	1	1	Mar.08.12
A-6	DSC-BF001000		Screw(11/64"n=40)	침나사	3	7	
A-7	DPK-CB000201		Rubber Cap For Face Plate	면판고무마개	1	1	
A-8	CMB-LD000200		Caution Sticker	경고스티커	1	1	
A-9	CMB-LA000800		Take-up Lever Cover	실채기커버	1	1	
A-10	DSC-BJ000300		Screw(9/64"n=40)	톱카바나사(우)	1	1	
A-11	DSC-BJ000200		Screw(11/64"n=40)	톱카바한치고정나사	14	14	
A-12	CMB-LB000300		Bed Cover(R)	베드커버(우)	1	1	
A-13	CMB-FC000500		Bed Cover Gasket(R)	베드커버가스켓(우)	1	1	
A-14	CMB-LB000200		Bed Cover(L)	베드커버(좌)	1	1	
A-15	CMB-FC000400		Bed Cover Gasket(L)	베드커버가스켓(좌)	1	1	
A-16	DPK-CB000500		Oil Tank Rubber Cap	오일탱크고무마개	1	1	
A-17	AMB-PS000800		Thread Guide With Three Holes	세구멍실걸이(조)	1Set	1Set	
A-18	CMB-HK000101		Tread Guide(L)	면판실걸이(좌)	1	1	Dec.19.11
A-19	DSC-BA000100		Screw(9/64"n=40)	침나사	3	3	
A-20	CMB-HK000501		Thread Guide(R)	암실걸이	1	1	Dec.19.11
A-21	CMB-HK001200		Arm Thread Guide Ass'y	아암실안내걸이(조)	1	1	
A-22	CMB-HK000400		Thread Guide(L)	실안내(하)	1	1	
A-29	DPK-CB000101	M	Rubber Cap(L)	고무마개(대)	1	1	
A-30	DPK-CB000801		Arm Upper Part Rubber Cap	아암 상부 고무 마개	1	1	Aug.22.11
A-31	DPK-CB000300		Needle Bar Rubber Cap	바늘대 고무 마개	1	1	
A-32	DPK-CB000101		Rubber Cap(L)	고무마개(대)	4	4	
A-33	DPK-CB000700		Rubber Cap(S)	고무마개(소)	4	4	
A-34	CMB-FD000100		Bed Rubber	베드 고무	1	1	
A-35	DPK-CA000100		Robber Cap	고무 마개	4	4	
A-36	CMB-LD001300		Model Sticker(01)	모델 스티커(01)	1	-	
A-37	GP-017547-00		Model Sticker(02)	모델 스티커(02)	1	-	
A-38	GP-017548-00		Model Sticker(03)	모델 스티커(03)	1	-	
A-39	CMB-LD001100		Model Sticker(01)	모델 스티커(01)	-	1	
A-40	GP-017544-00		Model Sticker(02)	모델 스티커(02)	-	1	
A-41	GP-017545-00		Model Sticker(03)	모델 스티커(03)	-	1	
A-42	PTC-AH000100		Cable Holder(7N)	케이블 홀더(7N)	3	3	
A-43	CMB-LA000500		Top Cover	윗뚜껑	1	1	
A-44	ABW-PS000301		Bobbin Winder Ass'y	실감기(조)	1Set	1Set	Oct.05.12
A-45	ABW-PS000201		Bobbin Winder Base	실감기 베이스(조)	1Set	1Set	Feb.17.12
A-46	CBW-KZ000200		Bobbin Winder Shaft	실감기 구동축	1	1	
A-47	PSC-CB000200		Screw(M4)	침나사	1	1	
A-48	CBW-CP000100		Bobbin Winder	실감기 작동 풀리	1	1	
A-49	DSC-CB000300		Screw(11/64"n=40)	침나사	2	2	
A-50	CBW-FA000100		Bobbin Winder Action Ring	실감기 작동링	1	1	
A-51	CBW-FA000200		Bobbin Winder Shaft Rubber Ring	실감기 구동축 고무링	1	1	
A-52	CBW-CM000100		Bobbin Winder Lever	실감기 레버	1	1	
A-53	CBW-BJ000200		Bobbin Winder Adjusting Plate	실감기 조정판	1	1	
A-54	DSC-BF001800		Screw(1/8"n=40)	톱니 침나사	1	1	
A-55	DWS-AA000200		Washer	와셔	1	1	
A-56	CBW-KC000100		Bobbin Winder Lever Shaft	실감기 레버 축	1	1	
A-57	CBW-DZ000100		Bobbin Winder Adjusting Cam	실감기 조절 캠	1	1	
A-58	PSC-AC000200		Screw(M4xP0.7)	침나사	1	1	
A-59	PSR-AC000200		E-Ring(φ5)	E-링(호칭경 5)	2	2	
A-60	CBW-BJ000100		Bobbin Winder Action Plate	실감기 작동판	1	1	
A-61	CBW-BA000301		Bobbin Winder Action Body	실감기 작동체	1	1	Oct.05.12
A-62	DWS-AA000400		Washer	와셔	2	2	
A-63	DSP-AB000100		Bobbin Winder Spring	실감기 인장 스프링	1	1	

From the library of Superior Sewing Machine & Supply LLC - www.supsew.com

A

Arm, Bed & Machine Body Mechanism

두부 및 외장 관계




[illegible]

B

Upper Shaft Mechanism

상축 관계






Ref. No.	Parts No.	Note	Name of Parts	품 명	Q'ty		Applied Period
					BS	BR	
B-1	CUS-KG000300		Upper Shaft(BS)	상축	1	-	
B-2	CUS-KF000100		Upper Shaft(BR)	상축	-	1	
B-4	DWS-AA000100		Link Cam Washer	링크 캠 와셔	1	1	
B-5	DSC-BJ000100		Screw(15/64"n=28)	침나사	1	1	
B-6	DSC-BF000700		Screw(15/64"n=28)	침나사	4	4	
B-7	ATH-SM000300		Thread Take-Up Lever Ass'y	실채기	1Set	1Set	
B-8	ATH-PS000100		Thread Take-Up Lever	실채기	1	1	
B-9	CTH-CJ000300		Needle Bar Crank	바늘대 크랭크	1	1	
B-10	CTH-CB000300		Thread Take-Up Lever Crank	실채기 크랭크	1	1	
B-11	PBR-BA000600		Needle Bearing	실채기 니들베어링(KT8123NC3)	1	1	
B-12	PBR-BA000600		Needle Bearing	실채기 니들베어링(KT8123NC3)	1	1	
B-13	CTH-CC000100		Needle Bar Crank Rod	바늘대 크랭크 로드	1	1	
B-14	DSC-BF001600		Screw	바늘대 C/R 원나사	1	1	
B-15	CNB-BF000100		Needle Bar Holder	바늘대 잡이	1	1	
B-16	DSC-BF001500		Screw	바늘대 잡이나사	1	1	
B-17	DPN-AD000301		Thread Take-Up Pin	실채기 핀	1	1	Jun.18.12
B-18	DSC-CB000500		Screw(15/64"n=28)	캠 접촉 안내 고정나사	1	1	
B-19	CNB-CD000100		Needle Bar Guide Block	바늘대 안내 블록	1	1	
B-20	CNB-KA000200		Needle Bar	바늘대	1	1	
B-21	DBS-DA000200		Needle Bar Bushing(U)	바늘대 상붓심	1	1	
B-22	DSC-CB000500		Screw(11/64"n=40)	캠 접촉 카라 고정나사	2	2	
B-23	DBS-DA000300		Needle Bar Bushing(L)	바늘대 하붓심	1	1	
B-24	CNB-HK000200		Thread Guide For Needle Bar(H)	바늘대 실안내-후물용	1	1	
B-25	CNB-HK000300		Thread Guide For Needle Bar(M)	바늘대 실안내-일반용	1	1	
B-26	DSC-BF000100		Screw	침나사	1	1	
B-27	-		Needle(DP×17 #14)	바늘-후물용	1	1	
B-28	PBR-AA000200		Front Bearing (A)	상축 전 베어링 A(6904DDUNR)	1	1	
B-29	PBR-AA000300		Front Bearing (B)	상축 전 베어링 B(6904DDU)	1	1	
B-30	DCL-AB000100		Front Bearing Bushing	상축 전 베어링 붓심	1	1	
B-31	DSC-CB000400		Screw(1/4"n=40)	침나사	6	6	
B-32	CUS-CF000100		Bobbin Winder Driving Wheel	실감기 구동 휠	1	1	
B-33	DSC-CB000100		Screw	동메스축 B/S 고정나사	2	2	
B-34	DCL-AB000200		Middle Bearing Bushing	상축 중 베어링 붓심	1	1	
B-35	PBR-AA000400		Middle Bearing	상축 중 베어링(6004DDUNR)	1	1	
B-36	DCL-AB000300		Rear Bearing Bushing	상축 후 베어링 붓심	1	1	
B-37	PBR-AA000500		Rear Bearing	상축 후 베어링(6204DDUNR)	1	1	
B-38	DCR-AD000100		Coupling	커플링	1	1	
B-39	PSC-CB000100		Screw	침나사(M6×1.0 L=8)	8	8	
B-40	SFAM-550-001		Main Motor	주축모터	1	1	
B-41	PSC-AC000100		Screw	침나사(M5×0.8 L=25)	4	4	
B-42	DWS-CA000100		Spring Washer	스프링와셔(φ5)	4	4	
B-43	DWS-AA000600		Washer	평와셔(φ5)	4	4	
B-44	DGR-AC000100		Hand Pulley Gear A	핸드풀리 기어A	1	1	
B-45	DSC-CB000400		Screw	고정나사(15/64"n=28)	4	4	
B-46	DGR-AC000100		Hand Pulley Gear A	핸드풀리 기어A	1	1	
B-47	DBS-DA001700		Hand Pulley Bushing	핸드풀리 붓심	1	1	
B-48	DSC-CA000100		Screw	고정나사(15/64"n=28)	1	1	
B-49	CHP-KZ000300		Hand Pulley Shaft	핸드풀리 축	1	1	
B-50	CHP-CL000100		Hand Pulley Roller	핸드풀리 로울러	1	1	
B-51	DSC-FA000200		Hand Pulley Roller Hinge Pin	핸드풀리 로울러 단나사	1	1	
B-52	DSP-AA000100		Hand Pulley Spring	핸드풀리 스프링	1	1	
B-53	CHP-CP000200		Hand Pulley	핸드풀리	1	1	
B-54	DSC-BF000200		Screw	핸드풀리 침나사	1	1	
B-55	DGR-AB000100		Upper Shaft Driving Gear	상축 구동 기어	-	1	
B-56	DSC-CB000500		Screw(15/64"n=28)	침나사	-	3	
B-57	DGR-AB000200		Upper Shaft Driven Gear	상축 종동 기어	-	1	

From the library of Superior Sewing Machine & Supply LLC - www.supsew.com

B

Upper Shaft Mechanism

상축 관계




[illegible]

C1


Lower Shaft Mechanism

하축 관계 (BS)



From the library of Superior Sewing Machine & Supply LLC - www.supsew.com

[illegible]




[illegible]

D


Presser Plate Mechanism

누름판 관계




From the library of Superior Sewing Machine & Supply LLC - www.supsew.com

[illegible]



Thread Release & Thread Tension Mechanism

실 늦추기 및 실 장력 조절 관계



From the library of Superior Sewing Machine & Supply LLC - www.supsew.com


[illegible]




Wiper Mechanism

와이퍼 관계


SPS/E-BS(BR)1202-01
SPS/E-BS(BR)1202-02



SPS/E-BS(BR)1202-03




[illegible]





Ref. No.	Parts No.	Note	Name of Parts	품 명	Q'ty		Assembly No.
					BS	BR	
G-1	STT150-00001		Trimmer Solenoid Ass'y	사철 솔레노이드(조)	1	1	
G-2	CTT-BB000200		Auto Trimmer Solenoid Bracket	사철 솔레노이드 브라켓	1	1	
G-3	DSP-AA000800		Thread Trimmer Damping Spring	사철 솔레노이드 완충 스프링	1	1	
G-4	DSC-BJ000200		Screw(11/64"n=40)	침나사	2	2	
G-5	DPN-BB000600		Thread Trimming Solenoid Pin	사철 솔레노이드 핀	1	1	
G-6	PSC-CB000300		Screw(M5xL5)	침나사	1	1	
G-7	PSR-AC000200		E-Ring	E-링(φ5)	1	1	
G-8	CTT-BB000300		Thread Trimming Driving Lever Bracket	사철 구동 레버 브라켓	1	1	
G-9	DSC-BA000500		Screw(3/16"n=28)	사철 구동 레버 브라켓 고정나사	3	3	
G-10	CTT-CM000400		Thread Trimming Driving Lever	사철 구동 레버	1	1	
G-11	DSC-FA002400		Hinge Screw	사철 구동 레버 단나사	1	1	
G-12	DWS-AA002500		Washer	사철 구동 레버 와셔	1	1	
G-13	DSN-AA000400		Nut(15/64"n=28)	너트	1	1	
G-14	CTT-DG000100		Thread Trimming Cam	사철 캠	1	1	
G-15	DSC-CB000400		Screw(1/4"n=40)	침나사	2	2	
G-16	CTT-BJ000300		Thread Release Notch	실 낮추기 노치	1	1	
G-17	PSC-AC002100		Screw(M4xP0.7)	침나사	1	1	
G-18	CTT-KF000100		Thread Trimming Shaft	사철 축	1	1	
G-19	DCL-AA000900		Thread Trimming Shaft Collar	사철 축 카라	1	1	
G-20	DSC-CB000700		Screw	침나사	1	1	
G-22	DWS-AA002400		Link Cam Washer	링크 캠 와셔	1	1	
G-23	CTT-CB000400		Thread Trimming Driving Link Ass'y	사철 구동 링크(조)	1	1	
G-24	DSC-CB000500		Screw(15/64"n=28)	침나사	1	1	
G-25	DSP-AA001100		Thread Trimming Shaft Spring	사철 축 스프링	1	1	
G-26	CTT-CL000200		Thread Trimming Cam Roller	사철 캠 로울러	1	1	
G-27	DPN-AD000600		Pin	사철 캠 로울러축 핀	1	1	
G-28	DSN-AA000900		Nut(11/64"n=40)	너트	3	3	
G-29	CTT-CM000300		Thread Release Lever	실 낮추기 레버	1	1	
G-30	DSC-GA000100		Thread Release Lever Pin	실 낮추기 레버 핀	1	1	
G-31	DSN-AA000400		Nut(15/64"n=28)	너트	1	1	
G-32	CTT-CC000400		Thread Trimming Connecting Rod	사철 연결 로드	1	1	
G-33	PBR-GB000100		Rod End(R)	Rod End(우)	2	2	
G-34	PSN-AA000200		Nut(M5)	너트	2	2	
G-35	DSC-FD000100		Hinge Screw	사철 연결 로드 단나사	1	1	
G-36	DWS-AA000600		Washer	와셔	1	1	
G-37	CTT-CB000100		Thread Trimming Connecting Link	사철 연결 링크	1	1	
G-38	DPN-BC000100		Hinge Screw	사철 연결 링크 단나사	1	1	
G-39	CTT-CC000300		Thread Trimming Connecting Bar	사철 연결봉	1	1	
G-40	DSC-FB000300		Hinge Screw	사철 연결봉 단나사	1	1	
G-41	DSN-AA000800		Nut(3/16"n=28)	사철 연결봉 단나사용 너트	1	1	
G-42	CTT-BB000400		Thread Trimming Stopper Bracket	사철 스토퍼 브라켓	1	1	
G-43	DSC-BJ000300		Screw(9/64"n=40)	침나사	1	1	
G-44	PSC-AA000400		Link Stopper Screw	링크 스토퍼 나사	1	1	
G-45	DSP-AB000300		Return Spring	사철 연결봉 리턴 스프링	1	1	
G-46	DSC-HD000200		Spring Holder	스프링 걸이	1	1	
G-47	CTT-BJ000400		Needle Plate	침판	1	-	
G-48	DSC-BC000100		Screw(11/64"n=40)	침판 침나사	1	-	
G-49	CTT-GL000501		Needle Plate Cover(01)	침판 커버(01)	1	-	Jun.14.12
G-50	CTT-GL001501		Needle Plate Cover(02)	침판 커버(02)	1	-	Jun.14.12
G-51	CTT-GL001401		Needle Plate Cover(03)	침판 커버(03)	1	-	Jun.14.12
G-52	DSC-BB000300		Screw	침판 커버 침나사	1	-	
G-53	CTT-NB000200		Fixed Mes	고정 메스	1	-	
G-54	DSC-BF002000		Screw(9/64"n=40)	침나사	2	2	
G-55	ATT-PS000900		Moving Mes	동메스	1	-	
G-56	DSC-FA002300		Hinge Screw	동메스 단나사	1	-	
G-57	DWS-AA001700		Washer(t=0.4)	동메스 와셔(t0.4)	1	-	




[illegible]



X-Y Mechanism

X-Y 관계




[illegible]



Button Clamp Mechanism

버튼 클램프 관계

◎ Parts for Small-Size Button



From the library of Superior Sewing Machine & Supply LLC - www.supsew.com


Ref. No.	Parts No.	Note	Name of Parts	품 명	Q'ty		Assembly No.
					BS	BR	
I-1	CCP-BA000300		Button Clamp Holder Base	버튼 클램프 홀더 베이스	1	1	
I-2	PSC-AC000600		Screw	싱크로 베이스 고정 볼트	2	2	
I-3	PWS-AA000300		Washer	고정 와셔	2	2	
I-4	CCP-BB001001		Button Clamp Holder	버튼 클램프 홀더	1	1	
I-5	CCP-KC000400		Button Clamp Holder Base Shaft	버튼 클램프 홀더 축	1	1	
I-6	DSC-CB000700		Screw	캠 접촉 카라 고정나사	4	4	
I-7	DSC-HZ000100		Tension Adjusting Screw	장력 조정 나사	1	1	
I-8	DSN-CZ000100		Tension Adjusting Nut	장력 조정 너트	2	2	
I-9	DSP-AA001400		Tension Adjusting Spring	버튼 클램프 장력 조정 스프링	1	1	
I-10	CCP-CM001300		Button Clamp Holder Bar	버튼 클램프 홀더봉	1	1	
I-11	PSC-CB000100		Screw	캠 접촉 안내 고정나사	2	2	
I-12	DBS-DB000700		Button Clamp Roller	버튼 클램프 로울러	2	2	
I-13	DWS-AA000600		Washer	고정 와셔	1	1	
I-14	DSN-AA000600		Nut	오프너 너트	2	2	
I-15	AS-004969-02		Button Clamp Ass'y	버튼 클램프(조)	1	1	
I-16	CCP-BB001101		Button Clamp Bracket	버튼 클램프 브라켓	1	1	
I-17	DWS-AA000600		Washer	고정 와셔	2	2	
I-18	DSC-AA000900		Screw	침나사	2	2	
I-19	CCP-CM001401		Adjusting Plate	버튼 클램프 조정판	1	1	
I-20	DSC-FA004100		Stud	단나사	1	1	
I-21	DSC-FD000200		Screw	나사	1	1	
I-22	CCP-BL001000		Button Clamp(M)	버튼 클램프(중)	1	1	
I-23	CCP-CM001500		Button Clamp Lever	버튼 클램프 레버	1	1	
I-24	DSC-BF003300		Screw	조정 나사	1	1	
I-25	DSN-CZ000200		Nut	조정 너트	1	1	
I-26	CCP-BH000301		Button Clamp Lever Return Spring	버튼 클램프 레버 리턴 스프링	1	1	
I-27	CCP-BL000600		Button Clamp Bracket (L)	버튼 클램프 브라켓(좌)	1	1	
I-28	CCP-BL000801		Small Button Clamp(L)	소형 버튼 클램프(좌)	1	1	
I-29	GP-047656-00		Small Button Clamp Plate(L)	소형 버튼 클램프 받침(좌)	1	1	
I-30	23-047A-120B	S	Small Button Clamp Plate(L)	소형 버튼 클램프 받침(좌)	1	1	
I-31	DSC-BB000600		Screw	침나사	2	2	
I-32	DSP-AD000400		Small Button Clamp Plate Spring(L)	소형 버튼 클램프 판 스프링(좌)	1	1	
I-32-1	SP-000033-00		Medium Button Clamp Plate Spring(L)	중형 버튼 클램프 판 스프링(좌)	1	1	Aug.07.09
I-32-2	SP-000030-00		Large Button Clamp Plate Spring(L)	대형 버튼 클램프 판 스프링(좌)	1	1	Aug.07.09
I-33	DSC-BJ001500		Screw	홈 카바 고정판 고정나사(소)	2	2	
I-34	DSC-FG000200		Button Clamp Lever Pin	버튼 클램프 레버 핀	2	2	
I-35	PBR-AA000200		Bearing	베어링	2	2	
I-36	DSC-BJ001100		Screw	고정나사	2	2	
I-37	PWS-AA001600		Washer	와셔	2	2	
I-38	DSC-FA004200		Stud	단나사	2	2	
I-39	CCP-BL000700		Button Clamp Bracket (R)	버튼 클램프 브라켓(R)	1	1	
I-40	CCP-BL000901		Small Button Clamp(R)	소형 버튼 클램프(우)	1	1	
I-41	GP-047657-00		Small Button Clamp Plate(R)	소형 버튼 클램프 받침(우)	1	1	
I-42	23-050A-120B	S	Small Button Clamp Plate(R)	소형 버튼 클램프 받침(우)	1	1	
I-43	DSP-AD000500		Small Button Clamp Plate Spring (R)	소형 버튼 클램프 판 스프링(우)	1	1	
I-43-1	SP-000032-00		Medium Button Clamp Plate Spring(R)	중형 버튼 클램프 판 스프링(우)	1	1	Aug.07.09
I-43-2	SP-000031-00		Large Button Clamp Plate Spring(R)	대형 버튼 클램프 판 스프링(우)	1	1	Aug.07.09
I-44	CCP-BF000100		Spacer Spring Plate	스페이스 스프링 판	1	1	
I-45	DSC-AA001000		Screw	실 뉘추기 스토퍼 침나사	1	1	
I-46	DWS-AA000600		Fixed Washer	고정 와셔	1	1	
I-47	GP-014565-00		Spacer Spring	스페이스 스프링	1	1	
I-47-1	CCP-BH000400		Spacer Spring(Small)	스페이스 스프링(소형)	1	1	
I-49	DSC-BA001000		Screw	바늘대 후레임 실걸이 나사	1	1	
I-50	CCP-BH000200		Finger Guard	핑거 가드	1	1	
I-51	DSC-BF003100		Screw	가마잡이 나사	2	2	
I-52	CGA-GJ000801		Feed Plate(Small)	이송판(소)	1	1	Jun.29.10




Button Clamp Mechanism

버튼 클램프 관계

◎ Parts for Medium-Size Button



◎ Parts for Large-Size Button




From the library of Superior Sewing Machine & Supply LLC - www.supsew.com

[illegible]


J

Lubrication Mechanism

급유 관계



[illegible]




[illegible]




Accessories Mechanism

액세서리 관계




From the library of Superior Sewing Machine & Supply LLC - www.supsew.com

Ref. No.	Parts No.	Note	Name of Parts	품 명	Q'ty		Assembly No.
					BS	BR	
L-1	PTL-BA000100		Driver(L)	드라이버(大)	1	1	
L-2	PTL-BA000200		Driver(S, M)	드라이버(中)	1	1	
L-3	PTL-BA000200		Driver(S)	드라이버(小)	1	1	
L-4	PTL-CB000100		Spaner(9×10)	스페너	1	1	
L-5	CAC-JB000100		Oiler	오일 주유통	1	1	
L-6	CAC-JB000200		Oil	오일	1	1	
L-7	-	H	Needle(DP×17 #19)	바늘(DP×17 #19)	1	1	
L-8	-	M	Needle(DP×5 #16)	바늘(DP×5 #16)	1	1	
L-9	-	L,K	Needle(DP×5 #11)	바늘(DP×5 #11)	1	1	
L-10	07-224A-120H	BS	Bobbin	보빈	4	-	
L-11	PTL-AB000100		L-Shaped Wrench	L자 렌치(2mm)	1	1	
L-12	PTL-AB000300		L-Shaped Wrench	L자 렌치(2.5mm)	1	1	
L-13	PTL-AB000500		L-Shaped Wrench	L자 렌치(3mm)	1	1	
L-14	PTL-AB000400		L-Shaped Wrench	L자 렌치(4mm)	1	1	
L-15	PTL-AB000200		L-Shaped Wrench	L자 렌치(5mm)	1	1	
L-19	91-101C-120H		Head Cover	미싱 커버	1	1	
L-22	CHK-HB000300	BR	Bobbin	보빈	-	4	
L-23	CST-MF000400		Thread Stand Ass'y	실패꽃이 (조)	1Set	1Set	
L-24	CMB-BJ000100		Safety Plate	안전판	1	1	
L-25	CMB-BB000100		Safety Plate Bracket	안전판 브라켓	1	1	
L-26	CMB-BG000100		Safety Plate Holder	안전판 홀더	1	1	
L-27	DSC-FA000100		Safety Plate Hinge Screw	안전판 단나사	1	1	
L-28	DSN-AA000300		Nut(3/16"n=28)	너트	3	3	
L-29	DWS-AA000400		Washer	와셔	1	1	
L-30	DSP-AC000100		Safety Plate Spring	안전판 스프링	1	1	
L-31	DSC-HD000100		Safety Plate Spring Hook	안전판 스프링 걸이	1	1	
L-32	DSN-AA000200		Nut(3/16"n=28)	너트	1	1	
L-33	DSC-BJ000200		Screw(11/64"n=40)	톱카바힌지 고정나사	4	4	
L-34	DWS-AA000500		Washer	와셔	2	2	
L-35	CST-BB001000		Hinge	힌지쇠	2	2	
L-36	CST-FF000200		Hinge Rubber	힌지쇠 고무	2	2	
L-37	DPN-AD001400		Hinge Pin	힌지쇠 핀	2	2	
L-38	PSC-AA000500		Bolt(M6×t60)	볼트	5	5	
L-39	PSN-AA000900		Nut(M6)	너트	8	8	
L-40	PWS-AA000600		Washer	와셔	9	9	
L-41	GP-018728-00		Cushion Rubber	쿠션 고무	2	2	
L-42	CST-JA000200		Oil Pan	오일받이	1	1	
L-43	CMB-LA000600		Motor Cover	모터커버	1	1	
L-44	-		CD Manual	CD 매뉴얼	1	1	
L-45	-		Bag	단위 포장 봉투	1	1	
L-46	CST-JB000100		Oiler	오일 저장통	1	1	
L-47	CST-BA000100		Oil Supporter	오일통 받이	1	1	
L-48	CAC-MH000100		Accessory Bag	액세서리 봉투	1	1	
L-49	-		Nail	고정 못	10	10	
L-50	PSC-DD000100		Screw Nail	목나사	5	5	
L-51	CLB-JD000300		Oil Wick	오일받이 유심	1	1	
L-52	DSC-BF001100		Screw(11/64"n=40)	나사(11/64"n=40)	4	4	
L-53	ATT-PS000900	BS	Moving Mes	동메스	1	-	
L-54	CTT-NB000200	BS	Fixed Mes	고정메스	1	-	
L-55	CTT-NA000300	BR	Moving Mes	동메스	-	1	
L-56	CTT-NB000300	BR	Fixed Mes	고정메스	-	1	






Ref. No.	Parts No.	Note	Name of Parts	품 명	Q'ty		Applied Period
					BS	BR	
M-1	SSBT-0000041		Control Box Ass'y	콘트롤박스 (組)	1	1	
M-2	GP-008658-04		Box Body	박스바디	1	1	
M-3	GP-008671-00		Front Profile Upper	전면부 프로파일-상	1	1	
M-4	10-016S-CPT1		Screw(M4×L12)	전면부 프로파일-상 고정나사(M4×L12)	2	2	
M-5	GP-008672-01		Front Profile Lower	전면부 프로파일-하	1	1	
M-6	10-016S-CPT1		Screw(M4×L12)	전면부 프로파일-하 고정나사(M4×L12)	2	2	
M-7	GP-008673-00		Rear Profile Upper	후면부 프로파일-상	2	2	
M-8	10-016S-CPT1		Screw(M4×L12)	후면부 프로파일-상 고정나사(M4×L12)	4	4	
M-9	GP-008674-00		Rear Profile Lower	후면부 프로파일-하	1	1	
M-10	10-016S-CPT1		Screw(M4×L12)	후면부 프로파일-하 고정나사(M4×L12)	2	2	
M-11	GP-013686-00		Upper Frame	가로지지대-상	1	1	
M-12	10-004M-SW68		Screw(M3×L5)	가로지지대-상 고정나사(M3×L5)	4	4	
M-13	GP-013687-00		Lower Frame	가로지지대-하	1	1	
M-14	10-004M-SW68		Screw(M3×L5)	가로지지대-하 고정나사(M3×L5)	4	4	
M-15	GP-008662-04		Upper Cover	상면커버	1	1	Jan.18.13
M-16	EP-000112-00		Control Box Fan	콘트롤박스 Fan	1	1	
M-17	SC-000392-00		Screw(M4×L30)	콘트롤박스 Fan 고정나사(M4×L30)	4	4	
M-19	10-004M-SW68		Screw(M3×L5)	상면커버 고정나사(M3×L5)	6	6	
M-20	GP-008667-00		Insulation Plate	절연 플레이트	3	3	
M-21	BD-000372-01		Backplane Board	백플레인 보드	1	1	
M-22	10-020M-SW66		Screw(M3×L12)	Backplane Board 고정나사 (Set)(M3×L12)	18	18	
M-23	GP-013683-01		Rear Cover	후면커버	1	1	
M-24	10-004M-SW68		Screw(M3×L5)	후면커버 고정나사(M3×L5)	6	6	
M-25	EP-000039-00		SMPS	SMPS	1	1	
M-26	GP-008701-05		SMPS Bracket	SMPS 브라켓	1	1	
M-27	10-002S-SW66		Screw(M3×L8)	SMPS 고정나사(Set)(M3×L8)	5	5	
M-28	BD-000203-07		DDC Board	DDC 보드	1	1	
M-29	10-002S-SW66		Screw(M3×L8)	DDC 보드 고정나사(Set)(M3×L8)	6	6	
M-30	BD-000373-19		Digital Board	디지털 보드	1	1	Nov.01.10
	BD-000373-12		Digital Board	디지털 보드	1	1	Oct.13.08
M-31	GP-008668-06		Digital Board Bracket	디지털 보드 브라켓	1	1	Feb.03.10
M-32	GP-007198-00		SMD FET Radiator Sheet	디지털 보드 SMD FET 방열시트	1	1	
M-33	10-002S-SW66		Screw(M3×L8)	디지털 보드 고정나사(Set)(M3×L8)	4	4	
M-50	GP-000441-02		Main Board	주축보드	1	1	
M-51	GP-007203-00		Main Board Radiator	주축보드 방열판	1	1	
M-52	10-012M-PT10		Main Board Stud	주축보드 스테드(3-5-15)	3	3	
M-53	01-003S-2070		Screw(M4×L16)	브릿지다이오드 고정나사(Set)(M4×L16)	1	1	
M-54	10-003M-PT10		Screw(M4×L10)	IPM 고정나사(Set)(M4×L10)	2	2	
M-55	GP-008670-05		Main Board Bracket	주축보드 브라켓	1	1	Feb.03.10
M-56	10-002S-SW66		Screw(M3×L8)	주축보드 고정나사(Set)(M3×L8)	4	4	
M-57	07-004S-SM5S		Screw(M4×L10)	후면커버 접지나사(Set)(M4×L10)	1	1	
M-58	GP-008660-01		Cable Cover	케이블 커버	1	1	
M-59	10-003M-PT01		Screw(M4×L8)	케이블 커버 고정나사(M4×L8)	4	4	
M-60	GP-007711-00		Digital Board Sticker	디지털 보드 스티커	1	1	
M-61	GP-014311-00		Step Board Sticker	스텝 보드 스티커	1	1	
M-62	GP-014312-00		Main Board Sticker	주축 보드 스티커	1	1	
M-63	GP-047599-00		QC Passed Sticker	QC Passed 스티커	1	1	Nov.04.09
M-64	GP-017788-01		Voltage Sticker	전압시양 스티커	1	1	Dec.30.09
M-65	04-004S-AU10		Caution Sticker	전원 경고 스티커	1	1	
M-66	CA-000342-00		SMPS Connecting Cable1	SMPS 연결 케이블1(입력)	1	1	
M-67	CA-000343-00		SMPS Connecting Cable2	SMPS 연결 케이블2(출력)	1	1	
M-68	CA-000351-00		Jumper Cable	발판 점퍼 케이블	1	1	
M-69	04-001C-SE50		Screw(ST5×L16)	콘트롤박스 고정나사(A)	4	4	
M-70	01-001M-PT01		Screw(M6×L45)	콘트롤박스 고정나사(B)	4	4	
M-71	01-003S-SW66		Spring Washer(M6)	스프링 와셔	4	4	
M-72	01-004S-SW66		Washer(M6)	평 와셔	4	4	



[illegible]



[illegible]

From the library of Superior Sewing Machine & Supply LLC - www.supsew.com

Index

Parts No.	Name of Parts	Page	Ref.No.	Parts No.	Name of Parts	Page	Ref.No.	Parts No.	Name of Parts	Page	Ref.No.
01-001M-PT01	Screw(M6xL45)	41	M-70	AS-008563	Arm, Bed	7	A-1	CCP-KC0004	Button Clamp Holder Base Shaft	31	I-5
01-003S-2070	Screw(M4xL16)	41	M-53	AS-008571	Arm, Bed	7	A-2	CGA-GJ0008	Feed Plate(Small)	31	I-52
01-003S-SW66	Spring Washer(M6)	41	M-71	ATA-PS0002	Second Thread Tension Adjusting Ass'y	21	E-16	CHK-BD0001	Shuttle(L)	15	C1-24
01-004S-SW66	Washer(M6)	41	M-72	ATA-PS0007	Thread Tension Adjusting Ass'y(M)	21	E-2	CHK-BJ0003	Shuttle Upper Spring	15	C1-29
04-001C-SE50	Screw(ST5xL16)	41	M-69	ATH-PS0001	Thread Take-Up Lever	11	B-8	CHK-CH0001	Shuttle Race Adjusting Shaft	15	C1-27
04-004S-AU10	Caution Sticker	41	M-65	ATH-SM0003	Thread Take-Up Lever Ass'y	11	B-7	CHK-HA0003	Shuttle(M)	15	C1-39
06-001C-SE50	Screw(M4xL8)	43	M-81	ATT-PS0006	Thread Trimming Lever A	27	G-65	CHK-HA0004	Hook	17	C2-13
07-004S-SM5S	Screw(M4xL10)	41	M-57	ATT-PS0008	Thread Trimming Lever B	27	G-62	CHK-HB0002	Bobbin	15	C1-37
07-224A-120H	Bobbin	39	L-10	ATT-PS0009	Moving Mes	25	G-55	CHK-HB0003	Bobbin	17	C2-14
07S111S-306H	Crank Rod	15	C1-12	ATT-PS0009	Moving Mes	39	L-53	CHK-HB0003	Bobbin	39	L-22
09-012S-CE53	Earth Sticker	43	M-86	AWP-PS0004	Wiper Connecting Arm Ass'y	23	F-6	CHK-HC0002	Bobbin Case Ass'y	15	C1-36
10-002S-SW66	Screw(M3xL8)	41	M-27	AXY-SM0013	X-Sensor Assy	29	H-43	CHK-HC0005	Bobbin Case Ass'y	17	C2-15
10-002S-SW66	Screw(M3xL8)	41	M-29	AXY-SM0014	X-Sensor Assy	29	H-42	CHK-HH0002	Bobbin Stopper	27	G-76
10-002S-SW66	Screw(M3xL8)	41	M-33	BD-000203	DDC Board	41	M-28	CHK-HP0002	Shuttle Driver	15	C1-40
10-002S-SW66	Screw(M3xL8)	41	M-56	BD-000216	CF Card Board	45	N-6	CHP-CL0001	Hand Pulley Roller	11	B-50
10-002S-SW66	Screw(M3xL8)	43	M-78	BD-000217	O/P Board	45	N-3	CHP-CP0002	Hand Pulley	11	B-53
10-002S-SW66	Screw(M3xL8)	43	M-85	BD-000372	Backplane Board	41	M-21	CHP-KZ0003	Hand Pulley Shaft	11	B-49
10-003M-PT01	Screw(M4xL8)	41	M-59	BD-000373	Digital Board	41	M-30	CL-000224	Collar for Button Clamp Holder Shaft	33	I-83
10-003M-PT10	Screw(M4xL10)	41	M-54	BD-000374	PQ Step Board	43	M-84	CLB-BG0002	Cable Holder	35	J-26
10-004M-SW68	Screw(M3xL5)	41	M-12	BD-000375	XY Step Board	43	M-83	CLB-BG0003	Balance Lubrication Plate	35	J-10
10-004M-SW68	Screw(M3xL5)	41	M-14	CA-000339	Input Cable	43	M-87	CLB-BG0006	Cable Holder	35	J-18
10-004M-SW68	Screw(M3xL5)	41	M-19	CA-000340	Main Board 110V/220V Jumper Cable	43	M-88	CLB-BG0007	Shuttle Lubrication Plate	35	J-20
10-004M-SW68	Screw(M3xL5)	41	M-24	CA-000341	Fan Connecting Cable	43	M-89	CLB-BG0009	Needle Bar Crank Rod Lubrication Plate	35	J-8
10-012M-PT10	Main Board Stud	41	M-52	CA-000344	Operation Cable	45	N-4	CLB-BG0010	Holder	35	J-6
10-016S-CPT1	Screw(M4xL12)	41	M-4	CA-000357	Wiper solenoid Cable	23	F-34	CLB-BG0011	Oscillator Lubrication Plate	35	J-13
10-016S-CPT1	Screw(M4xL12)	41	M-6	CA-000395	CF Card Power Cable	45	N-7	CLB-BG0012	Crank Rod Lubrication Plate	35	J-33
10-016S-CPT1	Screw(M4xL12)	41	M-8	CA-000396	CF Card Cable	45	N-8	CLB-BG0013	Oil Felt Holder	35	J-28
10-016S-CPT1	Screw(M4xL12)	41	M-10	CA-000342	SMPS Connecting Cable1	41	M-66	CLB-BG0015	Oil Hose Holder	35	J-30
10-020M-SW66	Screw(M3xL12)	41	M-22	CA-000343	SMPS Connecting Cable2	41	M-67	CLB-BJ0001	Felt Plate	35	J-37
10-073S-3701	Screw(M3xL10)	43	M-76	CA-000351	Jumper Cable	41	M-68	CLB-BK0001	Block For Adjusting Oil	35	J-40
11-002S-5050	Fixing Screw For O/P Board	45	N-5	CAC-JB0001	Oiler	39	L-5	CLB-FA0001	Oil Window Rubber Ring	35	J-25
11-002S-5050	Fixing Screw For CF Card Board	45	N-9	CAC-JB0002	Oil	39	L-6	CLB-JD0003	Oil Wick	35	J-1
11-002S-5050	Fixing Screw For Rear Cove	45	N-13	CAC-MH0001	Accessory Bag	39	L-48	CLB-JD0003	Oil Wick	37	K-16
11-024A-12HA	Wiper Link	23	F-28	CBW-BA0003	Bobbin Winder Action Body	7	A-61	CLB-JD0003	Oil Wick	39	L-51
11-028A-12HA	Solenoid	23	F-24	CBW-BH0001	Bobbin Stopper	9	A-64	CLB-JF0001	Nipple	35	J-43
11-033A-12HA	Wiper Cover	23	F-31	CBW-BJ0001	Bobbin Winder Action Plate	7	A-60	CLB-JG0002	Oil Hose For J-18	35	J-17
11-035R-12HA	Rubber for Wiper Stopper	23	F-35	CBW-BJ0002	Bobbin Winder Adjusting Plate	7	A-53	CLB-JG0003	Oil Hose	35	J-2
15-026M-1000	Cable Tie	45	N-10	CBW-BN0001	Bobbin Stand	9	A-66	CLB-JG0004	Oil Hose	35	J-5
23-025A-120B	Small Button Clamp(L)-2mm	33	I-78	CBW-CM0001	Bobbin Winder Lever	7	A-52	CLB-JJ0001	Oil Window	35	J-23
23-032A-120B	Small Button Clamp(R)-2mm	33	I-79	CBW-CP0001	Bobbin Winder	7	A-48	CLB-JL0001	Lubrication Felt	35	J-34
23-047A-120B	Small Button Clamp Plate(L)	31	I-30	CBW-DZ0001	Bobbin Winder Adjusting Cam	7	A-57	CLB-JL0002	Balance Lubrication Felt	35	J-11
23-050A-120B	Small Button Clamp Plate(R)	31	I-42	CBW-FA0001	Bobbin Winder Action Ring	7	A-50	CLB-JL0007	Shuttle Lubrication Felt(L)	35	J-21
23-078A-120B	Spacer	33	I-72	CBW-FA0002	Bobbin Winder Shaft Rubber Ring	7	A-51	CLB-JL0008	Shuttle Lubrication Felt(S)	35	J-22
44S042S-306H	Oscillator Lubrication Felt	35	J-14	CBW-KC0001	Bobbin Winder Lever Shaft	7	A-56	CLB-JL0009	Felt	35	J-36
90A008S-811H	Accessory Case	37	K-6	CBW-KZ0002	Bobbin Winder Shaft	7	A-46	CLB-JL0010	Oil Return Felt A	35	J-3
91-001C-BT10	Urethane Washer	41	M-73	CCP-BA0003	Button Clamp Holder Base	31	I-1	CLB-JL0011	Arm Oil Return Felt	35	J-4
91-005A-SH51	Power Switch	37	K-23	CCP-BB0010	Button Clamp Holder	31	I-4	CLB-JL0012	Bed Oil Return Felt	35	J-16
91-101C-120H	Head Cover	39	L-19	CCP-BB0011	Button Clamp Bracket	31	I-16	CLB-JL0013	Needle Bar Crank Rod Lubrication Felt	35	J-9
ABW-PS0002	Bobbin Winder Base	7	A-45	CCP-BF0001	Spacer Spring Plate	31	I-44	CLB-JL0015	Felt	35	J-32
ABW-PS0003	Bobbin Winder Ass'y	7	A-44	CCP-BH0002	Finger Guard	31	I-50	CLB-JN0001	Oil Gauge	35	J-24
AHK-PS0001	Inner Hook Presser Shaft Ass'y	15	C1-33	CCP-BH0003	Button Clamp Lever Return Spring	31	I-26	CLS-KC0003	Lower Shaft	15	C1-2
ALS-PS0003	Lower Shaft Ass'y	15	C1-1	CCP-BH0004	Spacer Spring(Small)	31	I-47-1	CLS-KC0006	Lower Shaft	17	C2-1
AMB-PS0001	Safety Plate Ass'y	9	A-78	CCP-BJ0009	Dust Plate(L)	33	I-55	CLS-KH0002	Oscillator Shaft	15	C1-16
AMB-PS0003	Thread Tension Adjusting Ass'y	9	A-69	CCP-BJ0010	Dust Plate(R)	33	I-56	CMB-BB0001	Safety Plate Bracket	9	A-80
AMB-PS0006	Hook Cover Ass'y	15	C1-42	CCP-BL0006	Button Clamp Bracket (L)	31	I-27	CMB-BB0001	Safety Plate Bracket	39	L-25
AMB-PS0006	Hook Cover Ass'y	17	C2-17	CCP-BL0007	Button Clamp Bracket (R)	31	I-39	CMB-BG0001	Safety Plate Holder	9	A-81
AMB-PS0008	Thread Guide With Three Holes	7	A-17	CCP-BL0008	Small Button Clamp(L)	31	I-28	CMB-BG0001	Safety Plate Holder	39	L-26
APR-PS0002	Presser Plate Cam Ass'y	19	D-25	CCP-BL0009	Small Button Clamp(R)	31	I-40	CMB-BJ0001	Safety Plate	9	A-79
APR-PS0003	Presser Plate Lifting Lever Ass'y	19	D-8	CCP-BL0010	Button Clamp(M)	31	I-22	CMB-BJ0001	Safety Plate	39	L-24
AS-004697	Medium Button Clamp Ass'y	33	I-57	CCP-CM0013	Button Clamp Holder Bar	31	I-10	CMB-BJ0012	Feed Guide Plate	29	H-36
AS-004698	Large Button Clamp Ass'y	33	I-65	CCP-CM0014	Adjusting Plate	31	I-19	CMB-FC0003	Face Plate Gasket	7	A-5
AS-004969	Button Clamp Ass'y	31	I-15	CCP-CM0015	Button Clamp Lever	31	I-23	CMB-FC0004	Bed Cover Gasket(L)	7	A-15

From the library of Superior Sewing Machine & Supply LLC - www.supsew.com

Index

Parts No.	Name of Parts	Page	Ref.No.	Parts No.	Name of Parts	Page	Ref.No.	Parts No.	Name of Parts	Page	Ref.No.
CMB-FC0005	Bed Cover Gasket(R)	7	A-13	CTA-BJ0002	Presser Plate	21	E-9	CXF-BJ0012	X-Sensor Film	29	H-13
CMB-FC0012	Side Cover Gasket	9	A-92	CTA-HL0001	Thread Tension Disk	9	A-72	CXF-BJ0013	Y-Sensor Base	29	H-32
CMB-FD0001	Bed Rubber	7	A-34	CTA-HL0001	Thread Guide Disk	21	E-8	CXF-BJ0014	X-Motor Mounting Plate	29	H-22
CMB-HK0001	Tread Guide(L)	7	A-18	CTA-HM0001	Thread Tension Adjusting Shaft	21	E-4	CYF-BA0004	Cloth Feed Plate	29	H-35
CMB-HK0004	Thread Guide(L)	7	A-22	CTA-HM0002	Second Thread Tension Adjusting Shaft	21	E-17	CYF-BB0005	Y-Motor Bracket	29	H-29
CMB-HK0005	Thread Guide(R)	7	A-20	CTH-CB0003	Thread Take-Up Lever Crank	11	B-10	CYF-BF0001	Y-Feed Arm	29	H-4
CMB-HK0010	Thread Guide Plate	9	A-71	CTH-CC0001	Needle Bar Crank Rod	11	B-13	CYF-BJ0013	X-Sensor Base	29	H-30
CMB-HK0012	Arm Thread Guide Ass'y	7	A-21	CTH-CJ0003	Needle Bar Crank	11	B-9	CYF-BJ0014	Y-Sensor Film	29	H-7
CMB-HM0001	Thread Tension Adjusting Shaft	9	A-70	CTR-BB0001	Thread Release Link Bracket	21	E-40	CYF-BJ0015	Y-Driven Motor Mounting Plate	29	H-27
CMB-LA0005	Top Cover	7	A-43	CTR-BH0003	Thread Release Connecting Rod	21	E-22	CYF-BJ0020	Cloth Feed Support Plate	29	H-34
CMB-LA0006	Motor Cover	9	A-88	CTR-BJ0001	Thread Release Bar Guide	21	E-38	DBS-DA0002	Needle Bar Bushing(U)	11	B-21
CMB-LA0006	Motor Cover	39	L-43	CTR-BJ0004	Thread Release Adjusting Plate(A)	21	E-29	DBS-DA0003	Needle Bar Bushing(L)	11	B-23
CMB-LA0007	Face Plate	7	A-4	CTR-BJ0005	Thread Release Adjusting Plate(B)	21	E-30	DBS-DA0008	Lower Shaft Rear Bushing	15	C1-8
CMB-LA0008	Take-up Lever Cover	7	A-9	CTR-BJ0006	Thread Release Stopper	21	E-27	DBS-DA0017	Hand Pulley Bushing	11	B-47
CMB-LA0009	X-Driving Motor Cover	9	A-90	CTR-CA0002	Thread Release Link	21	E-20	DBS-DA0018	Y-Feed Bushing(F)	29	H-1
CMB-LB0002	Bed Cover(L)	7	A-14	CTR-CC0003	Thread Release Bar	21	E-36	DBS-DA0019	Y-Feed Bushing(R)	29	H-2
CMB-LB0003	Bed Cover(R)	7	A-12	CTT-BB0002	Auto Trimmer Solenoid Bracket	25	G-2	DBS-DA0020	Bushing for Presser Plate Lifting Lever	19	D-11
CMB-LB0018	Side Cover	9	A-91	CTT-BB0003	Thread Trimming Driving Lever Bracket	25	G-8	DBS-DA0021	Presser Plate Guide Bushing	19	D-6
CMB-LD0002	Caution Sticker	7	A-8	CTT-BB0004	Thread Trimming Stopper Bracket	25	G-42	DBS-DA0025	Lower Shaft Rear Bushing	17	C2-6
CMB-LD0011	Model Sticker(01)	7	A-39	CTT-BJ0003	Thread Release Notch	25	G-16	DBS-DA0026	Lower Shaft Front Bushing	17	C2-10
CMB-LD0013	Model Sticker(01)	7	A-36	CTT-BJ0004	Needle Plate	25	G-47	DBS-DB0007	Button Clamp Roller	31	I-12
CMB-NB0001	Bobbin Winder Mes	9	A-67	CTT-BJ0007	Needle Plate	27	G-69	DBS-DB0007	Button Clamp Holder Bushing	33	I-82
CNB-BF0001	Needle Bar Holder	11	B-15	CTT-CA0001	Moving Mes Link	27	G-61	DCL-AA0002	Oscillator Shaft Collar(L)	15	C1-18
CNB-CD0001	Needle Bar Guide Block	11	B-19	CTT-CA0003	Moving Mes Link	27	G-75	DCL-AA0003	Oscillator Shaft Collar(R)	15	C1-23
CNB-CD0001	X-Feed Block	29	H-11	CTT-CB0001	Thread Trimming Connecting Link	25	G-37	DCL-AA0004	Lower Shaft Collar	15	C1-10
CNB-HK0002	Thread Guide For Needle Bar(H)	11	B-24	CTT-CB0004	Thread Trimming Driving Link Ass'y	25	G-23	DCL-AA0004	Lower Shaft Collar	17	C2-8
CNB-HK0003	Thread Guide For Needle Bar(M)	11	B-25	CTT-CC0003	Thread Trimming Connecting Bar	25	G-39	DCL-AA0009	Thread Trimming Shaft Collar	25	G-19
CNB-KA0002	Needle Bar	11	B-	CTT-CC0004	Thread Trimming Connecting Rod	25	G-32	DCL-AB0001	Front Bearing Bushing	11	B-
CPR-BB0001	Driving Motor Base	19	D-23	CTT-CL0001	Thread Trimming Lever Ring	27	G-63	DCL-AB0002	Meddle Bearing Bushing	11	B-34
CPR-BB0002	Button Clamp Lifting Lever Holder	19	D-42	CTT-CL0002	Thread Trimming Cam Roller	25	G-26	DCL-AB0003	Rear Bearing Bushing	11	B-36
CPR-BJ0002	Cam Stopper	19	D-36	CTT-CM0003	Thread Release Lever	25	G-29	DCL-BA0001	Lower Shaft Rear Bushing Collar	15	C1-9
CPR-CA0001	Presser Plate Connecting Link	19	D-14	CTT-CM0004	Thread Trimming Driving Lever	25	G-10	DCL-BA0004	Lower Shaft Rear Bush Collar	17	C2-7
CPR-CD0001	Presser Plate Slide Block	19	D-7	CTT-DG0001	Thread Trimming Cam	25	G-14	DCL-BB0004	X-Feed Lever Gear Shaft Collar	29	H-15
CPR-CL0001	Roller for Presser Plate Shaft	19	D-3	CTT-GL0005	Needle Plate Cover(01)	25	G-49	DCR-AD0001	Coupling	11	B-38
CPR-CM0002	Presser Plate Lifting Driving Lever	19	D-17	CTT-GL0006	Needle Plate Cover(01)	27	G-70	DGR-AA0001	Lower Shaft Gear	15	C1-3
CPR-CM0003	Button Clamp Lifting Lever	19	D-45	CTT-GL0014	Needle Plate Cover(03)	25	G-51	DGR-AA0002	Oscillator	15	C1-19
CPR-KC0001	Presser Plate Cam Shaft	19	D-27	CTT-GL0015	Needle Plate Cover(02)	25	G-50	DGR-AA0008	X-Feed Lever Gear	29	H-9
CPR-KC0002	Presser Plate Lifting Lever Shaft	19	D-9	CTT-KF0001	Thread Trimming Shaft	25	G-18	DGR-AA0009	X-Drive Gear	29	H-20
CPR-KC0003	Cam Lever Shaft	19	D-18	CTT-NA0003	Fixed Mes	27	G-73	DGR-AA0010	Y-Drive Gear	29	H-26
CPR-KF0001	Presser Plate Shaft	19	D-1	CTT-NA0003	Fixed Mes	39	L-55	DGR-AA0011	Cam Driving Gear	19	D-34
CPW-BJ0021	Wiper	23	F-30	CTT-NB0002	Fixed Mes	25	G-53	DGR-AA0014	X-Feed Lever Gear	29	H-10
CST-BA0001	Oil Supporter	37	K-19	CTT-NB0002	Fixed Mes	39	L-54	DGR-AB0001	Upper Shaft Driving Gear	11	B-55
CST-BA0001	Oil Supporter	39	L-47	CTT-NB0003	Moving Mes	27	G-74	DGR-AB0002	Upper Shaft Driven Gear	11	B-57
CST-BB0010	Hinge	37	K-8	CTT-NB0003	Moving Mes	39	L-56	DGR-AC0001	Hand Pulley Gear A	11	B-44
CST-BB0010	Hinge	39	L-35	CUS-BB0003	Upper Shaft Gear Adjusting Bracket	13	B-72	DGR-AC0001	Hand Pulley Gear A	11	B-46
CST-FD0006	Support Rubber Safety Switch	37	K-25	CUS-BB0004	Timing Pulley Bracket	13	B-59	DGR-AF0004	Y-Feed Shaft	29	H-3
CST-FD0008	Cushion Rubber	37	K-21	CUS-BB0005	Bracket For Idler	13	B-65	DPK-CA0001	Robber Cap	7	A-35
CST-FF0002	Hinge Rubber	37	K-9	CUS-CF0001	Bobbin Winder Driving Wheel	11	B-32	DPK-CA0002	Rubber	35	J-44
CST-FF0002	Hinge Rubber	39	L-36	CUS-DA0003	Link Cam	13	B-78	DPK-CB0001	Rubber Cap(L)	7	A-29
CST-JA0002	Oil Pan	37	K-15	CUS-KC0002	Driving Shaft	13	B-63	DPK-CB0001	Rubber Cap(L)	7	A-32
CST-JA0002	Oil Pan	39	L-42	CUS-KF0001	Upper Shaft(BR)	11	B-2	DPK-CB0002	Rubber Cap For Face Plate	7	A-7
CST-JB0001	Oiler	37	K-18	CUS-KG0003	Upper Shaft(BS)	11	B-1	DPK-CB0003	Needle Bar Rubber Cap	7	A-31
CST-JB0001	Oiler	39	L-46	CWP-BH0003	Wiper Spring	23	F-36	DPK-CB0005	Oil Tank Rubber Cap	7	A-16
CST-LG0004	Table Ass'y	37	K-1	CWP-BJ0003	Wiper Ass'y	23	F-1	DPK-CB0007	Rubber Cap(S)	7	A-33
CST-LH0003	Table Stand Ass'y	37	K-2	CWP-BJ0004	Wiper Base Plate	23	F-21	DPK-CB0008	Arm Upper Part Rubber Cap	7	A-30
CST-MF0001	Thread Stand Ass'y	37	K-22	CWP-CA0005	Wiper Connecting Rod	23	F-4	DPK-CB0013	Bed Oil Wick Rubber Cap	35	J-27
CST-MF0001	Thread Stand Ass'y	39	L-23	CWP-CA0006	Wiper Link Plate	23	F-16	DPK-CC0001	Bed Oil Wick Rubber Cap	35	J-19
CTA-BA0001	Thread Tension Adjusting Body	21	E-3	CWP-CA0007	Wiper Link	23	F-15	DPL-BC0001	Driving Pulley	13	B-61
CTA-BD0001	Spring Cover	21	E-10	CWP-CA0008	Wiper Operating Link	23	F-14	DPL-BC0002	Lower Timing Pulley	17	C2-2
CTA-BD0002	Spring Cover	9	A-75	CWP-CC0001	Wiper Driving Lever	23	F-11	DPN-AA0013	Shaft for Adjusting Oil	17	C2-11
CTA-BJ0001	Thread Tension Spring Stopper	9	A-74	CWP-CH0001	Wiper Adjusting Pin	23	F-9				
CTA-BJ0001	Spring Stopper	21	E-13								

From the library of Superior Sewing Machine & Supply LLC - www.supsew.com

Index

Parts No.	Name of Parts	Page	Ref.No.	Parts No.	Name of Parts	Page	Ref.No.	Parts No.	Name of Parts	Page	Ref.No.
DPN-AD0003	Thread Take-Up Pin	11	B-17	DSC-BJ0002	Screw(11/64"n=40)	23	F-33	DSC-FA0042	Stud	31	I-38
DPN-AD0005	Thread Release Shaft	21	E-34	DSC-BJ0002	Screw(11/64"n=40)	25	G-4	DSC-FB0001	Crank Rod Hinge Screw	15	C1-14
DPN-AD0006	Pin	25	G-27	DSC-BJ0002	Screw	27	G-77	DSC-FB0002	Hinge Screw B	21	E-25
DPN-AD0012	X-Feed Lever Gear Shaft	29	H-14	DSC-BJ0002	Screw(11/64"n=40)	35	J-15	DSC-FB0003	Hinge Screw	25	G-40
DPN-AD0014	Hinge Pin	37	K-10	DSC-BJ0002	Screw(11/64"n=40)	39	L-32	DSC-FB0006	Roller Stud for Presser Plate Shaft	19	D-2
DPN-AD0014	Hinge Pin	39	L-37	DSC-BJ0003	Screw(9/64"n=40)	7	A-10	DSC-FD0001	Hinge Screw	25	G-35
DPN-AD0015	Tension Release Pin	21	E-44	DSC-BJ0003	Screw(9/64"n=40)	21	E-39	DSC-FD0002	Screw	31	I-21
DPN-AD0017	Driving Cam Roller Shaft	19	D-19	DSC-BJ0003	Screw(9/64"n=40)	25	G-43	DSC-FF0004	Y-Feed Hinge Stud Screw	29	H-6
DPN-AD0020	X-Feed Block Shaft	29	H-12	DSC-BJ0003	Screw (9/64"n=40)	35	J-29	DSC-FG0001	Thread Lever Shaft	27	G-64
DPN-AD0020	X-Feed Block Shaft	29	H-38	DSC-BJ0004	Screw(11/64"n=40)	15	C1-13	DSC-FG0002	Button Clamp Lever Pin	31	I-34
DPN-AD0024	Feed Regulator Connecting Lod Pin	23	F-7	DSC-BJ0008	Screw(11/64"n=40)	27	G-67	DSC-GA0001	Thread Release Lever Pin	25	G-30
DPN-AD0025	Button Clamp Lifting Lever Shaft	19	D-46	DSC-BJ0011	Screw	31	I-36	DSC-HD0001	Safety Plate Spring Hook	9	A-86
DPN-BB0006	Thread Trimming Solenoid Pin	25	G-5	DSC-BJ0011	Screw(9/64"n=40)	35	J-7	DSC-HD0001	Safety Plate Spring Hook	39	L-31
DPN-BC0001	Hinge Screw	25	G-38	DSC-BJ0012	Screw(11/64"n=40)	29	H-16	DSC-HD0002	Spring Holder	25	G-46
DSC-AA0009	Screw	31	I-18	DSC-BJ0015	Screw	31	I-33	DSC-HZ0001	Tension Adjusting Screw	31	I-7
DSC-AA0010	Screw	31	I-45	DSC-BJ0022	Screw	23	F-37	DSN-AA0002	Nut(3/16"n=28)	9	A-87
DSC-AC0001	Screw(M5, L=12)	29	H-23	DSC-CA0001	Screw	11	B-48	DSN-AA0002	Nut(3/16"n=28)	21	E-24
DSC-BA0001	Screw(9/64"n=40)	7	A-19	DSC-CA0001	Screw(15/64"n=28)	19	D-22	DSN-AA0002	Nut(3/16"n=28)	39	L-32
DSC-BA0005	Screw(3/16"n=28)	25	G-9	DSC-CA0002	Screw(9/64"n=40)	21	E-5	DSN-AA0003	Nut(3/16"n=28)	9	A-83
DSC-BA0007	Screw(3/16"n=32)	29	H-8	DSC-CA0007	Screw for Adjusting Oil	17	C2-12	DSN-AA0003	Nut	21	E-43
DSC-BA0008	Screw(15/64"n=28)	19	D-37	DSC-CB0001	Screw	11	B-33	DSN-AA0003	Nut	23	F-38
DSC-BA0010	Screw	31	I-49	DSC-CB0003	Screw(11/64"n=40)	7	A-49	DSN-AA0003	Nut(3/16"n=28)	39	L-28
DSC-BB0003	Screw	25	G-52	DSC-CB0003	Screw(11/64"n=40)	19	D-35	DSN-AA0004	Nut(15/64"n=28)	25	G-13
DSC-BB0006	Screw	31	I-31	DSC-CB0004	Screw(1/4"n=40)	11	B-31	DSN-AA0004	Nut(15/64"n=28)	25	G-31
DSC-BC0001	Screw(11/64"n=40)	25	G-48	DSC-CB0004	Screw	11	B-45	DSN-AA0005	Nut(1/4"n=40)	15	C1-15
DSC-BC0001	Screw(11/64"n=40)	29	H-37	DSC-CB0004	Screw	15	C1-47	DSN-AA0006	Nut	31	I-14
DSC-BC0002	Screw(1/8"n=40)	9	A-68	DSC-CB0004	Screw(1/4"n=40)	25	G-15	DSN-AA0007	Nut(15/64"n=28)	9	A-77
DSC-BF0001	Screw	11	B-26	DSC-CB0004	Screw(1/4"n=40)	29	H-5	DSN-AA0008	Nut(3/16"n=28)	25	G-41
DSC-BF0002	Screw	11	B-54	DSC-CB0005	Screw(15/64"n=28)	11	B-18	DSN-AA0009	Nut(11/64"n=40)	19	D-5
DSC-BF0006	Screw(3/16"n=28)	23	F-8	DSC-CB0005	Screw(11/64"n=40)	11	B-22	DSN-AA0009	Nut(11/64"n=40)	25	G-28
DSC-BF0006	Screw (3/16"n=28)	35	J-35	DSC-CB0005	Screw(15/64"n=28)	11	B-56	DSN-CD0001	Thread Tension Nut	9	A-76
DSC-BF0007	Screw(15/64"n=28)	11	B-6	DSC-CB0005	Screw(15/64"n=28)	13	B-58	DSN-CD0001	Thread Adjusting Nut	21	E-14
DSC-BF0008	Screw(15/64"n=28)	15	C1-25	DSC-CB0005	Screw(15/64"n=28)	13	B-62	DSN-CD0002	Second Thread Adjusting Nut	21	E-19
DSC-BF0009	Screw(11/64"n=40)	15	C1-26	DSC-CB0005	Screw (15/64"n=28)	15	C1-17	DSN-CZ0001	Tension Adjusting Nut	31	I-8
DSC-BF0010	Screw(11/64"n=40)	7	A-6	DSC-CB0005	Screw(15/64"n=28)	17	C2-3	DSN-CZ0002	Nut	31	I-25
DSC-BF0010	Screw(11/64"n=40)	23	F-2	DSC-CB0005	Screw(15/64"n=28)	19	D-47	DSP-AA0001	Hand Pulley Spring	11	B-52
DSC-BF0010	Screw(11/64"n=40)	23	F-25	DSC-CB0005	Screw(15/64"n=28)	25	G-24	DSP-AA0006	Inner Hook Spring	15	C1-35
DSC-BF0011	Screw(11/64"n=40)	9	A-89	DSC-CB0005	Screw(15/64"n=28)	29	H-21	DSP-AA0008	Thread Trimmer Damping Spring	25	G-3
DSC-BF0011	Screw(11/64"n=40)	39	L-52	DSC-CB0006	Screw	15	C1-5	DSP-AA0011	Thread Trimming Shaft Spring	25	G-25
DSC-BF0012	Screw(11/64"n=40)	9	A-93	DSC-CB0007	Screw	19	D-12	DSP-AA0013	Spring for Adjusting Oil	17	C2-22
DSC-BF0012	Screw(3/16"n=28)	21	E-35	DSC-CB0007	Screw(M5)	19	D-13	DSP-AA0014	Tension Adjusting Spring	31	I-9
DSC-BF0013	Screw(3/32"n=56)	15	C1-30	DSC-CB0007	Screw(9/64"n=40)	23	F-10	DSP-AB0001	Bobbin Winder Spring	7	A-63
DSC-BF0013	Screw	35	J-38	DSC-CB0007	Screw	25	G-20	DSP-AB0002	Thread Release Return Spring	21	E-31
DSC-BF0014	Screw(9/64"n=28)	23	F-18	DSC-CB0007	Screw	31	I-6	DSP-AB0003	Return Spring	25	G-45
DSC-BF0015	Screw	11	B-16	DSC-CB0007	Screw(M5xP0.8)	37	K-11	DSP-AB0005	Wiper Spring	23	F-12
DSC-BF0016	Screw	11	B-14	DSC-CB0008	Screw (11/64"n=40)	15	C1-11	DSP-AB0006	Presser Plate Return Spring	19	D-16
DSC-BF0017	Screw	9	A-65	DSC-CB0008	Screw (11/64"n=40)	17	C2-9	DSP-AC0001	Safety Plate Spring	9	A-85
DSC-BF0018	Screw(1/8"n=40)	7	A-54	DSC-FA0001	Safety Plate Hinge Screw	9	A-82	DSP-AC0001	Safety Plate Spring	39	L-30
DSC-BF0019	Screw(3/16"n=28)	21	E-28	DSC-FA0001	Safety Plate Hinge Screw	39	L-27	DSP-AD0001	Hook Cover Plate Spring A	15	C1-43
DSC-BF0020	Screw(9/64"n=40)	25	G-54	DSC-FA0002	Hand Pulley Roller Hinge Pin	11	B-51	DSP-AD0001	Hook Cover Plate Spring A	17	C2-18
DSC-BF0021	Screw	27	G-66	DSC-FA0014	Hinge Screw	21	E-37	DSP-AD0002	Hook Cover Plate Spring B	15	C1-44
DSC-BF0022	Screw(11/64"n=28)	21	E-32	DSC-FA0014	Stud Screw	23	F-13	DSP-AD0002	Hook Cover Plate Spring B	17	C2-19
DSC-BF0024	Screw(9/64"n=40)	35	J-12	DSC-FA0015	Thread Release Link Hinge Screw	21	E-21	DSP-AD0004	Small Button Clamp Plate Spring(L)	31	I-32
DSC-BF0025	Screw (11/64"n=40)	35	J-42	DSC-FA0016	Hinge Screw A	21	E-23	DSP-AD0005	Small Button Clamp Plate Spring(R)	31	I-43
DSC-BF0030	Screw(M6)	19	D-24	DSC-FA0023	Hinge Screw	25	G-56	DSP-BA0001	Thread Tension Adjusting Spring(H)	21	E-11
DSC-BF0031	Screw	31	I-51	DSC-FA0024	Hinge Screw	25	G-11	DSP-BA0002	Second Thread Tension Adjusting Spring	21	E-18
DSC-BF0033	Screw	31	I-24	DSC-FA0026	Screw	23	F-22	DSP-BA0003	Thread Tension Spring	9	A-73
DSC-BH0001	Screw (M4xP0.7, L=4.5)	35	J-31	DSC-FA0027	Wiper Link Plate Stud Screw	23	F-17	DSP-BA0010	Thread Tension Adjusting Spring(M)	21	E-12
DSC-BJ0001	Screw(15/64"n=28)	11	B-5	DSC-FA0028	Stud Screw for Presser Plate Driving Lever	19	D-15	DSP-BB0001	Thread Take-Up Spring(H)	21	E-6
DSC-BJ0002	Screw(11/64"n=40)	7	A-11	DSC-FA0036	Idle Shaft	13	B-68	DWS-AA0001	Link Cam Washer	11	B-4
DSC-BJ0002	Screw(11/64"n=40)	15	C1-46	DSC-FA0041	Stud	31	I-20	DWS-AA0002	Washer	7	A-55
DSC-BJ0002	Screw(11/64"n=40)	17	C2-21					DWS-AA0004	Washer	7	A-62

Index

Parts No.	Name of Parts	Page	Ref.No.	Parts No.	Name of Parts	Page	Ref.No.	Parts No.	Name of Parts	Page	Ref.No.
DWS-AA0004	Washer	9	A-84	GP-014836	X-Sensor(TLP1253)	29	H-31	PSC-AC0006	Screw(M5)	21	E-15
DWS-AA0004	Washer	39	L-29	GP-014837	Y-Sensor(TLP1252)	29	H-33	PSC-AC0006	Screw	31	I-2
DWS-AA0005	Washer	39	L-34	GP-016485	Small Button Clamp Plate Spring(L)-2mm	33	I-80	PSC-AC0010	Screw(M5xL20)	29	H-41
DWS-AA0006	Washer	11	B-43	GP-016486	Small Button Clamp Plate Spring(R)-2mm	33	I-81	PSC-AC0014	Screw(11/64" n=40)	23	F-27
DWS-AA0006	Washer	19	D-4	GP-016487	Medium Button Clamp Plate Spring(L)	33	I-74	PSC-AC0020	Screw(M6xP=1 L=20)	13	B-60
DWS-AA0006	Washer	21	E-33	GP-016488	Medium Button Clamp Plate Spring(R)	33	I-75	PSC-AC0020	Screw(M6)	29	H-28
DWS-AA0006	Washer	23	F-19	GP-016489	Large Button Clamp Plate Spring(L)	33	I-76	PSC-AC0021	Screw(M4xP0.7)	25	G-17
DWS-AA0006	Washer	25	G-36	GP-016490	Large Button Clamp Plate Spring(R)	33	I-77	PSC-AC0022	Screw(M4, L=10)	29	H-18
DWS-AA0006	Washer	27	G-68	GP-017101	Medium Button Clamp(L)	33	I-58	PSC-AC0024	Screw(M4, L=16)	21	E-41
DWS-AA0006	Washer	31	I-13	GP-017162	Medium Button Clamp(R)	33	I-61	PSC-AC00340	Screw(M6xL20)	13	B-76
DWS-AA0006	Washer	31	I-17	GP-017163	Large Button Clamp(L)	33	I-66	PSC-AC0037	Screw(M5xL20)	13	B-73
DWS-AA0006	Fixed Washer	31	I-46	GP-017164	Large Button Clamp(R)	33	I-69	PSC-AC0038	Screw	13	B-67
DWS-AA0007	Washer	15	C1-20	GP-017544	Model Sticker(02)	7	A-40	PSC-BA0003	Screw(M4 L=10)	19	D-33
DWS-AA0009	Lower Shaft Washer	15	C1-6	GP-017545	Model Sticker(03)	7	A-41	PSC-BD0001	Screw	33	I-54
DWS-AA0009	Lower Shaft Washer	17	C2-4	GP-017547	Model Sticker(02)	7	A-37	PSC-CB0001	Screw	11	B-39
DWS-AA0011	Washer	23	F-32	GP-017548	Model Sticker(03)	7	A-38	PSC-CB0001	Screw(M6xL6)	19	D-26
DWS-AA0012	Washer	21	E-26	GP-017788	Voltage Sticker	41	M-64	PSC-CB0001	Screw	31	I-11
DWS-AA0016	Washer	29	H-19	GP-017885	Feed Plate(Large)	33	I-73	PSC-CB0002	Screw(M4)	7	A-47
DWS-AA0017	Washer(t=0.4)	25	G-57	GP-017886	Feed Plate(Medium)	33	I-64	PSC-CB0003	Screw(M5xL5)	25	G-6
DWS-AA0018	Washer(t=0.5)	27	G-58	GP-018079	Oil Shield Cap	23	F-20	PSC-CB0004	Screw (M8xL8)	35	J-41
DWS-AA0024	Link Cam Washer	25	G-22	GP-018702	Cushion Rubber	39	L-41	PSC-CB0006	Screw	33	I-84
DWS-AA0025	Washer	25	G-12	GP-026059	Shuttle Race Ring(M)	15	C1-38	PSC-DD0001	Screw Nail	39	L-50
DWS-AA0026	Bearing Washer	19	D-21	GP-027061	Fan Bracket	43	M-77	PSN-AA0002	Nut(M5)	25	G-34
DWS-AA0028	Washer(t=0.6)	27	G-59	GP-033637	Needle Plate Cover(03)	27	G-72	PSN-AA0008	Nut(M4)	29	H-40
DWS-AA0039	Washer(t=0.7)	27	G-60	GP-036134	Halley Coil	33	I-85	PSN-AA0009	Nut(M6)	37	K-13
DWS-CA0001	Spring Washer	11	B-42	GP-036723	Thread Take-Up Spring(M)	21	E-7	PSN-AA0009	Nut(M6)	39	L-39
DWS-CA0001	Spring Washer	21	E-42	GP-038536	Wick	35	J-39	PSN-AA0013	Nut(M6xP=1)	13	B-70
EP-000039	SMPS	41	M-25	GP-045164	Needle Plate Cover(02)	27	G-71	PSR-AC0001	E-Ring	15	C1-21
EP-000112	Control Box Fan	41	M-16	GP-047599	QC Passed Sticker	41	M-63	PSR-AC0002	E-Ring(φ5)	7	A-59
GP-000441	Main Board	41	M-50	GP-047656	Small Button Clamp Plate(L)	31	I-29	PSR-AC0002	E-Ring	25	G-7
GP-007198	SMD FET Radiator Sheet	41	M-32	GP-047657	Small Button Clamp Plate(R)	31	I-41	PSR-AC0003	Stop Ring	23	F-3
GP-007203	Main Board Radiator	41	M-51	PBR-AA0002	Front Bearing (A)	11	B-28	PSR-AC0004	E-Ring	15	C1-34
GP-007711	Digital Board Sticker	41	M-60	PBR-AA0002	Bearing	31	I-35	PSR-AC0005	Stop Ring	19	D-28
GP-008203	Hinge Screw for Wiper Link	23	F-29	PBR-AA0003	Front Bearing (B)	11	B-29	PSR-AC0008	Stop Ring	19	D-10
GP-008658	Box Body	41	M-2	PBR-AA0004	Middle Bearing	11	B-35	PTC-AH0001	Cable Holder(7N)	7	A-42
GP-008660	Cable Cover	41	M-58	PBR-AA0005	Rear Bearing	11	B-37	PTL-AB0001	L-Shaped Wrench	39	L-11
GP-008662	Upper Cover	41	M-15	PBR-AA0008	Cam Roller Bearing	19	D-20	PTL-AB0002	L-Shaped Wrench	39	L-15
GP-008667	Insulation Plate	41	M-20	PBR-AA0011	Cam Shaft Supporting Bearing	19	D-29	PTL-AB0003	L-Shaped Wrench	39	L-12
GP-008668	Digital Board Bracket	41	M-31	PBR-AA0018	Driving Shaft Bearing	13	B-64	PTL-AB0004	L-Shaped Wrench	39	L-14
GP-008670	Main Board Bracket	41	M-55	PBR-AA0019	Idle Bearing	13	B-69	PTL-AB0005	L-Shaped Wrench	39	L-13
GP-008671	Front Profile Upper	41	M-3	PBR-BA0002	Needle Roller Bearing	15	C1-28	PTL-BA0001	Driver(L)	39	L-1
GP-008672	Front Profile Lower	41	M-5	PBR-BA0003	Needle bearing	15	C1-7	PTL-BA0002	Driver(S, M)	39	L-2
GP-008673	Rear Profile Upper	41	M-7	PBR-BA0004	Needle bearing	17	C2-5	PTL-BA0002	Driver(S)	39	L-3
GP-008674	Rear Profile Lower	41	M-9	PBR-BA0006	Needle Bearing	11	B-11	PTL-CB0001	Spaner(9x10)	39	L-4
GP-008701	SMPS Bracket	41	M-26	PBR-BA0006	Needle Bearing	11	B-12	PWS-AA0003	Washer	19	D-43
GP-011450	Front Cover	45	N-2	PBR-GB0001	Rod End(R)	25	G-33	PWS-AA0003	Washer	31	I-3
GP-011451	Rear Cover	45	N-12	PBT-BC0002	Timing Belt	13	B-71	PWS-AA0003	Washer	33	I-53
GP-011452	CF Card Cover	45	N-11	PPK-BA0002	Oscillator O-Ring	15	C1-22	PWS-AA0006	Washer	37	K-14
GP-011454	Membrane Switch	45	N-1	PPK-BA0003	O-Ring	19	D-48	PWS-AA0006	Washer	39	L-40
GP-011455	Stand For OP Box	45	N-14	PPK-BA0003	O Ring	23	F-5	PWS-AA0009	Washer	13	B-75
GP-012587	Wiper Crank	23	F-26	PPN-AA0001	Pin	15	C1-4	PWS-AA0009	Washer	29	H-24
GP-012588	Wiper Base	23	F-23	PPN-AF0003	Spring Pin (φ2xI9.8)	15	C1-45	PWS-AA0016	Washer	31	I-37
GP-012617	Board Bracket Handle	43	M-75	PPN-AF0003	Spring Pin (φ2xI9.8)	17	C2-20	PWS-CA0008	Spring Washer	13	B-74
GP-013658	Step Board Radiator	43	M-80	PSC-AA0004	Link Stopper Screw	25	G-44	PWS-CA0010	Washer	13	B-77
GP-013683	Rear Cover	41	M-23	PSC-AA0005	Bolt(M6xI60)	37	K-12	SC-000392	Screw(M4xL30)	41	M-17
GP-013684	Step Board Bracket	43	M-79	PSC-AA0005	Bolt(M6xI60)	39	L-38	SC-000410	Fixing Screw For OP Box	45	N-15
GP-013686	Upper Frame	41	M-11	PSC-AA0008	Screw	13	B-66	SC-000411	Fixing Screw For OP Box Stand	45	N-16
GP-013687	Lower Frame	41	M-13	PSC-AC0001	Screw	11	B-41	SC-000507	Screw(M3.5xL6)	43	M-74
GP-014003	Step Board Radiator Sheet(A)	43	M-82	PSC-AC0002	Screw(M4xP0.7)	7	A-58	SFAM-550-001	Main Motor	11	B-40
GP-014311	Step Board Sticker	41	M-61	PSC-AC0003	Screw(M5xP0.8)	15	C1-41	SP-000030	Large Button Clamp Plate Spring(L)	31	I-32-2
GP-014312	Main Board Sticker	41	M-62	PSC-AC0005	Screw(M4xL16)	29	H-39	SP-000031	Large Button Clamp Plate Spring(R)	31	I-43-2
GP-014565	Spacer Spring	31	I-47	PSC-AC0006	Screw(M6)	19	D-44	SP-000032	Medium Button Clamp Plate Spring(R)	31	I-43-1

Index

[illegible]

Index

[illegible]