
UPPER THREADING-TWO-NEEDLES (TANDEM)

Machine 253-212



Assembly

Turn machine pulley over toward operator until needles are at their highest point,

Pass each needle thread from unwinder, through threading points on machine in the order shown in Figs. 15 to 18.


Dotted line indicates thread for front needle.

NOTE: Thread is passed from front to back through needle eye, as shown in Fig. 17.

Draw about two inches of thread through each needle eye with which to start sewing.







From the library of: Superior Sewing Machine & Supply LLC

Fig. 17. Threading Needles

Needle Machine (Needles - Tandem)