


## 9. THREADING THE MACHINE


Thread the machine according to the threading chart given below. (The same chart is on the inside of the looper cover.)





MO-2516





(Caution)
When using an untwisted thread such
as wooly nylon thread or weak thread,
do not wind it round the intermediate
thread guide.

