


**LIST  
OF  
PARTS**

*REX*

**MODEL** 26-188

LIST OF PARTS COMPLETE  
FOR



**M O D E L**

COMPOUND FEED. ALTERNATING PRESSERS.

SINGLE NEEDLE LOCKSTITCH.

FOR VINYL, LEATHER COATS, RUBBERIZED FABRIC and  
AUTOMOBILE WORK.

## INDEX

	Page
Accessories.....	8
Knee Lifter.....	8
Model .....	3

No.	Page	Name
T- 1	.....	Arm
T- 2	.....	Bed
T- 3	.....	Arm Screw (3)
TP-571	.....	Arm Position Pin (2)
T- 5	101	Shuttle Driver Pin (5)
T- 7	101	Main Shaft
T- 8	101	Main Shaft Front Bushing
1055Ph	101	Main Shaft Center Bushing Set Screw (3)
T- 10	101	Main Shaft Center Bushing
T- 11	101	Main Shaft Back Bushing
1053Ph	101	Feed Cam Set Screw (4)
T- 17	101	Oscillating Shaft
T- 18	101	Oscillating Shaft Front Bushing
T- 19	101	Oscillating Shaft Back Bushing
T- 21	101	Oscillating Shaft Collar
0651Ph	101	Oscillating Shaft Collar Set Screw (3)
T- 26	101	Take-up Came
T- 27	101	Take-up Came Set Screw
1054Ph	101	Take-up Came Set Screw (6)
T- 29-1	101	Take-up Crank Wedge
T- 29-2	101	Take-up Crank Wedge Screw
T- 30A-1	101	Take-up Lever
T- 30A-2	101	Take-up Lever Hinge Screw
T- 30B	101	Take-up Lever Roller
T- 30C-1	101	Needle Bar Connecting Link
T- 30C-2	101	Needle Bar Connecting Link Adjusting Screw
T- 30D	101	Take-up Crank Complete
T- 30E	101	Needle Bar Connecting Stud
T- 31	102	Needle Bar Connecting Link Holder
B- 32	102	Needle Bar Connecting Link Holder Slide Block
0513P	102	Needle Bar Connecting Link Holder Set Screw (6)
T- 34	102	Balance Wheel
B- 35	102	Balance Wheel Adjusting Screw

No.	Page	Name
T- 36	102	Needle Bar
T- 40	102	Needl Clamp with Screw
T- 41	102	Needl Clamp Thread Eyelet
0312b	102	Needl Bar Thread Guide Screw (3)
T- 43	102	Throat Plate
0631Ph	102	Throat Plate Screw (2)
A- 45	102	Bed Slide
H- 46	102	Bed Slide Spring
0311P	102	Bed Slide Spring Screw (2)
T 48	102	Presser Bar
T- 49	102	Pressure Regulating Thumb Screw
T- 49-1	102	Pressure Regulating Thumb Screw Nut
T- 50	102	Presser Bar Spring
0515b	102	Upper Feed Dog Screw (2)
T- 54-1	102	Presser Bar Lifting Pracket
07110Ph	102	Presser Bar Lifting Bracket Screw
T- 54-3	102	Presser Bar Lifting Bracket Roller & Stud
T- 57	103	Lifting Lever Link
T- 58	103	Lifting Lever Link Pin
T- 59	103	Presser Bar Lifter
T- 60	103	Pressure Bar Lifter Screw
T- 61	103	Feed Cam
T- 63	103	Feed Forked Connection
B- 64	103	Feed Forked Connection Hinge Screw with Nut (4)
T- 64	103	Feed Forked Connection Lower Screw
L- 65	103	Feed Connecting Link
L- 66	103	Feed Connecting Link Hinge Stud
1152Ph	103	Feed Connecting Link Hinge Stud Set Screw (2)
T- 68	103	Feed Regulator
B- 69	103	Feed Regulator Hinge Screw
T- 70	103	Feed Reverse Lever
0712Ph	103	Feed Reverse Lever Pinch Screw (3)
B- 72	103	Feed Reverse Lever Hinge Screw

No.	Page	Name
B- 74	103	Feed Reverse Lever Roller & Stud
B- 75	103	Feed Regulating Screw Stud
T- 75-1	103	Feed Regulating Screw Stud Set Lever
B- 76	103	Stitch Indicator Plate
0715b	103	Stitch Indicator Plate Screw
T- 78	103	Feed Regulating Screw Stud Lock Pin
B- 79	103	Feed Regulating Screw Stud Lock Pin Spring
T- 80	104	Crank Connecting Rod
0713C	104	Crank Connecting Rod Cap Screw (4)
T- 82	104	Feed Rock Shaft
T- 83	104	Feed Rock Shaft Crank
0615Ph	104	Feed Rock Shaft Crank Pinch Screw (4)
T- 85	104	Feed Lifting Rock Shaft
B- 86	104	Feed Lifting Rock Shaft Crank
B- 87	104	Feed Lifting Rock Shaft Crank Slide Block & Stud
B- 88	104	Feed Lifting Rock Shaft Screw Center with Nut (4)
T- 89	104	Feed Bar
B- 90	104	Feed Bar Screw Center with Nut (2)
T- 91	104	Feed Dog
0412Ph	104	Feed Dog Screw (4)
T- 93A	104	Shuttle Race Complete
T- 93B	105	Hook
T- 93C	105	Shuttle Driver
T- 96	105	Bobbin Case
T- 99	105	Oil Cup
T- 101	105	Tension Releasing Lever
T- 102	105	Tension Releasing Lever Pin
T- 105	105	Tension Stud
T- 107	105	Take-up Spring
B- 108	105	Tension Disc (2)
T- 110	105	Tension Regulator
T- 111	105	Tension Spring
B- 112	105	Tension Nut

No.	Page	Name
T- 114	105	Knee Lifter Lifting Lever
T- 115	105	Lifting Lever Hinge Screw
T- 116	105	Lifting Lever Pin
B- 117	105	Lifting Lever Rod Joint
B- 118	105	Lifting Lever Rod Joint Screw
T- 119	105	Lifting Lever Connecting Rod with Nut
T- 120-1	105	Lifting Lever Bell Crank
T- 120-2	105	Bell Crank Hinge Pin
T- 121	105	Bell Crank Spring
0711P	105	Arm Cap Set Screw (2)
T- 123	106	Face Plate
T- 124	106	Face Plate Thread Eyelet (upper)
T- 125	106	Face Plate Thread Eyelet (lower)
U- 126	106	Feed Reverse Lever Spring
T- 129	106	Face Plate Thread Guard
T- 130	106	Arm Side Cover
0561b	106	Arm Side Cover Thumb Screw
T- 132	106	Arm Cap
B- 136	106	Bed Oil Cup
B- 142	106	Mark Stick Pin (gold) (2)
B- 143	106	Mark Stick Pin (silver) (2)
T- 176	106	Lifting Bell Crank
T- 183	107	Upper Feed Dog Bar
04111Ph	107	Lifting Bell Crank Screw (2)
T- 186	107	Upper Feed Forked Connection Link
T- 187A-1	107	Upper Feed Forked Connection Link Hinge Screw
T- 187A-2	107	Upper Feed Forked Connection Link Hinge Screw Nut
T- 187B	107	Upper Feed Dog Bar Hinge Screw
T- 188	107	Upper Feed Forked Connection Bracket
T- 189	107	Upper Feed Forked Connection
T- 190	107	Upper Feed Forked Connection Hinge Pin

No.	Page	Name
U- 191	107	Upper Feed Forked Connection Slide Block Complete (2)
T- 192	107	Upper Feed Dog (working with foot U-193)
T- 193	107	Presser Foot (working with foot U-192)
T- 194	107	Upper Feed Driving Crank
T- 195	107	Upper Feed Driving Rock Shaft
T- 196	107	Upper Feed Driving Rock Shaft Front Bushing
1011C	107	Upper Feed Driving Rock Shaft Bushing Screw (4)
T- 198	107	Upper Feed Driving Rock Shaft Back Bushing
T- 199	108	Upper Feed Driving Rock Shaft Collar
T- 200	108	Upper Feed Driving Rock Shaft Crank
1151Ph	108	Upper Feed Driving Rock Shaft Collar Set Screw (3)
T- 201	108	Upper Feed Driving Rock Shaft Crank Connection
0518Ph	108	Face Plate Thread Eyelet (upper) Set Screw
T- 203	108	Lifting Bell Crank Bracket
0339P	108	Lifting Bell Crank Bracket Set Screw (3)
T- 205	108	Upright Bracket Plate
T- 206	108	Upper Feed Dog Bar Bracket
T- 207	.....	Upper Feed Dog Bar Bracket Pin (2)
T- 208	108	Oscillating Rock Shaft
T- 209	108	Oscillating Rock Shaft Hinge Pin
T- 210-1	108	Oscillating Rock Shaft Hinge Pin Front Bushing
T- 210-2	108	Oscillating Rock Shaft Hinge Pin Back Bushing
T- 211	108	Oscillating Shaft Crank
0514P	108	Face Plate Screw
T- 214	110	Needle size 23
T- 215	110	Bobbin

## ACCESSORIES

No.	Page	Name
BA - 1	110	Bobbin Winder Complete and wood screw (2)
BA - 3	111	Drip Pan
BA - 4	110	Oiler (vinyl)
BA - 5	110	Accessory Box
BA - 6	109	Screw Driver (large)
BA - 7	110	Screw Driver (middle)
BA - 8	110	Screw Driver (small)
BA - 10	109	Hinge Stud (2)
BA - 12	109	Spool pin
BA - 13	109	Felt Washer for Spool pin
BA - 20		Machine Cover
T - 91	104	Feed Dog
T - 214	110	Needl Size 23 (3)
T - 215	110	Bobbin (3)
T-30B-A		Take-up Lever Pooler (Nylo)

## KNEE LIFTER

BA - 2-1	109	Knee Lifter Rock Shaft
BA - 2-2	109	Knee Lifter Plate Rod
BA - 2-3	109	Knee Lifter Plate
BA - 2-4	109	Knee Lifter Hanger
BA - 2-5	109	Knee Lifter Rock Shaft Connection
BA - 2-6	109	Knee Lifter Rock Shaft Stop
BA - 2-7	109	Knee Lifter Lifting Bracket
BA - 2-8	109	Knee Lifter Plate Screw (5)
BA - 2-9	109	Knee Lifter Lifting Bracket Arm
BA - 2	.....	Knee Lifter Complete

No.	頁	名 称
T- 1	.....	アーム
T- 2	.....	ベッド
T- 3	.....	結合ボルト (3)
TP- 571	.....	ノックピン (2)
T- 5	101	テーパーピン (5)
T- 7	101	上シャフト
T- 8	101	上シャフト前メタル
1055Ph	101	上シャフト中メタル止メネジ (3)
T- 10	101	上シャフト中メタル
T- 11	101	上シャフト後メタル
1053Ph	101	モモ止メネジ (4)
T- 17	101	下シャフト
T- 18	101	下シャフト前メタル
T- 19	101	下シャフト後メタル
T- 21	101	下シャフトカラー
0651Ph	101	カラー止メネジ (3)
T- 26	101	天ビンカム
T- 27	101	カム止メネジ (大)
1054Ph	101	天ビンカム止メネジ (6)
T- 29-1	101	90°止メパイプ
T- 29-2	101	パイプネジ
T- 30A-1	101	天ビン
T- 30A-2	101	天ビン段ネジ
T- 30B	101	天ビンコロ
T- 30C-1	101	針棒クランクロット
T- 30C-2	101	針棒クランクロットネジ
T- 30D	101	90°
T- 30E	101	針棒抱キ
T- 31	102	コロ案内台
B- 32	102	針棒抱キ案内コロ
0513P	102	コロ案内台止メネジ (3)
T- 34	102	プーリー
B- 35	102	プーリー押シネジ

No.	頁	名 称
T- 36	102	針棒
T- 40	102	針止メ
T- 41	102	針棒糸カケ
0312b	102	針棒糸カケ止メネジ (3)
T- 43	102	針板
0631Ph	102	針板止メネジ (2)
A- 45	102	角板
H- 46	102	角板バネ
0311P	102	角板バネ止メネジ (2)
T- 48	102	押エ棒
T- 49	102	筒ネジ
T- 49-1	102	筒ネジナット
T- 50	102	押エバネ
0515b	102	押エ止メネジ
T- 54-1	102	押エ棒抱キ
07110Ph	102	押エ棒抱キ締メネジ
T- 54-3	102	抱キコロ
T- 57	103	タンザク
T- 58	103	タンザクピン
T- 59	103	押エ上ゲ
T- 60	103	押エ上ゲ段ネジ
T- 61	103	モモ
T- 63	103	二又
T- 64	103	テーパーネジ (ナット付) (4)
T- 64	103	二又下ネジ
L- 65	103	メガネ
L- 66	103	スリバチ
1152Ph	103	スリバチ止メネジ (2)
T- 68	103	烏口
B- 69	103	烏口段ネジ
T- 70	103	バックレバー
0712Ph	103	バックレバー締メネジ (3)
B- 72	103	バックレバー一段ネジ

No.	頁	名 称
B - 74	103	バックレバーコロ
B - 75	103	角ネジ
T - 75-1	103	角ネジ締付レバー
B - 76	103	目盛板
0715b	103	目盛板止メネジ
T - 78	103	調節ノック
B - 79	103	調節バネ
T - 80	104	立ロット
0713C	104	立ロット締メネジ (4)
T - 82	104	前後桿
T - 83	104	前後グルマ
0615Ph	104	グルマ締メネジ (4)
T - 85	104	上下桿
B - 86	104	上下グルマ
B - 87	104	上下グルマコロ
B - 88	104	大ペン (ナット付) (4)
T - 89	104	送り土台
B - 90	104	小ペン (ナット付) (2)
T - 91	104	送り
0412Ph	104	送り止メネジ (4)
T - 93A	104	大釜
T - 93B	105	中釜
T - 93C	105	トンビ
T - 96	105	ボビンケース
T - 99	105	油溝
T - 101	105	ルーパー
T - 102	105	ルーパー止メピン
T - 105	105	調子芯棒
T - 107	105	ピンピン
B - 108	105	調子皿 (2)
T - 110	105	ピンピン座金
T - 111	105	糸調子バネ
B - 112	105	ローレット

No.	頁	名 称
T- 114	105	横桿
T- 115	105	横桿段ネジ
T- 116	105	横桿ピン
B- 117	105	ナスビ
B- 118	105	ナスビ段ネジ
T- 119	105	吊り棒 (ナット付)
T- 120-1	105	大砲腕
T- 120-2	105	大砲ピン
T- 121	105	大砲バネ
0711 <sup>o</sup>	105	天板止メネジ (2)
T- 123	106	面板
T- 124	106	面板糸案内
T- 125	106	下糸カケ
U- 126	106	レバーバネ
T- 129	106	小糸カケ
T- 130	106	丸板
0561b	106	ツマミネジ (短)
T- 132	106	天板
B- 136	106	ボールオイルカップ
B- 140	106	小判マーク
T- 141	106	型式番号マーク
B- 142	106	マーク止メピン (金) (2)
B- 143	106	マーク止メピン (銀) (2)
T- 176	106	L板
T- 183	107	上送りロット
04111Ph	107	L板止メネジ (2)
T- 186	107	前後メガネ
T- 187A-1	107	前後メガネ段ネジ
T- 187A-2	107	前後メガネ段ネジナット
T- 187B	107	上送りロット段ネジ
T- 188	107	前後又軸受
T- 189	107	前後又
T- 190	107	前後又軸


No.	頁	名 称
U - 191	107	TC角玉 (2)
T - 192	107	上送り
T - 193	107	中押エ
T - 194	107	中軸グルマ
T - 195	107	中軸
T - 196	107	中軸前メタル
1011C	107	中軸メタル止メネジ (4)
T - 198	107	中軸後メタル
T - 199	108	中軸カラー
T - 200	108	中軸腕
1151Fh	108	主軸カラー止メネジ (3)
T - 201	108	前後ロット
0518Ph	108	面板上糸カケ止メネジ
T - 203	108	L板台
0339P	108	L板台止メネジ (3)
T - 205	108	上下ロット
T - 206	108	上送りロット台
T - 207	……	上送りロット台カシメピン (2)
T - 208	108	大振子
T - 209	108	大振子軸
T - 210-1	108	大振子軸前メタル
T - 210-2	108	大振子軸後メタル
T - 211	108	小振子
0514P	108	面板止メネジ
T - 214	110	針
T - 215	110	ボビン

附 属 品

No.	頁	名 称
BA - 1	110	{糸巻 (1組) {糸巻止ネジ及座金 (各2)
BA - 3	111	油 受
BA - 4	110	油 差
BA - 5	110	附属品箱
BA - 6	109	ドライバー (大)
BA - 7	110	ドライバー (中)
BA - 8	110	ドライバー (小)
BA - 10	109	ヒンヂカギ (2)
BA - 12	109	糸立棒
BA - 13	109	糸立棒フェルト
BA - 20		ミシンカバー
T - 91	104	送 り
T - 214	110	針 (3)
T - 215	110	ボビン (3)
T - 30B-A	110	天ビンコロ (ナイロン)

膝 上 グ

BA - 2-1	109	膝上グセット
BA - 2-2	109	膝上グ主軸
BA - 2-3	109	膝当て板軸
BA - 2-4	109	膝上グ主軸受
BA - 2-5	109	膝当て板軸接手
BA - 2-6	109	膝上グ主軸廻シ止め
BA - 2-7	109	膝上グ軸接手
BA - 2-8	109	膝当て板止めネジ (5)
BA - 2-9	109	膝上グ軸
BA - 2	……	膝上グセット



0513P



B-35




T-40



T-48



T-50



T-36



T-41



0312b



T-43



0631Ph



0515b



A-45



T-54-1

07110Ph



T-54-3

B-32



T-31



T-34



H-46




0311P


T-49



T-49-1







T-93B



T-93C



T-96



T-99



T-101



T-102



T-105



T-107



B-108



T-111



B-112



0711P



T-115



T-116



T-110



B-117



B-118



T-120-2



T-121




T-114



T-120-1



T-123




T-130



0501b



T-132



T-124



T-125



U-126



B-136



T-129



T-176



B-142



B-143



T-183



04111 Ph



T-186



T-187A-1



T-187B



T-188



T-189



T-190



T-187A-2



T-192



T-194



T-196



1011C



T-198



U-191

T-193



T-195



U-199



0518Ph



T-208



T-203



T-200



0339P



T-205



T-210-1



T-201



T-210-2



T-209



T-211



1151Ph



0514P



T-206



BA-2-1



BA-2-7



BA-12




BA-2-2



BA-6



BA-2-9



BA-2-6



BA-13



BA-2-3



BA-2-5



BA-2-8




BA-2-4



BA-10



B1A-5



BA-1



BA-1



BA-1

BA-8



BA-7



BA-4



T-215



T-214



BA-3

